

Changes to Table 3

	From	To
Vin to GND	"-0.3V to 3.6V"	"-0.3V to 4.0V"
Vout to GND	"-0.3V to 3.6V"	"-0.3V to VIN"
EN to GND	"-0.3V to 3.6V"	"-0.3V to VIN"
SS to GND	"-0.3V to 3.6V"	"-0.3V to VIN"
PG to GND	"-0.3V to 3.6V"	"-0.3V to 4.0V"
Sense/ADJ to GND	"-0.3V to 3.6V"	"-0.3V to VIN"