1 Products affected

Product hierarchy no. *				Part no.	SBU	Type / Description
SBU	PG	PUG	Type			
01	001	020	0000000050	See list	Circuit Protection	MSF 125
01	001	020	0000000051	See list	Circuit Protection	MSF 250
01	001	020	0000000052	See list	Circuit Protection	MST 250
01	001	020	0000000053	See list	Circuit Protection	MXT 250
01	001	020	0000000059	See list	Circuit Protection	MSTU 250
01	001	023	0000000064	See list	Circuit Protection	OMF 250
01	001	023	0000000080	See list	Circuit Protection	OMT
01	001	023	0000000082	See list	Circuit Protection	UMT 250
01	001	023	0000000094	See list	Circuit Protection	UMT-H
01	001	023	0000000094	See list	Circuit Protection	UMT-M
01	001	023	0000000106	See list	Circuit Protection	UMT-W
01	001	023	0000000350	See list	Circuit Protection	UMZ 250
01	001	023	0000000351	See list	Circuit Protection	UMF 250
01	001	023	0000000352	See list	Circuit Protection	UMK 250
01	001	023	0000000353	See list	Circuit Protection	HCSF
01	001	023	0000000354	See list	Circuit Protection	HCF
01	001	024	0000000060	See list	Circuit Protection	OMF 63
01	001	024	0000000061	See list	Circuit Protection	OMK 63
01	001	024	0000000062	See list	Circuit Protection	OMF 125
01	001	024	0000000063	See list	Circuit Protection	OMK 125
01	001	024	0000000079	See list	Circuit Protection	OMT 125
01	001	024	0000000081	See list	Circuit Protection	OMZ 125
01	001	025	0000000201	See list	Circuit Protection	MGA
01	001	025	0000000202	See list	Circuit Protection	MGA-S
01	001	025	0000000203	See list	Circuit Protection	MGA-A
01	001	025	0000000205	See list	Circuit Protection	USF 1206
01	001	025	0000000206	See list	Circuit Protection	USI 1206
01	001	025	0000000207	See list	Circuit Protection	UST 1206
01	001	025	0000000210	See list	Circuit Protection	USF 0603
01	001	025	0000000221	See list	Circuit Protection	USFF 1206
01	001	025	0000000230	See list	Circuit Protection	UAI 1206
01	022	001	0000000001	See list	Circuit Protection	RTS
01	022	001	0000000002	See list	Circuit Protection	USN 1206

*SBU (2-digit) / PG (3-digit) / PUG (3-digit) / Type (10-digit)

2 Type of change

- Modified label
- Improved identification product configuration code on the label

3 Detailed description of change

All product types listed in section 1 receive a new label layout.

To better visualize the changes, we have used colors and numbers to cluster information into the following sections (The colors and white numbers are not part of the new label layout):

Product identification section: To improve readability, we clustered all the information concerning product identification in this group. To increase clarity, we introduce our product configuration code into this area. 1

Product conformity section: Identical information was slightly rearranged. 2

Product logistics section: Label names changed. Information was slightly rearranged. 3

Product approval section: Identical information was slightly rearranged. 4

Interruption ratings section: Identical information was slightly rearranged. 5

Origin information section: Label for Factory Code was added. Information was slightly rearranged. 6

Old label	New label
	

4 Reason of change

We modernize our label printing process to increase standardization and harmonize processes throughout all SCHURTER factory locations.

5 Release date

Packaging labels will be changed earliest in week 47/2020 (Date code 2047 or higher on the label).

6 Impact of change and recommended action

Form	No	
Fit	No	
Function	No	
Manufacturing	No	
Label	Yes	No actions required since bar code & 2D-code are not affected by the change.
Packaging	No	

7 Reference Documents / Attachments

Kind of document	Remarks
List of affected articles	

Product Information Section

Part Number	Old Label Information			New Label Information		
P/N	Type	Part Name	Characteristics	Type	Short Text	Configuration Code
3409.0006	HCSF	Sub-miniature fuse	4 A 125 VDC	HCSF	HCSF Fuse FF 4A	HCSF-3220-4A000-SMD-SF-PB-00
3409.0006	HCSF	Sub-miniature fuse	4 A 125 VDC	HCSF	HCSF Fuse FF 4A	HCSF-3220-4A000-SMD-SF-PB-00
3409.0006	HCSF	Sub-miniature fuse	4 A 125 VDC	HCSF	HCSF Fuse FF 4A	HCSF-3220-4A000-SMD-SF-PB-00
3409.0007	HCSF	Sub-miniature fuse	5 A 125 VDC	HCSF	HCSF Fuse FF 5A	HCSF-3220-5A000-SMD-SF-PB-00
3409.0008	HCSF	Sub-miniature fuse	6.3 A 125 VDC	HCSF	HCSF Fuse FF 6.3A	HCSF-3220-6A300-SMD-SF-PB-00
3409.0008	HCSF	Sub-miniature fuse	6.3 A 125 VDC	HCSF	HCSF Fuse FF 6.3A	HCSF-3220-6A300-SMD-SF-PB-00
3409.0008	HCSF	Sub-miniature fuse	6.3 A 125 VDC	HCSF	HCSF Fuse FF 6.3A	HCSF-3220-6A300-SMD-SF-PB-00
3409.0009	HCSF	Sub-miniature fuse	7.5 A 125 VDC	HCSF	HCSF Fuse FF 7.5A	HCSF-3220-7A500-SMD-SF-PB-00
3409.0011	HCSF	Sub-miniature fuse	10 A 125 VDC	HCSF	HCSF Fuse FF 10A	HCSF-3220-10A00-SMD-SF-PB-00
3409.0015	HCSF	Sub-miniature fuse	15A 125 VDC	HCSF	HCSF Fuse FF 15A	HCSF-3220-15A00-SMD-SF-PB-00
3410.0021.01	MGA	Sub-miniature fuse	200 mA 125VAC / DC	MGA	MGA Fuse FF 200mA	MGA-1206-0A200-SMD-SF-SN-00
3410.0021.02	MGA	Sub-miniature fuse	200 mA 125VAC / DC	MGA	MGA Fuse FF 200mA	MGA-1206-0A200-SMD-SF-SN-00
3410.0021.03	MGA	Sub-miniature fuse	200 mA 125VAC / DC	MGA	MGA Fuse FF 200mA	MGA-1206-0A200-SMD-SF-SN-00
3410.0021.04	MGA	Sub-miniature fuse	200 mA 125VAC / DC	MGA	MGA Fuse FF 200mA	MGA-1206-0A200-SMD-SF-SN-00
3410.0022.01	MGA	Sub-miniature fuse	250 mA 125VAC / DC	MGA	MGA Fuse FF 250mA	MGA-1206-0A250-SMD-SF-SN-00
3410.0022.02	MGA	Sub-miniature fuse	250 mA 125VAC / DC	MGA	MGA Fuse FF 250mA	MGA-1206-0A250-SMD-SF-SN-00
3410.0022.03	MGA	Sub-miniature fuse	250 mA 125VAC / DC	MGA	MGA Fuse FF 250mA	MGA-1206-0A250-SMD-SF-SN-00
3410.0022.04	MGA	Sub-miniature fuse	250 mA 125VAC / DC	MGA	MGA Fuse FF 250mA	MGA-1206-0A250-SMD-SF-SN-00
3410.0025.01	MGA	Sub-miniature fuse	375 mA 125VAC / DC	MGA	MGA Fuse FF 375mA	MGA-1206-0A375-SMD-SF-SN-00
3410.0025.02	MGA	Sub-miniature fuse	375 mA 125VAC / DC	MGA	MGA Fuse FF 375mA	MGA-1206-0A375-SMD-SF-SN-00
3410.0025.03	MGA	Sub-miniature fuse	375 mA 125VAC / DC	MGA	MGA Fuse FF 375mA	MGA-1206-0A375-SMD-SF-SN-00
3410.0025.04	MGA	Sub-miniature fuse	375 mA 125VAC / DC	MGA	MGA Fuse FF 375mA	MGA-1206-0A375-SMD-SF-SN-00
3410.0027.01	MGA	Sub-miniature fuse	500 mA 125VAC / DC	MGA	MGA Fuse FF 500mA	MGA-1206-0A500-SMD-SF-SN-00
3410.0027.02	MGA	Sub-miniature fuse	500 mA 125VAC / DC	MGA	MGA Fuse FF 500mA	MGA-1206-0A500-SMD-SF-SN-00
3410.0027.03	MGA	Sub-miniature fuse	500 mA 125VAC / DC	MGA	MGA Fuse FF 500mA	MGA-1206-0A500-SMD-SF-SN-00
3410.0027.04	MGA	Sub-miniature fuse	500 mA 125VAC / DC	MGA	MGA Fuse FF 500mA	MGA-1206-0A500-SMD-SF-SN-00
3410.0029.01	MGA	Sub-miniature fuse	750 mA 125VAC / DC	MGA	MGA Fuse FF 750mA	MGA-1206-0A750-SMD-SF-SN-00
3410.0029.02	MGA	Sub-miniature fuse	750 mA 125VAC / DC	MGA	MGA Fuse FF 750mA	MGA-1206-0A750-SMD-SF-SN-00
3410.0029.03	MGA	Sub-miniature fuse	750 mA 125VAC / DC	MGA	MGA Fuse FF 750mA	MGA-1206-0A750-SMD-SF-SN-00
3410.0029.04	MGA	Sub-miniature fuse	750 mA 125VAC / DC	MGA	MGA Fuse FF 750mA	MGA-1206-0A750-SMD-SF-SN-00
3410.0031.01	MGA	Sub-miniature fuse	1A 125VAC / DC	MGA	MGA Fuse FF 1A	MGA-1206-1A000-SMD-SF-SN-00
3410.0031.02	MGA	Sub-miniature fuse	1A 125VAC / DC	MGA	MGA Fuse FF 1A	MGA-1206-1A000-SMD-SF-SN-00
3410.0031.03	MGA	Sub-miniature fuse	1A 125VAC / DC	MGA	MGA Fuse FF 1A	MGA-1206-1A000-SMD-SF-SN-00
3410.0031.04	MGA	Sub-miniature fuse	1A 125VAC / DC	MGA	MGA Fuse FF 1A	MGA-1206-1A000-SMD-SF-SN-00
3410.0033.01	MGA	Sub-miniature fuse	1.5 A 125VAC / DC	MGA	MGA Fuse FF 1.5A	MGA-1206-1A500-SMD-SF-SN-00
3410.0033.02	MGA	Sub-miniature fuse	1.5 A 125VAC / DC	MGA	MGA Fuse FF 1.5A	MGA-1206-1A500-SMD-SF-SN-00
3410.0033.03	MGA	Sub-miniature fuse	1.5 A 125VAC / DC	MGA	MGA Fuse FF 1.5A	MGA-1206-1A500-SMD-SF-SN-00
3410.0033.04	MGA	Sub-miniature fuse	1.5 A 125VAC / DC	MGA	MGA Fuse FF 1.5A	MGA-1206-1A500-SMD-SF-SN-00
3410.0035.01	MGA	Sub-miniature fuse	2A 125VAC / DC	MGA	MGA Fuse FF 2A	MGA-1206-2A000-SMD-SF-SN-00
3410.0035.02	MGA	Sub-miniature fuse	2A 125VAC / DC	MGA	MGA Fuse FF 2A	MGA-1206-2A000-SMD-SF-SN-00
3410.0035.03	MGA	Sub-miniature fuse	2A 125VAC / DC	MGA	MGA Fuse FF 2A	MGA-1206-2A000-SMD-SF-SN-00
3410.0035.04	MGA	Sub-miniature fuse	2A 125VAC / DC	MGA	MGA Fuse FF 2A	MGA-1206-2A000-SMD-SF-SN-00
3410.0036.01	MGA	Sub-miniature fuse	2.5 A 125VAC / DC	MGA	MGA Fuse FF 2.5A	MGA-1206-2A500-SMD-SF-SN-00
3410.0036.02	MGA	Sub-miniature fuse	2.5 A 125VAC / DC	MGA	MGA Fuse FF 2.5A	MGA-1206-2A500-SMD-SF-SN-00
3410.0036.03	MGA	Sub-miniature fuse	2.5 A 125VAC / DC	MGA	MGA Fuse FF 2.5A	MGA-1206-2A500-SMD-SF-SN-00
3410.0036.04	MGA	Sub-miniature fuse	2.5 A 125VAC / DC	MGA	MGA Fuse FF 2.5A	MGA-1206-2A500-SMD-SF-SN-00
3410.0037.01	MGA	Sub-miniature fuse	3 A 125VAC / DC	MGA	MGA Fuse FF 3A	MGA-1206-3A000-SMD-SF-SN-00
3410.0037.02	MGA	Sub-miniature fuse	3 A 125VAC / DC	MGA	MGA Fuse FF 3A	MGA-1206-3A000-SMD-SF-SN-00
3410.0037.03	MGA	Sub-miniature fuse	3 A 125VAC / DC	MGA	MGA Fuse FF 3A	MGA-1206-3A000-SMD-SF-SN-00
3410.0037.04	MGA	Sub-miniature fuse	3 A 125VAC / DC	MGA	MGA Fuse FF 3A	MGA-1206-3A000-SMD-SF-SN-00
3410.0141.01	MGA	Sub-miniature fuse	5 A 32VAC / 125V DC	MGA	MGA Fuse FF 5A	MGA-1206-5A000-SMD-SF-SN-00
3410.0141.02	MGA	Sub-miniature fuse	5 A 32VAC / 125V DC	MGA	MGA Fuse FF 5A	MGA-1206-5A000-SMD-SF-SN-00
3410.0141.03	MGA	Sub-miniature fuse	5 A 32VAC / 125V DC	MGA	MGA Fuse FF 5A	MGA-1206-5A000-SMD-SF-SN-00
3410.0141.04	MGA	Sub-miniature fuse	5 A 32VAC / 125V DC	MGA	MGA Fuse FF 5A	MGA-1206-5A000-SMD-SF-SN-00
3410.0240.01	MGA	Sub-miniature fuse	4 A 63VAC / 125V DC	MGA	MGA Fuse FF 4A	MGA-1206-4A000-SMD-SF-SN-00
3410.0240.02	MGA	Sub-miniature fuse	4 A 63VAC / 125V DC	MGA	MGA Fuse FF 4A	MGA-1206-4A000-SMD-SF-SN-00
3410.0240.03	MGA	Sub-miniature fuse	4 A 63VAC / 125V DC	MGA	MGA Fuse FF 4A	MGA-1206-4A000-SMD-SF-SN-00
3410.0240.04	MGA	Sub-miniature fuse	4 A 63VAC / 125V DC	MGA	MGA Fuse FF 4A	MGA-1206-4A000-SMD-SF-SN-00
3-103-085	MGA-A	Sub-miniature fuse	200mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 200mA	MGAA-1206-0A200-SMD-SF-AU-00
3-103-086	MGA-A	Sub-miniature fuse	200mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 200mA	MGAA-1206-0A200-SMD-SF-AU-00
3-103-087	MGA-A	Sub-miniature fuse	200mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 200mA	MGAA-1206-0A200-SMD-SF-AU-00
3-103-088	MGA-A	Sub-miniature fuse	200mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 200mA	MGAA-1206-0A200-SMD-SF-AU-00
3-103-089	MGA-A	Sub-miniature fuse	250mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 250mA	MGAA-1206-0A250-SMD-SF-AU-00
3-103-090	MGA-A	Sub-miniature fuse	250mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 250mA	MGAA-1206-0A250-SMD-SF-AU-00
3-103-091	MGA-A	Sub-miniature fuse	250mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 250mA	MGAA-1206-0A250-SMD-SF-AU-00
3-103-092	MGA-A	Sub-miniature fuse	250mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 250mA	MGAA-1206-0A250-SMD-SF-AU-00
3-103-093	MGA-A	Sub-miniature fuse	375mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 375mA	MGAA-1206-0A375-SMD-SF-AU-00
3-103-094	MGA-A	Sub-miniature fuse	375mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 375mA	MGAA-1206-0A375-SMD-SF-AU-00
3-103-095	MGA-A	Sub-miniature fuse	375mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 375mA	MGAA-1206-0A375-SMD-SF-AU-00
3-103-096	MGA-A	Sub-miniature fuse	375mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 375mA	MGAA-1206-0A375-SMD-SF-AU-00
3-103-097	MGA-A	Sub-miniature fuse	500mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 500mA	MGAA-1206-0A500-SMD-SF-AU-00
3-103-098	MGA-A	Sub-miniature fuse	500mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 500mA	MGAA-1206-0A500-SMD-SF-AU-00
3-103-099	MGA-A	Sub-miniature fuse	500mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 500mA	MGAA-1206-0A500-SMD-SF-AU-00
3-103-100	MGA-A	Sub-miniature fuse	500mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 500mA	MGAA-1206-0A500-SMD-SF-AU-00
3-103-101	MGA-A	Sub-miniature fuse	750mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 750mA	MGAA-1206-0A750-SMD-SF-AU-00
3-103-102	MGA-A	Sub-miniature fuse	750mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 750mA	MGAA-1206-0A750-SMD-SF-AU-00
3-103-103	MGA-A	Sub-miniature fuse	750mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 750mA	MGAA-1206-0A750-SMD-SF-AU-00
3-103-104	MGA-A	Sub-miniature fuse	750mA 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 750mA	MGAA-1206-0A750-SMD-SF-AU-00
3-103-105	MGA-A	Sub-miniature fuse	1A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 1A	MGAA-1206-1A000-SMD-SF-AU-00
3-103-106	MGA-A	Sub-miniature fuse	1A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 1A	MGAA-1206-1A000-SMD-SF-AU-00
3-103-107	MGA-A	Sub-miniature fuse	1A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 1A	MGAA-1206-1A000-SMD-SF-AU-00
3-103-108	MGA-A	Sub-miniature fuse	1A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 1A	MGAA-1206-1A000-SMD-SF-AU-00
3-103-109	MGA-A	Sub-miniature fuse	1.5A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 1.5A	MGAA-1206-1A500-SMD-SF-AU-00
3-103-110	MGA-A	Sub-miniature fuse	1.5A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 1.5A	MGAA-1206-1A500-SMD-SF-AU-00
3-103-111	MGA-A	Sub-miniature fuse	1.5A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 1.5A	MGAA-1206-1A500-SMD-SF-AU-00
3-103-112	MGA-A	Sub-miniature fuse	1.5A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 1.5A	MGAA-1206-1A500-SMD-SF-AU-00
3-103-113	MGA-A	Sub-miniature fuse	2A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 2A	MGAA-1206-2A000-SMD-SF-AU-00
3-103-114	MGA-A	Sub-miniature fuse	2A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 2A	MGAA-1206-2A000-SMD-SF-AU-00
3-103-115	MGA-A	Sub-miniature fuse	2A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 2A	MGAA-1206-2A000-SMD-SF-AU-00
3-103-116	MGA-A	Sub-miniature fuse	2A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 2A	MGAA-1206-2A000-SMD-SF-AU-00
3-103-117	MGA-A	Sub-miniature fuse	2.5A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 2.5A	MGAA-1206-2A500-SMD-SF-AU-00
3-103-118	MGA-A	Sub-miniature fuse	2.5A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 2.5A	MGAA-1206-2A500-SMD-SF-AU-00
3-103-119	MGA-A	Sub-miniature fuse	2.5A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 2.5A	MGAA-1206-2A500-SMD-SF-AU-00
3-103-120	MGA-A	Sub-miniature fuse	2.5A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 2.5A	MGAA-1206-2A500-SMD-SF-AU-00
3-103-121	MGA-A	Sub-miniature fuse	3A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 3A	MGAA-1206-3A000-SMD-SF-AU-00
3-103-122	MGA-A	Sub-miniature fuse	3A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 3A	MGAA-1206-3A000-SMD-SF-AU-00
3-103-123	MGA-A	Sub-miniature fuse	3A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 3A	MGAA-1206-3A000-SMD-SF-AU-00
3-103-124	MGA-A	Sub-miniature fuse	3A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 3A	MGAA-1206-3A000-SMD-SF-AU-00
3-103-125	MGA-A	Sub-miniature fuse	4A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 4A	MGAA-1206-4A000-SMD-SF-AU-00
3-103-126	MGA-A	Sub-miniature fuse	4A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 4A	MGAA-1206-4A000-SMD-SF-AU-00
3-103-127	MGA-A	Sub-miniature fuse	4A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 4A	MGAA-1206-4A000-SMD-SF-AU-00
3-103-128	MGA-A	Sub-miniature fuse	4A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 4A	MGAA-1206-4A000-SMD-SF-AU-00
3-103-129	MGA-A	Sub-miniature fuse	5A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 5A	MGAA-1206-5A000-SMD-SF-AU-00
3-103-130	MGA-A	Sub-miniature fuse	5A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 5A	MGAA-1206-5A000-SMD-SF-AU-00
3-103-131	MGA-A	Sub-miniature fuse	5A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 5A	MGAA-1206-5A000-SMD-SF-AU-00
3-103-132	MGA-A	Sub-miniature fuse	5A 125VAC / 125VDC	MGA-A	MGA-A Fuse FF 5A	MGAA-1206-5A000-SMD-SF-AU-00
3410.0310	MGA-S	Sub-miniature fuse	0.14 A 125 V	MGA-S	MGA-S Fuse FF 140mA	MGAS-1206-0A140-SMD-SF-PB-00
3410.0319	MGA-S	Sub-miniature fuse	2.1A 125 V	MGA-S	MGA-S Fuse FF 2.1A	MGAS-1206-2A100-SMD-SF-PB-00
3410.0321	MGA-S	Sub-miniature fuse	3.5 A 32 V	MGA-S	MGA-S Fuse FF 3.5A	MGAS-1206-3A500-SMD-SF-PB-00
3410.0321	MGA-S	Sub-miniature fuse	3.5 A 32 V	MGA-S	MGA-S Fuse FF 3.5A	MGAS-1206-3A500-SMD-SF-PB-00
3410.0311	MGA-S	Sub-miniature fuse	0.175 A 125 V	MGA-S	MGA-S Fuse FF 175mA	MGAS-1206-0A175-SMD-SF-PB-00
3410.0317	MGA-S	Sub-miniature fuse	1.4 A 125 V	MGA-S	MGA-S Fuse FF 1.4A	MGAS-1206-1A400-SMD-SF-PB-00
3410.0320	MGA-S	Sub-miniature fuse	2.8 A 63 V	MGA-S	MGA-S Fuse FF 2.8A	MGAS-1206-2A800-SMD-SF-PB-00

3410.0312	MGA-S	Sub-miniature fuse	0.262A 125 V	MGA-S	MGA-S Fuse FF 262mA	MGAS-1206-0A262-SMD-SF-PB-00
3410.0320	MGA-S	Sub-miniature fuse	2.8 A 63 V	MGA-S	MGA-S Fuse FF 2.8A	MGAS-1206-2A800-SMD-SF-PB-00
3410.0315	MGA-S	Sub-miniature fuse	0.7 A 125 V	MGA-S	MGA-S Fuse FF 700mA	MGAS-1206-0A700-SMD-SF-PB-00
3410.0316	MGA-S	Sub-miniature fuse	1.05 A 125 V	MGA-S	MGA-S Fuse FF 1.05A	MGAS-1206-1A050-SMD-SF-PB-00
3410.0313	MGA-S	Sub-miniature fuse	0.35A 125 V	MGA-S	MGA-S Fuse FF 350mA	MGAS-1206-0A350-SMD-SF-PB-00
3410.0314	MGA-S	Sub-miniature fuse	0.525 A 125 V	MGA-S	MGA-S Fuse FF 525mA	MGAS-1206-0A525-SMD-SF-PB-00
3410.0318	MGA-S	Sub-miniature fuse	1.75 A 125 V	MGA-S	MGA-S Fuse FF 1.75A	MGAS-1206-1A750-SMD-SF-PB-00
3410.0319	MGA-S	Sub-miniature fuse	2.1A 125 V	MGA-S	MGA-S Fuse FF 2.1A	MGAS-1206-2A100-SMD-SF-PB-00
3410.0321	MGA-S	Sub-miniature fuse	3.5 A 32 V	MGA-S	MGA-S Fuse FF 3.5A	MGAS-1206-3A500-SMD-SF-PB-00
0034.4641	MSF	MICROFUSE 125 V	F 1A 125V	MSF 125	MSF 125 Fuse F 1A	MSF125-6488-1A000-THT-0F-SN-00
0034.4641	MSF	MICROFUSE 125 V	F 1A 125V	MSF 125	MSF 125 Fuse F 1A	MSF125-6488-1A000-THT-0F-SN-00
0034.4209	MSF 125	Sub-miniature fuse-links	F 100mA 125VAC / DC	MSF 125	MSF 125 Fuse F 100mA	MSF125-6488-0A100-THT-0F-SN-00
0034.4210	MSF 125	Sub-miniature fuse-links	F 125mA 125VAC / DC	MSF 125	MSF 125 Fuse F 125mA	MSF125-6488-0A125-THT-0F-SN-00
0034.4211	MSF 125	Sub-miniature fuse-links	F 160mA 125VAC / DC	MSF 125	MSF 125 Fuse F 160mA	MSF125-6488-0A160-THT-0F-SN-00
0034.4212	MSF 125	Sub-miniature fuse-links	F 200mA 125VAC / DC	MSF 125	MSF 125 Fuse F 200mA	MSF125-6488-0A200-THT-0F-SN-00
0034.4213	MSF 125	Sub-miniature fuse-links	F 250mA 125VAC / DC	MSF 125	MSF 125 Fuse F 250mA	MSF125-6488-0A250-THT-0F-SN-00
0034.4214	MSF 125	Sub-miniature fuse-links	F 315mA 125VAC / DC	MSF 125	MSF 125 Fuse F 315mA	MSF125-6488-0A315-THT-0F-SN-00
0034.4215	MSF 125	Sub-miniature fuse-links	F 400mA 125VAC / DC	MSF 125	MSF 125 Fuse F 400mA	MSF125-6488-0A400-THT-0F-SN-00
0034.4216	MSF 125	Sub-miniature fuse-links	F 500mA 125VAC / DC	MSF 125	MSF 125 Fuse F 500mA	MSF125-6488-0A500-THT-0F-SN-00
0034.4217	MSF 125	Sub-miniature fuse-links	F 630mA 125VAC / DC	MSF 125	MSF 125 Fuse F 630mA	MSF125-6488-0A630-THT-0F-SN-00
0034.4218	MSF 125	Sub-miniature fuse-links	F 710mA 125VAC / DC	MSF 125	MSF 125 Fuse F 710mA	MSF125-6488-0A710-THT-0F-SN-00
0034.4219	MSF 125	Sub-miniature fuse-links	F 750mA 125VAC / DC	MSF 125	MSF 125 Fuse F 750mA	MSF125-6488-0A750-THT-0F-SN-00
0034.4220	MSF 125	Sub-miniature fuse-links	F 800mA 125VAC / DC	MSF 125	MSF 125 Fuse F 800mA	MSF125-6488-0A800-THT-0F-SN-00
0034.4221	MSF 125	Sub-miniature fuse-links	F 1A 125VAC / DC	MSF 125	MSF 125 Fuse F 1A	MSF125-6488-1A000-THT-0F-SN-00
0034.4222	MSF 125	Sub-miniature fuse-links	F 1.25A 125VAC / DC	MSF 125	MSF 125 Fuse F 1.25A	MSF125-6488-1A250-THT-0F-SN-00
0034.4223	MSF 125	Sub-miniature fuse-links	F 1.6A 125VAC / DC	MSF 125	MSF 125 Fuse F 1.6A	MSF125-6488-1A600-THT-0F-SN-00
0034.4224	MSF 125	Sub-miniature fuse-links	F 2A 125VAC / DC	MSF 125	MSF 125 Fuse F 2A	MSF125-6488-2A000-THT-0F-SN-00
0034.4225	MSF 125	Sub-miniature fuse-links	F 2.5A 125VAC / DC	MSF 125	MSF 125 Fuse F 2.5A	MSF125-6488-2A500-THT-0F-SN-00
0034.4226	MSF 125	Sub-miniature fuse-links	F 3.15A 125VAC / DC	MSF 125	MSF 125 Fuse F 3.15A	MSF125-6488-3A150-THT-0F-SN-00
0034.4227	MSF 125	Sub-miniature fuse-links	F 4A 125VAC / DC	MSF 125	MSF 125 Fuse F 4A	MSF125-6488-4A000-THT-0F-SN-00
0034.4228	MSF 125	Sub-miniature fuse-links	F 5A 125VAC / DC	MSF 125	MSF 125 Fuse F 5A	MSF125-6488-5A000-THT-0F-SN-00
0034.4239	MSF 125	Sub-miniature fuse-links	F 100mA 125VAC / DC	MSF 125	MSF 125 Fuse F 100mA	MSF125-6488-0A100-THT-0F-SN-00
0034.4240	MSF 125	Sub-miniature fuse-links	F 125mA 125VAC / DC	MSF 125	MSF 125 Fuse F 125mA	MSF125-6488-0A125-THT-0F-SN-00
0034.4241	MSF 125	Sub-miniature fuse-links	F 160mA 125V	MSF 125	MSF 125 Fuse F 160mA	MSF125-6488-0A160-THT-0F-SN-00
0034.4242	MSF 125	Sub-miniature fuse-links	F 200mA 125VAC / DC	MSF 125	MSF 125 Fuse F 200mA	MSF125-6488-0A200-THT-0F-SN-00
0034.4243	MSF 125	Sub-miniature fuse-links	F 250mA 125VAC / DC	MSF 125	MSF 125 Fuse F 250mA	MSF125-6488-0A250-THT-0F-SN-00
0034.4244	MSF 125	Sub-miniature fuse-links	F 315mA 125VAC / DC	MSF 125	MSF 125 Fuse F 315mA	MSF125-6488-0A315-THT-0F-SN-00
0034.4245	MSF 125	Sub-miniature fuse-links	F 400mA 125VAC / DC	MSF 125	MSF 125 Fuse F 400mA	MSF125-6488-0A400-THT-0F-SN-00
0034.4246	MSF 125	Sub-miniature fuse-links	F 500mA 125VAC / DC	MSF 125	MSF 125 Fuse F 500mA	MSF125-6488-0A500-THT-0F-SN-00
0034.4247	MSF 125	Sub-miniature fuse-links	F 630mA 125VAC / DC	MSF 125	MSF 125 Fuse F 630mA	MSF125-6488-0A630-THT-0F-SN-00
0034.4248	MSF 125	Sub-miniature fuse-links	F 710mA 125VAC / DC	MSF 125	MSF 125 Fuse F 710mA	MSF125-6488-0A710-THT-0F-SN-00
0034.4249	MSF 125	Sub-miniature fuse-links	F 750mA 125VAC / DC	MSF 125	MSF 125 Fuse F 750mA	MSF125-6488-0A750-THT-0F-SN-00
0034.4250	MSF 125	Sub-miniature fuse-links	F 800mA 125VAC / DC	MSF 125	MSF 125 Fuse F 800mA	MSF125-6488-0A800-THT-0F-SN-00
0034.4251	MSF 125	Sub-miniature fuse-links	F 1A 125VAC / DC	MSF 125	MSF 125 Fuse F 1A	MSF125-6488-1A000-THT-0F-SN-00
0034.4252	MSF 125	Sub-miniature fuse-links	F 1.25A 125VAC / DC	MSF 125	MSF 125 Fuse F 1.25A	MSF125-6488-1A250-THT-0F-SN-00
0034.4253	MSF 125	Sub-miniature fuse-links	F 1.6A 125VAC / DC	MSF 125	MSF 125 Fuse F 1.6A	MSF125-6488-1A600-THT-0F-SN-00
0034.4254	MSF 125	Sub-miniature fuse-links	F 2A 125VAC / DC	MSF 125	MSF 125 Fuse F 2A	MSF125-6488-2A000-THT-0F-SN-00
0034.4255	MSF 125	Sub-miniature fuse-links	F 2.5A 125VAC / DC	MSF 125	MSF 125 Fuse F 2.5A	MSF125-6488-2A500-THT-0F-SN-00
0034.4256	MSF 125	Sub-miniature fuse-links	F 3.15A 125VAC / DC	MSF 125	MSF 125 Fuse F 3.15A	MSF125-6488-3A150-THT-0F-SN-00
0034.4257	MSF 125	Sub-miniature fuse-links	F 4A 125VAC / DC	MSF 125	MSF 125 Fuse F 4A	MSF125-6488-4A000-THT-0F-SN-00
0034.4258	MSF 125	Sub-miniature fuse-links	F 5A 125VAC / DC	MSF 125	MSF 125 Fuse F 5A	MSF125-6488-5A000-THT-0F-SN-00
0034.4539	MSF 125	Sub-miniature fuse-links	F 100mA 125VAC / DC	MSF 125	MSF 125 Fuse F 100mA	MSF125-6488-0A100-THT-0F-SN-00
0034.4540	MSF 125	Sub-miniature fuse-links	F 125mA 125VAC / DC	MSF 125	MSF 125 Fuse F 125mA	MSF125-6488-0A125-THT-0F-SN-00
0034.4541	MSF 125	Sub-miniature fuse-links	F 160mA 125VAC / DC	MSF 125	MSF 125 Fuse F 160mA	MSF125-6488-0A160-THT-0F-SN-00
0034.4542	MSF 125	Sub-miniature fuse-links	F 200mA 125VAC / DC	MSF 125	MSF 125 Fuse F 200mA	MSF125-6488-0A200-THT-0F-SN-00
0034.4543	MSF 125	Sub-miniature fuse-links	F 250mA 125VAC / DC	MSF 125	MSF 125 Fuse F 250mA	MSF125-6488-0A250-THT-0F-SN-00
0034.4544	MSF 125	Sub-miniature fuse-links	F 315mA 125VAC / DC	MSF 125	MSF 125 Fuse F 315mA	MSF125-6488-0A315-THT-0F-SN-00
0034.4545	MSF 125	Sub-miniature fuse-links	F 400mA 125VAC / DC	MSF 125	MSF 125 Fuse F 400mA	MSF125-6488-0A400-THT-0F-SN-00
0034.4546	MSF 125	Sub-miniature fuse-links	F 500mA 125VAC / DC	MSF 125	MSF 125 Fuse F 500mA	MSF125-6488-0A500-THT-0F-SN-00
0034.4547	MSF 125	Sub-miniature fuse-links	F 630mA 125VAC / DC	MSF 125	MSF 125 Fuse F 630mA	MSF125-6488-0A630-THT-0F-SN-00
0034.4548	MSF 125	Sub-miniature fuse-links	F 710mA 125VAC / DC	MSF 125	MSF 125 Fuse F 710mA	MSF125-6488-0A710-THT-0F-SN-00
0034.4549	MSF 125	Sub-miniature fuse-links	F 750mA 125VAC / DC	MSF 125	MSF 125 Fuse F 750mA	MSF125-6488-0A750-THT-0F-SN-00
0034.4550	MSF 125	Sub-miniature fuse-links	F 800mA 125VAC / DC	MSF 125	MSF 125 Fuse F 800mA	MSF125-6488-0A800-THT-0F-SN-00
0034.4551	MSF 125	Sub-miniature fuse-links	F 1A 125VAC / DC	MSF 125	MSF 125 Fuse F 1A	MSF125-6488-1A000-THT-0F-SN-00
0034.4552	MSF 125	Sub-miniature fuse-links	F 1.25A 125VAC / DC	MSF 125	MSF 125 Fuse F 1.25A	MSF125-6488-1A250-THT-0F-SN-00
0034.4553	MSF 125	Sub-miniature fuse-links	F 1.6A 125VAC / DC	MSF 125	MSF 125 Fuse F 1.6A	MSF125-6488-1A600-THT-0F-SN-00
0034.4554	MSF 125	Sub-miniature fuse-links	F 2A 125VAC / DC	MSF 125	MSF 125 Fuse F 2A	MSF125-6488-2A000-THT-0F-SN-00
0034.4555	MSF 125	Sub-miniature fuse-links	F 2.5A 125VAC / DC	MSF 125	MSF 125 Fuse F 2.5A	MSF125-6488-2A500-THT-0F-SN-00
0034.4556	MSF 125	Sub-miniature fuse-links	F 3.15A 125VAC / DC	MSF 125	MSF 125 Fuse F 3.15A	MSF125-6488-3A150-THT-0F-SN-00
0034.4557	MSF 125	Sub-miniature fuse-links	F 4A 125VAC / DC	MSF 125	MSF 125 Fuse F 4A	MSF125-6488-4A000-THT-0F-SN-00
0034.4558	MSF 125	Sub-miniature fuse-links	F 5A 125VAC / DC	MSF 125	MSF 125 Fuse F 5A	MSF125-6488-5A000-THT-0F-SN-00
0034.6000	MSF 250	Sub-miniature fuse links	F 40mA / 250V	MSF 250	MSF 250 Fuse F 40mA	MSF250-8585-0A040-THT-0F-SN-00
0034.6001	MSF 250	Sub-miniature fuse links	F 50mA / 250V	MSF 250	MSF 250 Fuse F 50mA	MSF250-8585-0A050-THT-0F-SN-00
0034.6002	MSF 250	Sub-miniature fuse links	F 63mA / 250V	MSF 250	MSF 250 Fuse F 63mA	MSF250-8585-0A063-THT-0F-SN-00
0034.6003	MSF 250	Sub-miniature fuse links	F 80mA / 250V	MSF 250	MSF 250 Fuse F 80mA	MSF250-8585-0A080-THT-0F-SN-00
0034.6004	MSF 250	Sub-miniature fuse links	F 100mA / 250V	MSF 250	MSF 250 Fuse F 100mA	MSF250-8585-0A100-THT-0F-SN-00
0034.6005	MSF 250	Sub-miniature fuse links	F 125mA / 250V	MSF 250	MSF 250 Fuse F 125mA	MSF250-8585-0A125-THT-0F-SN-00
0034.6006	MSF 250	Sub-miniature fuse links	F 160mA / 250V	MSF 250	MSF 250 Fuse F 160mA	MSF250-8585-0A160-THT-0F-SN-00
0034.6007	MSF 250	Sub-miniature fuse links	F 200mA / 250V	MSF 250	MSF 250 Fuse F 200mA	MSF250-8585-0A200-THT-0F-SN-00
0034.6008	MSF 250	Sub-miniature fuse links	F 250mA / 250V	MSF 250	MSF 250 Fuse F 250mA	MSF250-8585-0A250-THT-0F-SN-00
0034.6009	MSF 250	Sub-miniature fuse links	F 315mA / 250V	MSF 250	MSF 250 Fuse F 315mA	MSF250-8585-0A315-THT-0F-SN-00
0034.6010	MSF 250	Sub-miniature fuse links	F 400mA / 250V	MSF 250	MSF 250 Fuse F 400mA	MSF250-8585-0A400-THT-0F-SN-00
0034.6011	MSF 250	Sub-miniature fuse links	F 500mA / 250V	MSF 250	MSF 250 Fuse F 500mA	MSF250-8585-0A500-THT-0F-SN-00
0034.6012	MSF 250	Sub-miniature fuse links	F 630mA / 250V	MSF 250	MSF 250 Fuse F 630mA	MSF250-8585-0A630-THT-0F-SN-00
0034.6013	MSF 250	Sub-miniature fuse links	F 800mA / 250V	MSF 250	MSF 250 Fuse F 800mA	MSF250-8585-0A800-THT-0F-SN-00
0034.6014	MSF 250	Sub-miniature fuse links	F 1A / 250VAC	MSF 250	MSF 250 Fuse F 1A	MSF250-8585-1A000-THT-0F-SN-00
0034.6015	MSF 250	Sub-miniature fuse links	F 1.25A / 250VAC	MSF 250	MSF 250 Fuse F 1.25A	MSF250-8585-1A250-THT-0F-SN-00
0034.6016	MSF 250	Sub-miniature fuse links	F 1.6A / 250VAC	MSF 250	MSF 250 Fuse F 1.6A	MSF250-8585-1A600-THT-0F-SN-00
0034.6017	MSF 250	Sub-miniature fuse links	F 2A / 250VAC	MSF 250	MSF 250 Fuse F 2A	MSF250-8585-2A000-THT-0F-SN-00
0034.6018	MSF 250	Sub-miniature fuse links	F 2.5A / 250VAC	MSF 250	MSF 250 Fuse F 2.5A	MSF250-8585-2A500-THT-0F-SN-00
0034.6019	MSF 250	Sub-miniature fuse links	F 3.15A / 250VAC	MSF 250	MSF 250 Fuse F 3.15A	MSF250-8585-3A150-THT-0F-SN-00
0034.6020	MSF 250	Sub-miniature fuse links	F 4A / 250VAC	MSF 250	MSF 250 Fuse F 4A	MSF250-8585-4A000-THT-0F-SN-00
0034.6021	MSF 250	Sub-miniature fuse links	F 5A / 250VAC	MSF 250	MSF 250 Fuse F 5A	MSF250-8585-5A000-THT-0F-SN-00
0034.6030	MSF 250	Sub-miniature fuse links	F 40mA / 250V	MSF 250	MSF 250 Fuse F 40mA	MSF250-8585-0A040-THT-0F-SN-00
0034.6031	MSF 250	Sub-miniature fuse links	F 50mA / 250V	MSF 250	MSF 250 Fuse F 50mA	MSF250-8585-0A050-THT-0F-SN-00
0034.6032	MSF 250	Sub-miniature fuse links	F 63mA / 250V	MSF 250	MSF 250 Fuse F 63mA	MSF250-8585-0A063-THT-0F-SN-00
0034.6033	MSF 250	Sub-miniature fuse links	F 80mA / 250V	MSF 250	MSF 250 Fuse F 80mA	MSF250-8585-0A080-THT-0F-SN-00
0034.6034	MSF 250	Sub-miniature fuse links	F 100mA / 250V	MSF 250	MSF 250 Fuse F 100mA	MSF250-8585-0A100-THT-0F-SN-00
0034.6035	MSF 250	Sub-miniature fuse links	F 125mA / 250V	MSF 250	MSF 250 Fuse F 125mA	MSF250-8585-0A125-THT-0F-SN-00
0034.6036	MSF 250	Sub-miniature fuse links	F 160mA / 250V	MSF 250	MSF 250 Fuse F 160mA	MSF250-8585-0A160-THT-0F-SN-00
0034.6037	MSF 250	Sub-miniature fuse links	F 200mA / 250V	MSF 250	MSF 250 Fuse F 200mA	MSF250-8585-0A200-THT-0F-SN-00
0034.6038	MSF 250	Sub-miniature fuse links	F 250mA / 250V	MSF 250	MSF 250 Fuse F 250mA	MSF250-8585-0A250-THT-0F-SN-00
0034.6039	MSF 250	Sub-miniature fuse links	F 315mA / 250V	MSF 250	MSF 250 Fuse F 315mA	MSF250-8585-0A315-THT-0F-SN-00
0034.6040	MSF 250	Sub-miniature fuse links	F 400mA / 250V	MSF 250	MSF 250 Fuse F 400mA	MSF250-8585-0A400-THT-0F-SN-00
0034.6041	MSF 250	Sub-miniature fuse links	F 500mA / 250V	MSF 250	MSF 250 Fuse F 500mA	MSF250-8585-0A500-THT-0F-SN-00
0034.6042	MSF 250	Sub-miniature fuse links	F 630mA / 250V	MSF 250	MSF 250 Fuse F 630mA	MSF250-8585-0A630-THT-0F-SN-00
0034.6043	MSF 250	Sub-miniature fuse links	F 800mA / 250V	MSF 250	MSF 250 Fuse F 800mA	MSF250-8585-0A800-THT-0F-SN-00
0034.6044	MSF 250	Sub-miniature fuse links	F 1A / 250VAC	MSF 250	MSF 250 Fuse F 1A	MSF250-8585-1A000-THT-0F-SN-00
0034.6045	MSF 250	Sub-miniature fuse links	F 1.25A / 250VAC	MSF 250	MSF 250 Fuse F 1.25A	MSF250-8585-1A250-THT-0F-SN-00
0034.6046	MSF 250	Sub-miniature fuse links	F 1.6A / 250VAC	MSF 250	MSF 250 Fuse F 1.6A	MSF250-8585-1A600-THT-0F-SN-00
0034.6047	MSF 250	Sub-miniature fuse links	F 2A / 250VAC	MSF 250	MSF 250 Fuse F 2A	MSF250-8585-2A000-THT-0F-SN-00
0034.6048	MSF 250	Sub-miniature fuse links	F 2.5A / 250VAC	MSF 250	MSF 250 Fuse F 2.5A	MSF250-8585-2A500-THT-0F-SN-00
0034.6049	MSF 250	Sub-miniature fuse links	F 3.15A / 250VAC	MSF 250	MSF 250 Fuse F 3.15A	MSF250-8585-3A150-THT-0F-SN-00
0034.6050	MSF 250	Sub-miniature fuse links	F 4A / 250VAC	MSF 250	MSF 250 Fuse F 4A	MSF250-8585-4A000-THT-0F-SN-00
0034.6051	MSF 250	Sub-miniature fuse links	F 5A / 250VAC	MSF 250	MSF 250 Fuse F 5A	MSF250-8585-5A000-THT-0F-SN-00
0034.6060	MSF 250	Sub-miniature fuse links	F 40mA / 250V	MSF 250	MSF 250 Fuse F 40mA	MSF250-8585-0A040-THT-0F-SN-00
0034.6061	MSF 250	Sub-miniature fuse links	F 50mA / 250V	MSF 250	MSF 250 Fuse F 50mA	MSF250-8585-0A050-THT-0F-SN-00
0034.6062	MSF 250	Sub-miniature fuse links	F 63mA / 250V	MSF 250	MSF 250 Fuse F 63mA	MSF250-8585-0A063-THT-0F-SN-00

0034.6063	MSF 250	Sub-miniature fuse links	F 80mA / 250V	MSF 250	MSF 250 Fuse F 80mA	MSF250-8585-0A080-THT-0F-SN-00
0034.6064	MSF 250	Sub-miniature fuse links	F 100mA / 250V	MSF 250	MSF 250 Fuse F 100mA	MSF250-8585-0A100-THT-0F-SN-00
0034.6065	MSF 250	Sub-miniature fuse links	F 125mA / 250V	MSF 250	MSF 250 Fuse F 125mA	MSF250-8585-0A125-THT-0F-SN-00
0034.6066	MSF 250	Sub-miniature fuse links	F 160mA / 250V	MSF 250	MSF 250 Fuse F 160mA	MSF250-8585-0A160-THT-0F-SN-00
0034.6067	MSF 250	Sub-miniature fuse links	F 200mA / 250V	MSF 250	MSF 250 Fuse F 200mA	MSF250-8585-0A200-THT-0F-SN-00
0034.6068	MSF 250	Sub-miniature fuse links	F 250mA / 250V	MSF 250	MSF 250 Fuse F 250mA	MSF250-8585-0A250-THT-0F-SN-00
0034.6069	MSF 250	Sub-miniature fuse links	F 315mA / 250V	MSF 250	MSF 250 Fuse F 315mA	MSF250-8585-0A315-THT-0F-SN-00
0034.6070	MSF 250	Sub-miniature fuse links	F 400mA / 250V	MSF 250	MSF 250 Fuse F 400mA	MSF250-8585-0A400-THT-0F-SN-00
0034.6071	MSF 250	Sub-miniature fuse links	F 500mA / 250V	MSF 250	MSF 250 Fuse F 500mA	MSF250-8585-0A500-THT-0F-SN-00
0034.6072	MSF 250	Sub-miniature fuse links	F 630mA / 250V	MSF 250	MSF 250 Fuse F 630mA	MSF250-8585-0A630-THT-0F-SN-00
0034.6073	MSF 250	Sub-miniature fuse links	F 800mA / 250V	MSF 250	MSF 250 Fuse F 800mA	MSF250-8585-0A800-THT-0F-SN-00
0034.6074	MSF 250	Sub-miniature fuse links	F 1A / 250VAC	MSF 250	MSF 250 Fuse F 1A	MSF250-8585-1A000-THT-0F-SN-00
0034.6075	MSF 250	Sub-miniature fuse links	F 1.25A / 250VAC	MSF 250	MSF 250 Fuse F 1.25A	MSF250-8585-1A250-THT-0F-SN-00
0034.6076	MSF 250	Sub-miniature fuse links	F 1.6A / 250VAC	MSF 250	MSF 250 Fuse F 1.6A	MSF250-8585-1A600-THT-0F-SN-00
0034.6077	MSF 250	Sub-miniature fuse links	F 2A / 250VAC	MSF 250	MSF 250 Fuse F 2A	MSF250-8585-2A000-THT-0F-SN-00
0034.6078	MSF 250	Sub-miniature fuse links	F 2.5A / 250VAC	MSF 250	MSF 250 Fuse F 2.5A	MSF250-8585-2A500-THT-0F-SN-00
0034.6079	MSF 250	Sub-miniature fuse links	F 3.15A / 250VAC	MSF 250	MSF 250 Fuse F 3.15A	MSF250-8585-3A150-THT-0F-SN-00
0034.6079.A	MSF 250	Sub-miniature fuse links	F 3.15A / 250VAC	MSF 250	MSF 250 Fuse F 3.15A	MSF250-8585-3A150-THT-0F-SN-00
0034.6080	MSF 250	Sub-miniature fuse links	F 4A / 250VAC	MSF 250	MSF 250 Fuse F 4A	MSF250-8585-4A000-THT-0F-SN-00
0034.6081	MSF 250	Sub-miniature fuse links	F 5A / 250VAC	MSF 250	MSF 250 Fuse F 5A	MSF250-8585-5A000-THT-0F-SN-00
0034.6768	MST 250	Sub-miniature fuse links	T 2A / 250VAC	MST 250	MST 250 Fuse T 2A	MST250-8585-2A000-THT-0T-SN-00
0034.6868	MST 250	MICROFUSE	T 2A / 250VAC	MST 250	MST 250 Fuse T 2A	MST250-8585-2A000-THT-0T-SN-00
0034.6817.A	MST 250	Sub-miniature fuse links	T 1.6A / 250VAC	MST 250	MST 250 Fuse T 1.6A	MST250-8585-1A600-THT-0T-SN-00
0034.6868.A	MST 250	MICROFUSE	T 2A / 250VAC	MST 250	MST 250 Fuse T 2A	MST250-8585-2A000-THT-0T-SN-00
0034.6815	MST 250	Sub-miniature fuse links	T 1A / 250VAC	MST 250	MST 250 Fuse T 1A	MST250-8585-1A000-THT-0T-SN-00
0034.6816.BF	MST 250	Sub-miniature fuse links	T 1.25A / 250VAC	MST 250	MST 250 Fuse T 1.25A	MST250-8585-1A250-THT-0T-SN-00
0034.6809.A	MST 250	Sub-miniature fuse links	T 250 mA / 250V	MST 250	MST 250 Fuse T 250mA	MST250-8585-0A250-THT-0T-SN-00
0034.6803.A	MST 250	Sub-miniature fuse links	T 63 mA / 250V	MST 250	MST 250 Fuse T 63mA	MST250-8585-0A063-THT-0T-SN-00
0034.6668	MST 250	Sub-miniature fuse links	T 2A / 250VAC	MST 250	MST 250 Fuse T 2A	MST250-8585-2A000-THT-0T-SN-00
0034.6602	MST 250	Sub-miniature fuse links	T 50mA / 250V	MST 250	MST 250 Fuse T 50mA	MST250-8585-0A050-THT-0T-SN-00
0034.6603	MST 250	Sub-miniature fuse links	T 63mA / 250V	MST 250	MST 250 Fuse T 63mA	MST250-8585-0A063-THT-0T-SN-00
0034.6604	MST 250	Sub-miniature fuse links	T 80mA / 250V	MST 250	MST 250 Fuse T 80mA	MST250-8585-0A080-THT-0T-SN-00
0034.6605	MST 250	Sub-miniature fuse links	T 100mA / 250V	MST 250	MST 250 Fuse T 100mA	MST250-8585-0A100-THT-0T-SN-00
0034.6606	MST 250	Sub-miniature fuse links	T 125mA / 250V	MST 250	MST 250 Fuse T 125mA	MST250-8585-0A125-THT-0T-SN-00
0034.6607	MST 250	Sub-miniature fuse links	T 160mA / 250V	MST 250	MST 250 Fuse T 160mA	MST250-8585-0A160-THT-0T-SN-00
0034.6608	MST 250	Sub-miniature fuse links	T 200mA / 250V	MST 250	MST 250 Fuse T 200mA	MST250-8585-0A200-THT-0T-SN-00
0034.6609	MST 250	Sub-miniature fuse links	T 250mA / 250V	MST 250	MST 250 Fuse T 250mA	MST250-8585-0A250-THT-0T-SN-00
0034.6610	MST 250	Sub-miniature fuse links	T 315mA / 250V	MST 250	MST 250 Fuse T 315mA	MST250-8585-0A315-THT-0T-SN-00
0034.6611	MST 250	Sub-miniature fuse links	T 400mA / 250V	MST 250	MST 250 Fuse T 400mA	MST250-8585-0A400-THT-0T-SN-00
0034.6612	MST 250	Sub-miniature fuse links	T 500mA / 250V	MST 250	MST 250 Fuse T 500mA	MST250-8585-0A500-THT-0T-SN-00
0034.6613	MST 250	Sub-miniature fuse links	T 630mA / 250V	MST 250	MST 250 Fuse T 630mA	MST250-8585-0A630-THT-0T-SN-00
0034.6614	MST 250	Sub-miniature fuse links	T 800mA / 250V	MST 250	MST 250 Fuse T 800mA	MST250-8585-0A800-THT-0T-SN-00
0034.6615	MST 250	Sub-miniature fuse links	T 1A / 250VAC	MST 250	MST 250 Fuse T 1A	MST250-8585-1A000-THT-0T-SN-00
0034.6616	MST 250	Sub-miniature fuse links	T 1.25A / 250VAC	MST 250	MST 250 Fuse T 1.25A	MST250-8585-1A250-THT-0T-SN-00
0034.6617	MST 250	Sub-miniature fuse links	T 1.6A / 250VAC	MST 250	MST 250 Fuse T 1.6A	MST250-8585-1A600-THT-0T-SN-00
0034.6618	MST 250	Sub-miniature fuse links	T 2A / 250VAC	MST 250	MST 250 Fuse T 2A	MST250-8585-2A000-THT-0T-SN-00
0034.6619	MST 250	Sub-miniature fuse links	T 2.5A / 250VAC	MST 250	MST 250 Fuse T 2.5A	MST250-8585-2A500-THT-0T-SN-00
0034.6620	MST 250	Sub-miniature fuse links	T 3.15A / 250VAC	MST 250	MST 250 Fuse T 3.15A	MST250-8585-3A150-THT-0T-SN-00
0034.6621	MST 250	Sub-miniature fuse links	T 4A / 250VAC	MST 250	MST 250 Fuse T 4A	MST250-8585-4A000-THT-0T-SN-00
0034.6622	MST 250	Sub-miniature fuse links	T 5A / 250VAC	MST 250	MST 250 Fuse T 5A	MST250-8585-5A000-THT-0T-SN-00
0034.6623	MST 250	Sub-miniature fuse links	T 6.3A / 250VAC	MST 250	MST 250 Fuse T 6.3A	MST250-8585-6A300-THT-0T-SN-00
0034.6702	MST 250	Sub-miniature fuse links	T 50mA / 250V	MST 250	MST 250 Fuse T 50mA	MST250-8585-0A050-THT-0T-SN-00
0034.6703	MST 250	Sub-miniature fuse links	T 63mA / 250V	MST 250	MST 250 Fuse T 63mA	MST250-8585-0A063-THT-0T-SN-00
0034.6704	MST 250	Sub-miniature fuse links	T 80mA / 250V	MST 250	MST 250 Fuse T 80mA	MST250-8585-0A080-THT-0T-SN-00
0034.6705	MST 250	Sub-miniature fuse links	T 100mA / 250V	MST 250	MST 250 Fuse T 100mA	MST250-8585-0A100-THT-0T-SN-00
0034.6706	MST 250	Sub-miniature fuse links	T 125mA / 250V	MST 250	MST 250 Fuse T 125mA	MST250-8585-0A125-THT-0T-SN-00
0034.6707	MST 250	Sub-miniature fuse links	T 160mA / 250V	MST 250	MST 250 Fuse T 160mA	MST250-8585-0A160-THT-0T-SN-00
0034.6708	MST 250	Sub-miniature fuse links	T 200mA / 250V	MST 250	MST 250 Fuse T 200mA	MST250-8585-0A200-THT-0T-SN-00
0034.6708.G	MST 250	Sub-miniature fuse links	T 200mA / 250V	MST 250	MST 250 Fuse T 200mA	MST250-8585-0A200-THT-0T-SN-00
0034.6709	MST 250	Sub-miniature fuse links	T 250mA / 250V	MST 250	MST 250 Fuse T 250mA	MST250-8585-0A250-THT-0T-SN-00
0034.6710	MST 250	Sub-miniature fuse links	T 315mA / 250V	MST 250	MST 250 Fuse T 315mA	MST250-8585-0A315-THT-0T-SN-00
0034.6711	MST 250	Sub-miniature fuse links	T 400mA / 250V	MST 250	MST 250 Fuse T 400mA	MST250-8585-0A400-THT-0T-SN-00
0034.6712	MST 250	Sub-miniature fuse links	T 500mA / 250V	MST 250	MST 250 Fuse T 500mA	MST250-8585-0A500-THT-0T-SN-00
0034.6713	MST 250	Sub-miniature fuse links	T 630mA / 250V	MST 250	MST 250 Fuse T 630mA	MST250-8585-0A630-THT-0T-SN-00
0034.6714	MST 250	Sub-miniature fuse links	T 800mA / 250V	MST 250	MST 250 Fuse T 800mA	MST250-8585-0A800-THT-0T-SN-00
0034.6715	MST 250	Sub-miniature fuse links	T 1A / 250VAC	MST 250	MST 250 Fuse T 1A	MST250-8585-1A000-THT-0T-SN-00
0034.6716	MST 250	Sub-miniature fuse links	T 1.25A / 250VAC	MST 250	MST 250 Fuse T 1.25A	MST250-8585-1A250-THT-0T-SN-00
0034.6717	MST 250	Sub-miniature fuse links	T 1.6A / 250VAC	MST 250	MST 250 Fuse T 1.6A	MST250-8585-1A600-THT-0T-SN-00
0034.6718	MST 250	Sub-miniature fuse links	T 2A / 250VAC	MST 250	MST 250 Fuse T 2A	MST250-8585-2A000-THT-0T-SN-00
0034.6719	MST 250	Sub-miniature fuse links	T 2.5A / 250VAC	MST 250	MST 250 Fuse T 2.5A	MST250-8585-2A500-THT-0T-SN-00
0034.6720	MST 250	Sub-miniature fuse links	T 3.15A / 250VAC	MST 250	MST 250 Fuse T 3.15A	MST250-8585-3A150-THT-0T-SN-00
0034.6721	MST 250	Sub-miniature fuse links	T 4A / 250VAC	MST 250	MST 250 Fuse T 4A	MST250-8585-4A000-THT-0T-SN-00
0034.6722	MST 250	Sub-miniature fuse links	T 5A / 250VAC	MST 250	MST 250 Fuse T 5A	MST250-8585-5A000-THT-0T-SN-00
0034.6723	MST 250	Sub-miniature fuse links	T 6.3A / 250VAC	MST 250	MST 250 Fuse T 6.3A	MST250-8585-6A300-THT-0T-SN-00
0034.6802	MST 250	Sub-miniature fuse links	T 50mA / 250V	MST 250	MST 250 Fuse T 50mA	MST250-8585-0A050-THT-0T-SN-00
0034.6803	MST 250	Sub-miniature fuse links	T 63mA / 250V	MST 250	MST 250 Fuse T 63mA	MST250-8585-0A063-THT-0T-SN-00
0034.6804	MST 250	Sub-miniature fuse links	T 80mA / 250V	MST 250	MST 250 Fuse T 80mA	MST250-8585-0A080-THT-0T-SN-00
0034.6805	MST 250	Sub-miniature fuse links	T 100mA / 250V	MST 250	MST 250 Fuse T 100mA	MST250-8585-0A100-THT-0T-SN-00
0034.6806	MST 250	Sub-miniature fuse links	T 125mA / 250V	MST 250	MST 250 Fuse T 125mA	MST250-8585-0A125-THT-0T-SN-00
0034.6807	MST 250	Sub-miniature fuse links	T 160mA / 250V	MST 250	MST 250 Fuse T 160mA	MST250-8585-0A160-THT-0T-SN-00
0034.6808	MST 250	Sub-miniature fuse links	T 200mA / 250V	MST 250	MST 250 Fuse T 200mA	MST250-8585-0A200-THT-0T-SN-00
0034.6809	MST 250	Sub-miniature fuse links	T 250mA / 250V	MST 250	MST 250 Fuse T 250mA	MST250-8585-0A250-THT-0T-SN-00
0034.6810	MST 250	Sub-miniature fuse links	T 315mA / 250V	MST 250	MST 250 Fuse T 315mA	MST250-8585-0A315-THT-0T-SN-00
0034.6811	MST 250	Sub-miniature fuse links	T 400mA / 250V	MST 250	MST 250 Fuse T 400mA	MST250-8585-0A400-THT-0T-SN-00
0034.6812	MST 250	Sub-miniature fuse links	T 500mA / 250V	MST 250	MST 250 Fuse T 500mA	MST250-8585-0A500-THT-0T-SN-00
0034.6813	MST 250	Sub-miniature fuse links	T 630mA / 250V	MST 250	MST 250 Fuse T 630mA	MST250-8585-0A630-THT-0T-SN-00
0034.6814	MST 250	Sub-miniature fuse links	T 800mA / 250V	MST 250	MST 250 Fuse T 800mA	MST250-8585-0A800-THT-0T-SN-00
0034.6816	MST 250	Sub-miniature fuse links	T 1.25A / 250VAC	MST 250	MST 250 Fuse T 1.25A	MST250-8585-1A250-THT-0T-SN-00
0034.6817	MST 250	Sub-miniature fuse links	T 1.6A / 250VAC	MST 250	MST 250 Fuse T 1.6A	MST250-8585-1A600-THT-0T-SN-00
0034.6818	MST 250	Sub-miniature fuse links	T 2A / 250VAC	MST 250	MST 250 Fuse T 2A	MST250-8585-2A000-THT-0T-SN-00
0034.6819	MST 250	Sub-miniature fuse links	T 2.5A / 250VAC	MST 250	MST 250 Fuse T 2.5A	MST250-8585-2A500-THT-0T-SN-00
0034.6820	MST 250	Sub-miniature fuse links	T 3.15A / 250VAC	MST 250	MST 250 Fuse T 3.15A	MST250-8585-3A150-THT-0T-SN-00
0034.6821	MST 250	Sub-miniature fuse links	T 4A / 250VAC	MST 250	MST 250 Fuse T 4A	MST250-8585-4A000-THT-0T-SN-00
0034.6822	MST 250	Sub-miniature fuse links	T 5A / 250VAC	MST 250	MST 250 Fuse T 5A	MST250-8585-5A000-THT-0T-SN-00
0034.6823	MST 250	Sub-miniature fuse links	T 6.3A / 250VAC	MST 250	MST 250 Fuse T 6.3A	MST250-8585-6A300-THT-0T-SN-00
0034.7125	MSTU 250	Sub-miniature fuse links	T 10A / 250VAC	MSTU 250	MSTU 250 Fuse T 10A	MSTU250-8585-10A00-THT-0T-SN-00
0034.7225	MSTU 250	Sub-miniature fuse links	T 10A / 250VAC	MSTU 250	MSTU 250 Fuse T 10A	MSTU250-8585-10A00-THT-0T-SN-00
0034.7325	MSTU 250	Sub-miniature fuse links	T 10A / 250VAC	MSTU 250	MSTU 250 Fuse T 10A	MSTU250-8585-10A00-THT-0T-SN-00
0034.7103	MSTU 250	Sub-miniature fuse links	T 63mA / 250V	MSTU 250	MSTU 250 Fuse T 63mA	MSTU250-8585-0A063-THT-0T-SN-00
0034.7104	MSTU 250	Sub-miniature fuse links	T 80mA / 250V	MSTU 250	MSTU 250 Fuse T 80m	MSTU250-8585-0A080-THT-0T-SN-00
0034.7105	MSTU 250	Sub-miniature fuse links	T 100mA / 250V	MSTU 250	MSTU 250 Fuse T 100mA	MSTU250-8585-0A100-THT-0T-SN-00
0034.7106	MSTU 250	Sub-miniature fuse links	T 125mA / 250V	MSTU 250	MSTU 250 Fuse T 125mA	MSTU250-8585-0A125-THT-0T-SN-00
0034.7107	MSTU 250	Sub-miniature fuse links	T 160mA / 250V	MSTU 250	MSTU 250 Fuse T 160mA	MSTU250-8585-0A160-THT-0T-SN-00
0034.7108	MSTU 250	Sub-miniature fuse links	T 200mA / 250V	MSTU 250	MSTU 250 Fuse T 200mA	MSTU250-8585-0A200-THT-0T-SN-00
0034.7110	MSTU 250	Sub-miniature fuse links	T 315mA / 250V	MSTU 250	MSTU 250 Fuse T 315mA	MSTU250-8585-0A315-THT-0T-SN-00
0034.7111	MSTU 250	Sub-miniature fuse links	T 400mA / 250V	MSTU 250	MSTU 250 Fuse T 400mA	MSTU250-8585-0A400-THT-0T-SN-00
0034.7112	MSTU 250	Sub-miniature fuse links	T 500mA / 250V	MSTU 250	MSTU 250 Fuse T 500mA	MSTU250-8585-0A500-THT-0T-SN-00
0034.7113	MSTU 250	Sub-miniature fuse links	T 630mA / 250V	MSTU 250	MSTU 250 Fuse T 630mA	MSTU250-8585-0A630-THT-0T-SN-00
0034.7114	MSTU 250	Sub-miniature fuse links	T 800mA / 250V	MSTU 250	MSTU 250 Fuse T 800mA	MSTU250-8585-0A800-THT-0T-SN-00
0034.7116	MSTU 250	Sub-miniature fuse links	T 1.25A / 250VAC	MSTU 250	MSTU 250 Fuse T 1.25A	MSTU250-8585-1A250-THT-0T-SN-00
0034.7118	MSTU 250	Sub-miniature fuse links	T 2A / 250VAC	MSTU 250	MSTU 250 Fuse T 2A	MSTU250-8585-2A000-THT-0T-SN-00
0034.7119	MSTU 250	Sub-miniature fuse links	T 2.5A / 250VAC	MSTU 250	MSTU 250 Fuse T 2.5A	MSTU250-8585-2A500-THT-0T-SN-00
0034.7121	MSTU 250	Sub-miniature fuse links	T 4A / 250VAC	MSTU 250	MSTU 250 Fuse T 4A	MSTU250-8585-4A000-THT-0T-SN-00
0034.7122	MSTU 250	Sub-miniature fuse links	T 5A / 250VAC	MSTU 250	MSTU 250 Fuse T 5A	MSTU250-8585-5A000-THT-0T-SN-00
0034.7203	MSTU 250	Sub-miniature fuse links	T 63mA / 250V	MSTU 250	MSTU 250 Fuse T 63mA	MSTU250-8585-0A063-THT-0T-SN-00
0034.7204	MSTU 250	Sub-miniature fuse links	T 80mA / 250V	MSTU 250	MSTU 250 Fuse T 80mA	MSTU250-8585-0A080-THT-0T-SN-00
0034.7205	MSTU 250	Sub-miniature fuse links	T 100mA / 250V	MSTU 250	MSTU 250 Fuse T 100mA	MSTU250-8585-0A100-THT-0T-SN-00
0034.7206	MSTU 250	Sub-miniature fuse links	T 125mA / 250V	MSTU 250	MSTU 250 Fuse T 125mA	MSTU250-8585-0A125-THT-0T-SN-00

0034.7207	MSTU 250	Sub-miniature fuse links	T 160mA / 250V	MSTU 250	MSTU 250 Fuse T 160mA	MSTU250-8585-0A160-THT-0T-SN-00
0034.7208	MSTU 250	Sub-miniature fuse links	T 200mA / 250V	MSTU 250	MSTU 250 Fuse T 200mA	MSTU250-8585-0A200-THT-0T-SN-00
0034.7210	MSTU 250	Sub-miniature fuse links	T 315mA / 250V	MSTU 250	MSTU 250 Fuse T 315mA	MSTU250-8585-0A315-THT-0T-SN-00
0034.7211	MSTU 250	Sub-miniature fuse links	T 400mA / 250V	MSTU 250	MSTU 250 Fuse T 400mA	MSTU250-8585-0A400-THT-0T-SN-00
0034.7212	MSTU 250	Sub-miniature fuse links	T 500mA / 250V	MSTU 250	MSTU 250 Fuse T 500mA	MSTU250-8585-0A500-THT-0T-SN-00
0034.7213	MSTU 250	Sub-miniature fuse links	T 630mA / 250V	MSTU 250	MSTU 250 Fuse T 630mA	MSTU250-8585-0A630-THT-0T-SN-00
0034.7214	MSTU 250	Sub-miniature fuse links	T 800mA / 250V	MSTU 250	MSTU 250 Fuse T 800mA	MSTU250-8585-0A800-THT-0T-SN-00
0034.7216	MSTU 250	Sub-miniature fuse links	T 1.25A / 250VAC	MSTU 250	MSTU 250 Fuse T 1.25A	MSTU250-8585-1A250-THT-0T-SN-00
0034.7218	MSTU 250	Sub-miniature fuse links	T 2A / 250VAC	MSTU 250	MSTU 250 Fuse T 2A	MSTU250-8585-2A000-THT-0T-SN-00
0034.7219	MSTU 250	Sub-miniature fuse links	T 2.5A / 250VAC	MSTU 250	MSTU 250 Fuse T 2.5A	MSTU250-8585-2A500-THT-0T-SN-00
0034.7221	MSTU 250	Sub-miniature fuse links	T 4A / 250VAC	MSTU 250	MSTU 250 Fuse T 4A	MSTU250-8585-4A000-THT-0T-SN-00
0034.7222	MSTU 250	Sub-miniature fuse links	T 5A / 250VAC	MSTU 250	MSTU 250 Fuse T 5A	MSTU250-8585-5A000-THT-0T-SN-00
0034.7303	MSTU 250	Sub-miniature fuse links	T 63mA / 250V	MSTU 250	MSTU 250 Fuse T 63mA	MSTU250-8585-0A063-THT-0T-SN-00
0034.7304	MSTU 250	Sub-miniature fuse links	T 80mA / 250V	MSTU 250	MSTU 250 Fuse T 80mA	MSTU250-8585-0A080-THT-0T-SN-00
0034.7305	MSTU 250	Sub-miniature fuse links	T 100mA / 250V	MSTU 250	MSTU 250 Fuse T 100mA	MSTU250-8585-0A100-THT-0T-SN-00
0034.7306	MSTU 250	Sub-miniature fuse links	T 125mA / 250V	MSTU 250	MSTU 250 Fuse T 125mA	MSTU250-8585-0A125-THT-0T-SN-00
0034.7307	MSTU 250	Sub-miniature fuse links	T 160mA / 250V	MSTU 250	MSTU 250 Fuse T 160mA	MSTU250-8585-0A160-THT-0T-SN-00
0034.7308	MSTU 250	Sub-miniature fuse links	T 200mA / 250V	MSTU 250	MSTU 250 Fuse T 200mA	MSTU250-8585-0A200-THT-0T-SN-00
0034.7310	MSTU 250	Sub-miniature fuse links	T 315mA / 250V	MSTU 250	MSTU 250 Fuse T 315mA	MSTU250-8585-0A315-THT-0T-SN-00
0034.7311	MSTU 250	Sub-miniature fuse links	T 400mA / 250V	MSTU 250	MSTU 250 Fuse T 400mA	MSTU250-8585-0A400-THT-0T-SN-00
0034.7312	MSTU 250	Sub-miniature fuse links	T 500mA / 250V	MSTU 250	MSTU 250 Fuse T 500mA	MSTU250-8585-0A500-THT-0T-SN-00
0034.7313	MSTU 250	Sub-miniature fuse links	T 630mA / 250V	MSTU 250	MSTU 250 Fuse T 630mA	MSTU250-8585-0A630-THT-0T-SN-00
0034.7314	MSTU 250	Sub-miniature fuse links	T 800mA / 250V	MSTU 250	MSTU 250 Fuse T 800mA	MSTU250-8585-0A800-THT-0T-SN-00
0034.7316	MSTU 250	Sub-miniature fuse links	T 1.25A / 250VAC	MSTU 250	MSTU 250 Fuse T 1.25A	MSTU250-8585-1A250-THT-0T-SN-00
0034.7318	MSTU 250	Sub-miniature fuse links	T 2A / 250VAC	MSTU 250	MSTU 250 Fuse T 2A	MSTU250-8585-2A000-THT-0T-SN-00
0034.7319	MSTU 250	Sub-miniature fuse links	T 2.5A / 250VAC	MSTU 250	MSTU 250 Fuse T 2.5A	MSTU250-8585-2A500-THT-0T-SN-00
0034.7321	MSTU 250	Sub-miniature fuse links	T 4A / 250VAC	MSTU 250	MSTU 250 Fuse T 4A	MSTU250-8585-4A000-THT-0T-SN-00
0034.7322	MSTU 250	Sub-miniature fuse links	T 5A / 250VAC	MSTU 250	MSTU 250 Fuse T 5A	MSTU250-8585-5A000-THT-0T-SN-00
0034.7109	MSTU 250	Sub-miniature fuse links	T 250mA / 250V	MSTU 250	MSTU 250 Fuse T 250mA	MSTU250-8585-0A250-THT-0T-SN-00
0034.7115	MSTU 250	Sub-miniature fuse links	T 1A / 250VAC	MSTU 250	MSTU 250 Fuse T 1A	MSTU250-8585-1A000-THT-0T-SN-00
0034.7117	MSTU 250	Sub-miniature fuse links	T 1.6A / 250VAC	MSTU 250	MSTU 250 Fuse T 1.6A	MSTU250-8585-1A600-THT-0T-SN-00
0034.7120	MSTU 250	Sub-miniature fuse links	T 3.15A / 250VAC	MSTU 250	MSTU 250 Fuse T 3.15A	MSTU250-8585-3A150-THT-0T-SN-00
0034.7123	MSTU 250	Sub-miniature fuse links	T 6.3A / 250VAC	MSTU 250	MSTU 250 Fuse T 6.3A	MSTU250-8585-6A300-THT-0T-SN-00
0034.7209	MSTU 250	Sub-miniature fuse links	T 250mA / 250V	MSTU 250	MSTU 250 Fuse T 250mA	MSTU250-8585-0A250-THT-0T-SN-00
0034.7215	MSTU 250	Sub-miniature fuse links	T 1A / 250VAC	MSTU 250	MSTU 250 Fuse T 1A	MSTU250-8585-1A000-THT-0T-SN-00
0034.7217	MSTU 250	Sub-miniature fuse links	T 1.6A / 250VAC	MSTU 250	MSTU 250 Fuse T 1.6A	MSTU250-8585-1A600-THT-0T-SN-00
0034.7220	MSTU 250	Sub-miniature fuse links	T 3.15A / 250VAC	MSTU 250	MSTU 250 Fuse T 3.15A	MSTU250-8585-3A150-THT-0T-SN-00
0034.7223	MSTU 250	Sub-miniature fuse links	T 6.3A / 250VAC	MSTU 250	MSTU 250 Fuse T 6.3A	MSTU250-8585-6A300-THT-0T-SN-00
0034.7309	MSTU 250	Sub-miniature fuse links	T 250mA / 250V	MSTU 250	MSTU 250 Fuse T 250mA	MSTU250-8585-0A250-THT-0T-SN-00
0034.7315	MSTU 250	Sub-miniature fuse links	T 1A / 250VAC	MSTU 250	MSTU 250 Fuse T 1A	MSTU250-8585-1A000-THT-0T-SN-00
0034.7317	MSTU 250	Sub-miniature fuse links	T 1.6A / 250VAC	MSTU 250	MSTU 250 Fuse T 1.6A	MSTU250-8585-1A600-THT-0T-SN-00
0034.7320	MSTU 250	Sub-miniature fuse links	T 3.15A / 250VAC	MSTU 250	MSTU 250 Fuse T 3.15A	MSTU250-8585-3A150-THT-0T-SN-00
0034.7323	MSTU 250	Sub-miniature fuse links	T 6.3A / 250VAC	MSTU 250	MSTU 250 Fuse T 6.3A	MSTU250-8585-6A300-THT-0T-SN-00
0034.7124	MSTU 250	Sub-miniature fuse links	T 8A / 250VAC	MSTU 250	MSTU 250 Fuse T 8A	MSTU250-8585-8A000-THT-0T-SN-00
0034.7224	MSTU 250	Sub-miniature fuse links	T 8A / 250VAC	MSTU 250	MSTU 250 Fuse T 8A	MSTU250-8585-8A000-THT-0T-SN-00
0034.7324	MSTU 250	Sub-miniature fuse links	T 8A / 250VAC	MSTU 250	MSTU 250 Fuse T 8A	MSTU250-8585-8A000-THT-0T-SN-00
0034.7324.A	MSTU 250	Sub-miniature fuse links	T 8A / 250VAC	MSTU 250	MSTU 250 Fuse T 8A	MSTU250-8585-8A000-THT-0T-SN-00
0034.6924	MXT 250	Sub-miniature fuse-link	T 8A / 250VAC	MXT 250	MXT 250 Fuse T 8A	MXT250-8585-8A000-THT-0T-SN-00
0034.6925	MXT 250	Sub-miniature fuse-link	T 10A / 250VAC	MXT 250	MXT 250 Fuse T 10A	MXT250-8585-10A00-THT-0T-SN-00
0034.6954	MXT 250	Sub-miniature fuse-link	T 8A / 250VAC	MXT 250	MXT 250 Fuse T 8A	MXT250-8585-8A000-THT-0T-SN-00
0034.6955	MXT 250	Sub-miniature fuse-link	T 10A / 250VAC	MXT 250	MXT 250 Fuse T 10A	MXT250-8585-10A00-THT-0T-SN-00
0034.6984	MXT 250	Sub-miniature fuse-link	T 8A / 250VAC	MXT 250	MXT 250 Fuse T 8A	MXT250-8585-8A000-THT-0T-SN-00
0034.6984.A	MXT 250	Sub-miniature fuse-link	T 8A / 250VAC	MXT 250	MXT 250 Fuse T 8A	MXT250-8585-8A000-THT-0T-SN-00
0034.6985	MXT 250	Sub-miniature fuse-link	T 10A / 250VAC	MXT 250	MXT 250 Fuse T 10A	MXT250-8585-10A00-THT-0T-SN-00
0034.6914	MXT 250	Sub-miniature fuse-link	T 800mA / 250V	MXT 250	MXT 250 Fuse T 800mA	MXT250-8585-0A800-THT-0T-SN-00
0034.6915	MXT 250	Sub-miniature fuse-link	T 1A / 250VAC	MXT 250	MXT 250 Fuse T 1A	MXT250-8585-1A000-THT-0T-SN-00
0034.6916	MXT 250	Sub-miniature fuse-link	T 1.25A / 250VAC	MXT 250	MXT 250 Fuse T 1.25A	MXT250-8585-1A250-THT-0T-SN-00
0034.6917	MXT 250	Sub-miniature fuse-link	T 1.6A / 250VAC	MXT 250	MXT 250 Fuse T 1.6A	MXT250-8585-1A600-THT-0T-SN-00
0034.6918	MXT 250	Sub-miniature fuse-link	T 2A / 250VAC	MXT 250	MXT 250 Fuse T 2A	MXT250-8585-2A000-THT-0T-SN-00
0034.6919	MXT 250	Sub-miniature fuse-link	T 2.5A / 250VAC	MXT 250	MXT 250 Fuse T 2.5A	MXT250-8585-2A500-THT-0T-SN-00
0034.6920	MXT 250	Sub-miniature fuse-link	T 3.15A / 250VAC	MXT 250	MXT 250 Fuse T 3.15A	MXT250-8585-3A150-THT-0T-SN-00
0034.6921	MXT 250	Sub-miniature fuse-link	T 4A / 250VAC	MXT 250	MXT 250 Fuse T 4A	MXT250-8585-4A000-THT-0T-SN-00
0034.6921.1	MXT 250	Sub-miniature fuse-link	T 4A / 250VAC	MXT 250	MXT 250 Fuse T 4A	MXT250-8585-4A000-THT-0T-SN-00
0034.6922	MXT 250	Sub-miniature fuse-link	T 5A / 250VAC	MXT 250	MXT 250 Fuse T 5A	MXT250-8585-5A000-THT-0T-SN-00
0034.6923	MXT 250	Sub-miniature fuse-link	T 6.3A / 250VAC	MXT 250	MXT 250 Fuse T 6.3A	MXT250-8585-6A300-THT-0T-SN-00
0034.6944	MXT 250	Sub-miniature fuse-link	T 800mA / 250V	MXT 250	MXT 250 Fuse T 800mA	MXT250-8585-0A800-THT-0T-SN-00
0034.6945	MXT 250	Sub-miniature fuse-link	T 1A / 250VAC	MXT 250	MXT 250 Fuse T 1A	MXT250-8585-1A000-THT-0T-SN-00
0034.6946	MXT 250	Sub-miniature fuse-link	T 1.25A / 250VAC	MXT 250	MXT 250 Fuse T 1.25A	MXT250-8585-1A250-THT-0T-SN-00
0034.6947	MXT 250	Sub-miniature fuse-link	T 1.6A / 250VAC	MXT 250	MXT 250 Fuse T 1.6A	MXT250-8585-1A600-THT-0T-SN-00
0034.6948	MXT 250	Sub-miniature fuse-link	T 2A / 250VAC	MXT 250	MXT 250 Fuse T 2A	MXT250-8585-2A000-THT-0T-SN-00
0034.6949	MXT 250	Sub-miniature fuse-link	T 2.5A / 250VAC	MXT 250	MXT 250 Fuse T 2.5A	MXT250-8585-2A500-THT-0T-SN-00
0034.6950	MXT 250	Sub-miniature fuse-link	T 3.15A / 250VAC	MXT 250	MXT 250 Fuse T 3.15A	MXT250-8585-3A150-THT-0T-SN-00
0034.6951	MXT 250	Sub-miniature fuse-link	T 4A / 250VAC	MXT 250	MXT 250 Fuse T 4A	MXT250-8585-4A000-THT-0T-SN-00
0034.6952	MXT 250	Sub-miniature fuse-link	T 5A / 250VAC	MXT 250	MXT 250 Fuse T 5A	MXT250-8585-5A000-THT-0T-SN-00
0034.6953	MXT 250	Sub-miniature fuse-link	T 6.3A / 250VAC	MXT 250	MXT 250 Fuse T 6.3A	MXT250-8585-6A300-THT-0T-SN-00
0034.6974	MXT 250	Sub-miniature fuse-link	T 800mA / 250V	MXT 250	MXT 250 Fuse T 800mA	MXT250-8585-0A800-THT-0T-SN-00
0034.6975	MXT 250	Sub-miniature fuse-link	T 1A / 250VAC	MXT 250	MXT 250 Fuse T 1A	MXT250-8585-1A000-THT-0T-SN-00
0034.6976	MXT 250	Sub-miniature fuse-link	T 1.25A / 250VAC	MXT 250	MXT 250 Fuse T 1.25A	MXT250-8585-1A250-THT-0T-SN-00
0034.6977	MXT 250	Sub-miniature fuse-link	T 1.6A / 250VAC	MXT 250	MXT 250 Fuse T 1.6A	MXT250-8585-1A600-THT-0T-SN-00
0034.6978	MXT 250	Sub-miniature fuse-link	T 2A / 250VAC	MXT 250	MXT 250 Fuse T 2A	MXT250-8585-2A000-THT-0T-SN-00
0034.6979	MXT 250	Sub-miniature fuse-link	T 2.5A / 250VAC	MXT 250	MXT 250 Fuse T 2.5A	MXT250-8585-2A500-THT-0T-SN-00
0034.6980	MXT 250	Sub-miniature fuse-link	T 3.15A / 250VAC	MXT 250	MXT 250 Fuse T 3.15A	MXT250-8585-3A150-THT-0T-SN-00
0034.6981	MXT 250	Sub-miniature fuse-link	T 4A / 250VAC	MXT 250	MXT 250 Fuse T 4A	MXT250-8585-4A000-THT-0T-SN-00
0034.6982	MXT 250	Sub-miniature fuse-link	T 5A / 250VAC	MXT 250	MXT 250 Fuse T 5A	MXT250-8585-5A000-THT-0T-SN-00
0034.6983	MXT 250	Sub-miniature fuse-link	T 6.3A / 250VAC	MXT 250	MXT 250 Fuse T 6.3A	MXT250-8585-6A300-THT-0T-SN-00
3404.0008.24	OMF 125	Sub-miniature fuse-links	F 630mA 125VAC / DC	OMF 125	OMF 125 Fuse F 630mA	OMF125-7431-0A630-SMD-0F-SN-00
3404.0021.11	OMF 125	Sub-miniature fuse-links	F 10A 125VAC / DC	OMF 125	OMF 125 Fuse F 10A	OMF125-7431-10A00-SMD-0F-SN-00
3404.0049.24.S	OMF 125	Sub-miniature fuse-links	F 125mA 125VAC / DC	OMF 125	OMF 125 Fuse F 125mA	OMF125-7431-0A125-SMD-0F-SN-00
3404.0021.24	OMF 125	Sub-miniature fuse-links	F 10A 125VAC / DC	OMF 125	OMF 125 Fuse F 10A	OMF125-7431-10A00-SMD-0F-SN-00
3404.0009.11	OMF 125	Sub-miniature fuse-links	F 1A 125VAC / DC	OMF 125	OMF 125 Fuse F 1A	OMF125-7431-1A000-SMD-0F-SN-00
3404.0009.24	OMF 125	Sub-miniature fuse-links	F 1A 125VAC / DC	OMF 125	OMF 125 Fuse F 1A	OMF125-7431-1A000-SMD-0F-SN-00
3404.0003.11	OMF 125	Sub-miniature fuse-links	F 63mA 125VAC / DC	OMF 125	OMF 125 Fuse F 63mA	OMF125-7431-0A063-SMD-0F-SN-00
3404.0003.22	OMF 125	Sub-miniature fuse-links	F 63mA 125VAC / DC	OMF 125	OMF 125 Fuse F 63mA	OMF125-7431-0A063-SMD-0F-SN-00
3404.0003.24	OMF 125	Sub-miniature fuse-links	F 63mA 125VAC / DC	OMF 125	OMF 125 Fuse F 63mA	OMF125-7431-0A063-SMD-0F-SN-00
3404.0004.11	OMF 125	Sub-miniature fuse-links	F 100mA 125VAC / DC	OMF 125	OMF 125 Fuse F 100mA	OMF125-7431-0A100-SMD-0F-SN-00
3404.0004.22	OMF 125	Sub-miniature fuse-links	F 100mA 125VAC / DC	OMF 125	OMF 125 Fuse F 100mA	OMF125-7431-0A100-SMD-0F-SN-00
3404.0004.24	OMF 125	Sub-miniature fuse-links	F 100mA 125VAC / DC	OMF 125	OMF 125 Fuse F 100mA	OMF125-7431-0A100-SMD-0F-SN-00
3404.0005.11	OMF 125	Sub-miniature fuse-links	F 160mA 125VAC / DC	OMF 125	OMF 125 Fuse F 160mA	OMF125-7431-0A160-SMD-0F-SN-00
3404.0005.22	OMF 125	Sub-miniature fuse-links	F 160mA 125VAC / DC	OMF 125	OMF 125 Fuse F 160mA	OMF125-7431-0A160-SMD-0F-SN-00
3404.0005.24	OMF 125	Sub-miniature fuse-links	F 160mA 125VAC / DC	OMF 125	OMF 125 Fuse F 160mA	OMF125-7431-0A160-SMD-0F-SN-00
3404.0006.11	OMF 125	Sub-miniature fuse-links	F 250mA 125VAC / DC	OMF 125	OMF 125 Fuse F 250mA	OMF125-7431-0A250-SMD-0F-SN-00
3404.0006.22	OMF 125	Sub-miniature fuse-links	F 250mA 125VAC / DC	OMF 125	OMF 125 Fuse F 250mA	OMF125-7431-0A250-SMD-0F-SN-00
3404.0006.24	OMF 125	Sub-miniature fuse-links	F 250mA 125VAC / DC	OMF 125	OMF 125 Fuse F 250mA	OMF125-7431-0A250-SMD-0F-SN-00
3404.0007.11	OMF 125	Sub-miniature fuse-links	F 400mA 125VAC / DC	OMF 125	OMF 125 Fuse F 400mA	OMF125-7431-0A400-SMD-0F-SN-00
3404.0007.22	OMF 125	Sub-miniature fuse-links	F 400mA 125VAC / DC	OMF 125	OMF 125 Fuse F 400mA	OMF125-7431-0A400-SMD-0F-SN-00
3404.0007.24	OMF 125	Sub-miniature fuse-links	F 400mA 125VAC / DC	OMF 125	OMF 125 Fuse F 400mA	OMF125-7431-0A400-SMD-0F-SN-00
3404.0008.11	OMF 125	Sub-miniature fuse-links	F 630mA 125VAC / DC	OMF 125	OMF 125 Fuse F 630mA	OMF125-7431-0A630-SMD-0F-SN-00
3404.0008.22	OMF 125	Sub-miniature fuse-links	F 630mA 125VAC / DC	OMF 125	OMF 125 Fuse F 630mA	OMF125-7431-0A630-SMD-0F-SN-00
3404.0009.22	OMF 125	Sub-miniature fuse-links	F 1A 125VAC / DC	OMF 125	OMF 125 Fuse F 1A	OMF125-7431-1A000-SMD-0F-SN-00
3404.0010.11	OMF 125	Sub-miniature fuse-links	F 1.25A 125VAC / DC	OMF 125	OMF 125 Fuse F 1.25A	OMF125-7431-1A250-SMD-0F-SN-00
3404.0010.22	OMF 125	Sub-miniature fuse-links	F 1.25A 125VAC / DC	OMF 125	OMF 125 Fuse F 1.25A	OMF125-7431-1A250-SMD-0F-SN-00
3404.0010.24	OMF 125	Sub-miniature fuse-links	F 1.25A 125VAC / DC	OMF 125	OMF 125 Fuse F 1.25A	OMF125-7431-1A250-SMD-0F-SN-00
3404.0011.11	OMF 125	Sub-miniature fuse-links	F 1.6A 125VAC / DC	OMF 125	OMF 125 Fuse F 1.6A	OMF125-7431-1A600-SMD-0F-SN-00
3404.0011.22	OMF 125	Sub-miniature fuse-links	F 1.6A 125VAC / DC	OMF 125	OMF 125 Fuse F 1.6A	OMF125-7431-1A600-SMD-0F-SN-00
3404.0011.24	OMF 125	Sub-miniature fuse-links	F 1.6A 125VAC / DC	OMF 125	OMF 125 Fuse F 1.6A	OMF125-7431-1A600-SMD-0F-SN-00
3404.0012.11	OMF 125	Sub-miniature fuse-links	F 2A 125VAC / DC	OMF 125	OMF 125 Fuse F 2A	OMF125-7431-2A000-SMD-0F-SN-00
3404.0012.22	OMF 125	Sub-miniature fuse-links	F 2A 125VAC / DC	OMF 125	OMF 125 Fuse F 2A	OMF125-7431-2A000-SMD-0F-SN-00
3404.0012.24	OMF 125	Sub-miniature fuse-links	F 2A 125VAC / DC	OMF 125	OMF 125 Fuse F 2A	OMF125-7431-2A000-SMD-0F-SN-00

3404.0013.11	OMF 125	Sub-miniature fuse-links	F 2.5A 125VAC / DC	OMF 125	OMF 125 Fuse F 2.5A	OMF125-7431-2A500-SMD-0F-SN-00
3404.0013.22	OMF 125	Sub-miniature fuse-links	F 2.5A 125VAC / DC	OMF 125	OMF 125 Fuse F 2.5A	OMF125-7431-2A500-SMD-0F-SN-00
3404.0013.24	OMF 125	Sub-miniature fuse-links	F 2.5A 125VAC / DC	OMF 125	OMF 125 Fuse F 2.5A	OMF125-7431-2A500-SMD-0F-SN-00
3404.0014.11	OMF 125	Sub-miniature fuse-links	F 3A 125VAC / DC	OMF 125	OMF 125 Fuse F 3A	OMF125-7431-3A000-SMD-0F-SN-00
3404.0014.22	OMF 125	Sub-miniature fuse-links	F 3A 125VAC / DC	OMF 125	OMF 125 Fuse F 3A	OMF125-7431-3A000-SMD-0F-SN-00
3404.0014.24	OMF 125	Sub-miniature fuse-links	F 3A 125VAC / DC	OMF 125	OMF 125 Fuse F 3A	OMF125-7431-3A000-SMD-0F-SN-00
3404.0015.11	OMF 125	Sub-miniature fuse-links	F 3.5A 125VAC / DC	OMF 125	OMF 125 Fuse F 3.5A	OMF125-7431-3A500-SMD-0F-SN-00
3404.0015.22	OMF 125	Sub-miniature fuse-links	F 3.5A 125VAC / DC	OMF 125	OMF 125 Fuse F 3.5A	OMF125-7431-3A500-SMD-0F-SN-00
3404.0015.24	OMF 125	Sub-miniature fuse-links	F 3.5A 125VAC / DC	OMF 125	OMF 125 Fuse F 3.5A	OMF125-7431-3A500-SMD-0F-SN-00
3404.0016.11	OMF 125	Sub-miniature fuse-links	F 4A 125VAC / DC	OMF 125	OMF 125 Fuse F 4A	OMF125-7431-4A000-SMD-0F-SN-00
3404.0016.22	OMF 125	Sub-miniature fuse-links	F 4A 125VAC / DC	OMF 125	OMF 125 Fuse F 4A	OMF125-7431-4A000-SMD-0F-SN-00
3404.0016.24	OMF 125	Sub-miniature fuse-links	F 4A 125VAC / DC	OMF 125	OMF 125 Fuse F 4A	OMF125-7431-4A000-SMD-0F-SN-00
3404.0017.11	OMF 125	Sub-miniature fuse-links	F 5A 125VAC / DC	OMF 125	OMF 125 Fuse F 5A	OMF125-7431-5A000-SMD-0F-SN-00
3404.0017.22	OMF 125	Sub-miniature fuse-links	F 5A 125VAC / DC	OMF 125	OMF 125 Fuse F 5A	OMF125-7431-5A000-SMD-0F-SN-00
3404.0017.24	OMF 125	Sub-miniature fuse-links	F 5A 125VAC / DC	OMF 125	OMF 125 Fuse F 5A	OMF125-7431-5A000-SMD-0F-SN-00
3404.0018.11	OMF 125	Sub-miniature fuse-links	F 6.3A 125VAC / DC	OMF 125	OMF 125 Fuse F 6.3A	OMF125-7431-6A300-SMD-0F-SN-00
3404.0018.22	OMF 125	Sub-miniature fuse-links	F 6.3A 125VAC / DC	OMF 125	OMF 125 Fuse F 6.3A	OMF125-7431-6A300-SMD-0F-SN-00
3404.0018.24	OMF 125	Sub-miniature fuse-links	F 6.3A 125VAC / DC	OMF 125	OMF 125 Fuse F 6.3A	OMF125-7431-6A300-SMD-0F-SN-00
3404.0019.11	OMF 125	Sub-miniature fuse-links	F 7A 125VAC / DC	OMF 125	OMF 125 Fuse F 7A	OMF125-7431-7A000-SMD-0F-SN-00
3404.0019.22	OMF 125	Sub-miniature fuse-links	F 7A 125VAC / DC	OMF 125	OMF 125 Fuse F 7A	OMF125-7431-7A000-SMD-0F-SN-00
3404.0019.24	OMF 125	Sub-miniature fuse-links	F 7A 125VAC / DC	OMF 125	OMF 125 Fuse F 7A	OMF125-7431-7A000-SMD-0F-SN-00
3404.0020.11	OMF 125	Sub-miniature fuse-links	F 8A 125VAC / DC	OMF 125	OMF 125 Fuse F 8A	OMF125-7431-8A000-SMD-0F-SN-00
3404.0020.22	OMF 125	Sub-miniature fuse-links	F 8A 125VAC / DC	OMF 125	OMF 125 Fuse F 8A	OMF125-7431-8A000-SMD-0F-SN-00
3404.0020.24	OMF 125	Sub-miniature fuse-links	F 8A 125VAC / DC	OMF 125	OMF 125 Fuse F 8A	OMF125-7431-8A000-SMD-0F-SN-00
3404.0021.22	OMF 125	Sub-miniature fuse-links	F 10A 125VAC / DC	OMF 125	OMF 125 Fuse F 10A	OMF125-7431-10A00-SMD-0F-SN-00
3404.0043.11	OMF 125	Sub-miniature fuse-links	F 350mA 125VAC / DC	OMF 125	OMF 125 Fuse F 350mA	OMF125-7431-0A350-SMD-0F-SN-00
3404.0043.22	OMF 125	Sub-miniature fuse-links	F 350mA 125VAC / DC	OMF 125	OMF 125 Fuse F 350mA	OMF125-7431-0A350-SMD-0F-SN-00
3404.0043.24	OMF 125	Sub-miniature fuse-links	F 350mA 125VAC / DC	OMF 125	OMF 125 Fuse F 350mA	OMF125-7431-0A350-SMD-0F-SN-00
3404.0044.11	OMF 125	Sub-miniature fuse-links	F 375mA 125VAC / DC	OMF 125	OMF 125 Fuse F 375mA	OMF125-7431-0A375-SMD-0F-SN-00
3404.0044.22	OMF 125	Sub-miniature fuse-links	F 375mA 125VAC / DC	OMF 125	OMF 125 Fuse F 375mA	OMF125-7431-0A375-SMD-0F-SN-00
3404.0044.24	OMF 125	Sub-miniature fuse-links	F 375mA 125VAC / DC	OMF 125	OMF 125 Fuse F 375mA	OMF125-7431-0A375-SMD-0F-SN-00
3404.0045.11	OMF 125	Sub-miniature fuse-links	F 500mA 125VAC / DC	OMF 125	OMF 125 Fuse F 500mA	OMF125-7431-0A500-SMD-0F-SN-00
3404.0045.22	OMF 125	Sub-miniature fuse-links	F 500mA 125VAC / DC	OMF 125	OMF 125 Fuse F 500mA	OMF125-7431-0A500-SMD-0F-SN-00
3404.0045.24	OMF 125	Sub-miniature fuse-links	F 500mA 125VAC / DC	OMF 125	OMF 125 Fuse F 500mA	OMF125-7431-0A500-SMD-0F-SN-00
3404.0046.11	OMF 125	Sub-miniature fuse-links	F 750mA 125VAC / DC	OMF 125	OMF 125 Fuse F 750mA	OMF125-7431-0A750-SMD-0F-SN-00
3404.0046.22	OMF 125	Sub-miniature fuse-links	F 750mA 125VAC / DC	OMF 125	OMF 125 Fuse F 750mA	OMF125-7431-0A750-SMD-0F-SN-00
3404.0046.24	OMF 125	Sub-miniature fuse-links	F 750mA 125VAC / DC	OMF 125	OMF 125 Fuse F 750mA	OMF125-7431-0A750-SMD-0F-SN-00
3404.0047.11	OMF 125	Sub-miniature fuse-links	F 1.5A 125VAC / DC	OMF 125	OMF 125 Fuse F 1.5A	OMF125-7431-1A500-SMD-0F-SN-00
3404.0047.22	OMF 125	Sub-miniature fuse-links	F 1.5A 125VAC / DC	OMF 125	OMF 125 Fuse F 1.5A	OMF125-7431-1A500-SMD-0F-SN-00
3404.0047.24	OMF 125	Sub-miniature fuse-links	F 1.5A 125VAC / DC	OMF 125	OMF 125 Fuse F 1.5A	OMF125-7431-1A500-SMD-0F-SN-00
3404.0048.11	OMF 125	Sub-miniature fuse-links	F 3.15A 125VAC / DC	OMF 125	OMF 125 Fuse F 3.15A	OMF125-7431-3A150-SMD-0F-SN-00
3404.0048.22	OMF 125	Sub-miniature fuse-links	F 3.15A 125VAC / DC	OMF 125	OMF 125 Fuse F 3.15A	OMF125-7431-3A150-SMD-0F-SN-00
3404.0048.24	OMF 125	Sub-miniature fuse-links	F 3.15A 125VAC / DC	OMF 125	OMF 125 Fuse F 3.15A	OMF125-7431-3A150-SMD-0F-SN-00
3404.0049.11	OMF 125	Sub-miniature fuse-links	F 125mA 125VAC / DC	OMF 125	OMF 125 Fuse F 125mA	OMF125-7431-0A125-SMD-0F-SN-00
3404.0049.22	OMF 125	Sub-miniature fuse-links	F 125mA 125VAC / DC	OMF 125	OMF 125 Fuse F 125mA	OMF125-7431-0A125-SMD-0F-SN-00
3404.0049.24	OMF 125	Sub-miniature fuse-links	F 125mA 125VAC / DC	OMF 125	OMF 125 Fuse F 125mA	OMF125-7431-0A125-SMD-0F-SN-00
3403.0012.24	OMF 250	Sub -miniature fuse-link	F 400mA L 250VAC / DC	OMF 250	OMF 250 Fuse F 400mA L 250V AC	OMF250-1146-0A400-SMD-0F-SN-00
3403.0010.11	OMF 250	Sub -miniature fuse-link	F 250mA L 250VAC / DC	OMF 250	OMF 250 Fuse F 250mA	OMF250-1146-0A250-SMD-0F-SN-00
3403.0010.24	OMF 250	Sub -miniature fuse-link	F 250mA L 250VAC / DC	OMF 250	OMF 250 Fuse F 250mA	OMF250-1146-0A250-SMD-0F-SN-00
3403.0011.11	OMF 250	Sub -miniature fuse-link	F 315mA L 250VAC / DC	OMF 250	OMF 250 Fuse F 315mA	OMF250-1146-0A315-SMD-0F-SN-00
3403.0011.24	OMF 250	Sub -miniature fuse-link	F 315mA L 250VAC / DC	OMF 250	OMF 250 Fuse F 315mA	OMF250-1146-0A315-SMD-0F-SN-00
3403.0012.11	OMF 250	Sub -miniature fuse-link	F 400mA L 250VAC / DC	OMF 250	OMF 250 Fuse F 400mA L 250V AC	OMF250-1146-0A400-SMD-0F-SN-00
3403.0013.11	OMF 250	Sub -miniature fuse-link	F 500mA L 250VAC / DC	OMF 250	OMF 250 Fuse F 500mA L 250V AC	OMF250-1146-0A500-SMD-0F-SN-00
3403.0013.24	OMF 250	Sub -miniature fuse-link	F 500mA L 250VAC / DC	OMF 250	OMF 250 Fuse F 500mA L 250V AC	OMF250-1146-0A500-SMD-0F-SN-00
3403.0014.11	OMF 250	Sub -miniature fuse-link	F 630mA L 250VAC / DC	OMF 250	OMF 250 Fuse F 630mA L 250V AC	OMF250-1146-0A630-SMD-0F-SN-00
3403.0014.24	OMF 250	Sub -miniature fuse-link	F 630mA L 250VAC / DC	OMF 250	OMF 250 Fuse F 630mA L 250V AC	OMF250-1146-0A630-SMD-0F-SN-00
3403.0015.11	OMF 250	Sub -miniature fuse-link	F 800mA L 250VAC / DC	OMF 250	OMF 250 Fuse F 800mA L 250V AC	OMF250-1146-0A800-SMD-0F-SN-00
3403.0015.24	OMF 250	Sub -miniature fuse-link	F 800mA L 250VAC / DC	OMF 250	OMF 250 Fuse F 800mA L 250V AC	OMF250-1146-0A800-SMD-0F-SN-00
3403.0016.11	OMF 250	Sub -miniature fuse-link	F 1A L 250VAC / DC	OMF 250	OMF 250 Fuse F 1A L 250V AC	OMF250-1146-1A000-SMD-0F-SN-00
3403.0016.24	OMF 250	Sub -miniature fuse-link	F 1A L 250VAC / DC	OMF 250	OMF 250 Fuse F 1A L 250V AC	OMF250-1146-1A000-SMD-0F-SN-00
3403.0017.11	OMF 250	Sub -miniature fuse-link	F 1.25A L 250VAC / DC	OMF 250	OMF 250 Fuse F 1.25A L 250V AC	OMF250-1146-1A250-SMD-0F-SN-00
3403.0017.24	OMF 250	Sub -miniature fuse-link	F 1.25A L 250VAC / DC	OMF 250	OMF 250 Fuse F 1.25A L 250V AC	OMF250-1146-1A250-SMD-0F-SN-00
3403.0018.11	OMF 250	Sub -miniature fuse-link	F 1.6A L 250VAC / DC	OMF 250	OMF 250 Fuse F 1.6A L 250V AC	OMF250-1146-1A600-SMD-0F-SN-00
3403.0018.24	OMF 250	Sub -miniature fuse-link	F 1.6A L 250VAC / DC	OMF 250	OMF 250 Fuse F 1.6A L 250V AC	OMF250-1146-1A600-SMD-0F-SN-00
3403.0019.11	OMF 250	Sub -miniature fuse-link	F 2A L 250VAC / DC	OMF 250	OMF 250 Fuse F 2A L 250V AC	OMF250-1146-2A000-SMD-0F-SN-00
3403.0019.24	OMF 250	Sub -miniature fuse-link	F 2A L 250VAC / DC	OMF 250	OMF 250 Fuse F 2A L 250V AC	OMF250-1146-2A000-SMD-0F-SN-00
3403.0020.11	OMF 250	Sub -miniature fuse-link	F 2.5A L 250VAC / DC	OMF 250	OMF 250 Fuse F 2.5A L 250V AC	OMF250-1146-2A500-SMD-0F-SN-00
3403.0020.24	OMF 250	Sub -miniature fuse-link	F 2.5A L 250VAC / DC	OMF 250	OMF 250 Fuse F 2.5A L 250V AC	OMF250-1146-2A500-SMD-0F-SN-00
3403.0021.11	OMF 250	Sub -miniature fuse-link	F 3.15A L 250VAC / DC	OMF 250	OMF 250 Fuse F 3.15A L 250V AC	OMF250-1146-3A150-SMD-0F-SN-00
3403.0021.24	OMF 250	Sub -miniature fuse-link	F 3.15A L 250VAC / DC	OMF 250	OMF 250 Fuse F 3.15A L 250V AC	OMF250-1146-3A150-SMD-0F-SN-00
3403.0022.11	OMF 250	Sub -miniature fuse-link	F 4A L 250VAC / DC	OMF 250	OMF 250 Fuse F 4A L 250V AC	OMF250-1146-4A000-SMD-0F-SN-00
3403.0022.24	OMF 250	Sub -miniature fuse-link	F 4A L 250VAC / DC	OMF 250	OMF 250 Fuse F 4A L 250V AC	OMF250-1146-4A000-SMD-0F-SN-00
3402.0049.24	OMF 63	Sub-miniature fuse-links	F 125mA 63VAC / DC	OMF 63	OMF 63 Fuse F 125mA	OMF63-7431-0A125-SMD-0F-SN-00
3402.0049.11	OMF 63	Sub-miniature fuse-links	F 125mA 63VAC / DC	OMF 63	OMF 63 Fuse F 125mA	OMF63-7431-0A125-SMD-0F-SN-00
3402.0049.22	OMF 63	Sub-miniature fuse-links	F 125mA 63VAC / DC	OMF 63	OMF 63 Fuse F 125mA	OMF63-7431-0A125-SMD-0F-SN-00
3402.0003.11	OMF 63	Sub-miniature fuse-links	F 63mA 63VAC / DC	OMF 63	OMF 63 Fuse F 63mA	OMF63-7431-0A063-SMD-0F-SN-00
3402.0003.22	OMF 63	Sub-miniature fuse-links	F 63mA 63VAC / DC	OMF 63	OMF 63 Fuse F 63mA	OMF63-7431-0A063-SMD-0F-SN-00
3402.0003.24	OMF 63	Sub-miniature fuse-links	F 63mA 63VAC / DC	OMF 63	OMF 63 Fuse F 63mA	OMF63-7431-0A063-SMD-0F-SN-00
3402.0004.11	OMF 63	Sub-miniature fuse-links	F 100mA 63VAC / DC	OMF 63	OMF 63 Fuse F 100mA	OMF63-7431-0A100-SMD-0F-SN-00
3402.0004.22	OMF 63	Sub-miniature fuse-links	F 100mA 63VAC / DC	OMF 63	OMF 63 Fuse F 100mA	OMF63-7431-0A100-SMD-0F-SN-00
3402.0004.24	OMF 63	Sub-miniature fuse-links	F 100mA 63VAC / DC	OMF 63	OMF 63 Fuse F 100mA	OMF63-7431-0A100-SMD-0F-SN-00
3402.0005.11	OMF 63	Sub-miniature fuse-links	F 160mA 63VAC / DC	OMF 63	OMF 63 Fuse F 160mA	OMF63-7431-0A160-SMD-0F-SN-00
3402.0005.22	OMF 63	Sub-miniature fuse-links	F 160mA 63VAC / DC	OMF 63	OMF 63 Fuse F 160mA	OMF63-7431-0A160-SMD-0F-SN-00
3402.0005.24	OMF 63	Sub-miniature fuse-links	F 160mA 63VAC / DC	OMF 63	OMF 63 Fuse F 160mA	OMF63-7431-0A160-SMD-0F-SN-00
3402.0006.11	OMF 63	Sub-miniature fuse-links	F 250mA 63VAC / DC	OMF 63	OMF 63 Fuse F 250mA	OMF63-7431-0A250-SMD-0F-SN-00
3402.0006.22	OMF 63	Sub-miniature fuse-links	F 250mA 63VAC / DC	OMF 63	OMF 63 Fuse F 250mA	OMF63-7431-0A250-SMD-0F-SN-00
3402.0006.24	OMF 63	Sub-miniature fuse-links	F 250mA 63VAC / DC	OMF 63	OMF 63 Fuse F 250mA	OMF63-7431-0A250-SMD-0F-SN-00
3402.0007.11	OMF 63	Sub-miniature fuse-links	F 400mA 63VAC / DC	OMF 63	OMF 63 Fuse F 400mA	OMF63-7431-0A400-SMD-0F-SN-00
3402.0007.22	OMF 63	Sub-miniature fuse-links	F 400mA 63VAC / DC	OMF 63	OMF 63 Fuse F 400mA	OMF63-7431-0A400-SMD-0F-SN-00
3402.0007.24	OMF 63	Sub-miniature fuse-links	F 400mA 63VAC / DC	OMF 63	OMF 63 Fuse F 400mA	OMF63-7431-0A400-SMD-0F-SN-00
3402.0008.11	OMF 63	Sub-miniature fuse-links	F 630mA 63VAC / DC	OMF 63	OMF 63 Fuse F 630mA	OMF63-7431-0A630-SMD-0F-SN-00
3402.0008.22	OMF 63	Sub-miniature fuse-links	F 630mA 63VAC / DC	OMF 63	OMF 63 Fuse F 630mA	OMF63-7431-0A630-SMD-0F-SN-00
3402.0008.24	OMF 63	Sub-miniature fuse-links	F 630mA 63VAC / DC	OMF 63	OMF 63 Fuse F 630mA	OMF63-7431-0A630-SMD-0F-SN-00
3402.0009.11	OMF 63	Sub-miniature fuse-links	F 1A 63VAC / DC	OMF 63	OMF 63 Fuse F 1A	OMF63-7431-1A000-SMD-0F-SN-00
3402.0009.22	OMF 63	Sub-miniature fuse-links	F 1A 63VAC / DC	OMF 63	OMF 63 Fuse F 1A	OMF63-7431-1A000-SMD-0F-SN-00
3402.0009.24	OMF 63	Sub-miniature fuse-links	F 1A 63VAC / DC	OMF 63	OMF 63 Fuse F 1A	OMF63-7431-1A000-SMD-0F-SN-00
3402.0010.11	OMF 63	Sub-miniature fuse-links	F 1.25A 63VAC / DC	OMF 63	OMF 63 Fuse F 1.25A	OMF63-7431-1A250-SMD-0F-SN-00
3402.0010.22	OMF 63	Sub-miniature fuse-links	F 1.25A 63VAC / DC	OMF 63	OMF 63 Fuse F 1.25A	OMF63-7431-1A250-SMD-0F-SN-00
3402.0010.24	OMF 63	Sub-miniature fuse-links	F 1.25A 63VAC / DC	OMF 63	OMF 63 Fuse F 1.25A	OMF63-7431-1A250-SMD-0F-SN-00
3402.0011.11	OMF 63	Sub-miniature fuse-links	F 1.6A 63VAC / DC	OMF 63	OMF 63 Fuse F 1.6A	OMF63-7431-1A600-SMD-0F-SN-00
3402.0011.22	OMF 63	Sub-miniature fuse-links	F 1.6A 63VAC / DC	OMF 63	OMF 63 Fuse F 1.6A	OMF63-7431-1A600-SMD-0F-SN-00
3402.0011.24	OMF 63	Sub-miniature fuse-links	F 1.6A 63VAC / DC	OMF 63	OMF 63 Fuse F 1.6A	OMF63-7431-1A600-SMD-0F-SN-00
3402.0012.11	OMF 63	Sub-miniature fuse-links	F 2A 63VAC / DC	OMF 63	OMF 63 Fuse F 2A	OMF63-7431-2A000-SMD-0F-SN-00
3402.0012.22	OMF 63	Sub-miniature fuse-links	F 2A 63VAC / DC	OMF 63	OMF 63 Fuse F 2A	OMF63-7431-2A000-SMD-0F-SN-00
3402.0012.24	OMF 63	Sub-miniature fuse-links	F 2A 63VAC / DC	OMF 63	OMF 63 Fuse F 2A	OMF63-7431-2A000-SMD-0F-SN-00
3402.0013.11	OMF 63	Sub-miniature fuse-links	F 2.5A 63VAC / DC	OMF 63	OMF 63 Fuse F 2.5A	OMF63-7431-2A500-SMD-0F-SN-00
3402.0013.22	OMF 63	Sub-miniature fuse-links	F 2.5A 63VAC / DC	OMF 63	OMF 63 Fuse F 2.5A	OMF63-7431-2A500-SMD-0F-SN-00
3402.0013.24	OMF 63	Sub-miniature fuse-links	F 2.5A 63VAC / DC	OMF 63	OMF 63 Fuse F 2.5A	OMF63-7431-2A500-SMD-0F-SN-00
3402.0014.11	OMF 63	Sub-miniature fuse-links	F 3A 63VAC / DC	OMF 63	OMF 63 Fuse F 3A	OMF63-7431-3A000-SMD-0F-SN-00
3402.0014.22	OMF 63	Sub-miniature fuse-links	F 3A 63VAC / DC	OMF 63	OMF 63 Fuse F 3A	OMF63-7431-3A000-SMD-0F-SN-00
3402.0014.24	OMF 63	Sub-miniature fuse-links	F 3A 63VAC / DC	OMF 63	OMF 63 Fuse F 3A	OMF63-7431-3A000-SMD-0F-SN-00
3402.0015.11	OMF 63	Sub-miniature fuse-links	F 3.5A 63VAC / DC	OMF 63	OMF 63 Fuse F 3.5A	OMF63-7431-3A500-SMD-0F-SN-00
3402.0015.22	OMF 63	Sub-miniature fuse-links	F 3.5A 63VAC / DC	OMF 63	OMF 63 Fuse F 3.5A	OMF63-7431-3A500-SMD-0F-SN-00
3402.0015.24	OMF 63	Sub-miniature fuse-links	F 3.5A 63VAC / DC	OMF 63	OMF 63 Fuse F 3.5A	OMF63-7431-3A500-SMD-0F-SN-00
3402.0016.11	OMF 63	Sub-miniature fuse-links	F 4A 63VAC / DC	OMF 63	OMF 63 Fuse F 4A	OMF63-7431-4A000-SMD-0F-SN-00
3402.0016.22	OMF 63	Sub-miniature fuse-links	F 4A 63VAC / DC	OMF 63	OMF 63 Fuse F 4A	OMF63-7431-4A000-SMD-0F-SN-00
3402.0016.24	OMF 63	Sub-miniature fuse-links	F 4A 63VAC / DC	OMF 63	OMF 63 Fuse F 4A	OMF63-7431-4A000-SMD-0F-SN-00
3402.0017.11	OMF 63	Sub-miniature fuse-links	F 5A 63VAC / DC	OMF 63	OMF 63 Fuse F 5A	OMF63-7431-5A000-SMD-0F-SN-00

3402.0017.22	OMF 63	Sub-miniature fuse-links	F 5A 63VAC / DC	OMF 63	OMF 63 Fuse F 5A	OMF63-7431-5A000-SMD-0F-SN-00
3402.0017.24	OMF 63	Sub-miniature fuse-links	F 5A 63VAC / DC	OMF 63	OMF 63 Fuse F 5A	OMF63-7431-5A000-SMD-0F-SN-00
3402.0018.11	OMF 63	Sub-miniature fuse-links	F 6.3A 63VAC / DC	OMF 63	OMF 63 Fuse F 6.3A	OMF63-7431-6A300-SMD-0F-SN-00
3402.0018.22	OMF 63	Sub-miniature fuse-links	F 6.3A 63VAC / DC	OMF 63	OMF 63 Fuse F 6.3A	OMF63-7431-6A300-SMD-0F-SN-00
3402.0018.24	OMF 63	Sub-miniature fuse-links	F 6.3A 63VAC / DC	OMF 63	OMF 63 Fuse F 6.3A	OMF63-7431-6A300-SMD-0F-SN-00
3402.0019.11	OMF 63	Sub-miniature fuse-links	F 7A 63VAC / DC	OMF 63	OMF 63 Fuse F 7A	OMF63-7431-7A000-SMD-0F-SN-00
3402.0019.22	OMF 63	Sub-miniature fuse-links	F 7A 63VAC / DC	OMF 63	OMF 63 Fuse F 7A	OMF63-7431-7A000-SMD-0F-SN-00
3402.0019.24	OMF 63	Sub-miniature fuse-links	F 7A 63VAC / DC	OMF 63	OMF 63 Fuse F 7A	OMF63-7431-7A000-SMD-0F-SN-00
3402.0020.11	OMF 63	Sub-miniature fuse-links	F 8A 63VAC / DC	OMF 63	OMF 63 Fuse F 8A	OMF63-7431-8A000-SMD-0F-SN-00
3402.0020.22	OMF 63	Sub-miniature fuse-links	F 8A 63VAC / DC	OMF 63	OMF 63 Fuse F 8A	OMF63-7431-8A000-SMD-0F-SN-00
3402.0020.24	OMF 63	Sub-miniature fuse-links	F 8A 63VAC / DC	OMF 63	OMF 63 Fuse F 8A	OMF63-7431-8A000-SMD-0F-SN-00
3402.0040.11	OMF 63	Sub-miniature fuse-links	F 10A 63VAC / DC	OMF 63	OMF 63 Fuse F 10A	OMF63-7431-10A00-SMD-0F-SN-00
3402.0040.22	OMF 63	Sub-miniature fuse-links	F 10A 63VAC / DC	OMF 63	OMF 63 Fuse F 10A	OMF63-7431-10A00-SMD-0F-SN-00
3402.0040.24	OMF 63	Sub-miniature fuse-links	F 10A 63VAC / DC	OMF 63	OMF 63 Fuse F 10A	OMF63-7431-10A00-SMD-0F-SN-00
3402.0043.11	OMF 63	Sub-miniature fuse-links	F 350mA 63VAC / DC	OMF 63	OMF 63 Fuse F 350mA	OMF63-7431-0A350-SMD-0F-SN-00
3402.0043.22	OMF 63	Sub-miniature fuse-links	F 350mA 63VAC / DC	OMF 63	OMF 63 Fuse F 350mA	OMF63-7431-0A350-SMD-0F-SN-00
3402.0043.24	OMF 63	Sub-miniature fuse-links	F 350mA 63VAC / DC	OMF 63	OMF 63 Fuse F 350mA	OMF63-7431-0A350-SMD-0F-SN-00
3402.0044.11	OMF 63	Sub-miniature fuse-links	F 375mA 63VAC / DC	OMF 63	OMF 63 Fuse F 375mA	OMF63-7431-0A375-SMD-0F-SN-00
3402.0044.22	OMF 63	Sub-miniature fuse-links	F 375mA 63VAC / DC	OMF 63	OMF 63 Fuse F 375mA	OMF63-7431-0A375-SMD-0F-SN-00
3402.0044.24	OMF 63	Sub-miniature fuse-links	F 375mA 63VAC / DC	OMF 63	OMF 63 Fuse F 375mA	OMF63-7431-0A375-SMD-0F-SN-00
3402.0045.11	OMF 63	Sub-miniature fuse-links	F 500mA 63VAC / DC	OMF 63	OMF 63 Fuse F 500mA	OMF63-7431-0A500-SMD-0F-SN-00
3402.0045.22	OMF 63	Sub-miniature fuse-links	F 500mA 63VAC / DC	OMF 63	OMF 63 Fuse F 500mA	OMF63-7431-0A500-SMD-0F-SN-00
3402.0045.24	OMF 63	Sub-miniature fuse-links	F 500mA 63VAC / DC	OMF 63	OMF 63 Fuse F 500mA	OMF63-7431-0A500-SMD-0F-SN-00
3402.0046.11	OMF 63	Sub-miniature fuse-links	F 750mA 63VAC / DC	OMF 63	OMF 63 Fuse F 750mA	OMF63-7431-0A750-SMD-0F-SN-00
3402.0046.22	OMF 63	Sub-miniature fuse-links	F 750mA 63VAC / DC	OMF 63	OMF 63 Fuse F 750mA	OMF63-7431-0A750-SMD-0F-SN-00
3402.0046.24	OMF 63	Sub-miniature fuse-links	F 750mA 63VAC / DC	OMF 63	OMF 63 Fuse F 750mA	OMF63-7431-0A750-SMD-0F-SN-00
3402.0047.11	OMF 63	Sub-miniature fuse-links	F 1.5A 63VAC / DC	OMF 63	OMF 63 Fuse F 1.5A	OMF63-7431-1A500-SMD-0F-SN-00
3402.0047.22	OMF 63	Sub-miniature fuse-links	F 1.5A 63VAC / DC	OMF 63	OMF 63 Fuse F 1.5A	OMF63-7431-1A500-SMD-0F-SN-00
3402.0047.24	OMF 63	Sub-miniature fuse-links	F 1.5A 63VAC / DC	OMF 63	OMF 63 Fuse F 1.5A	OMF63-7431-1A500-SMD-0F-SN-00
3402.0048.11	OMF 63	Sub-miniature fuse-links	F 3.15A 63VAC / DC	OMF 63	OMF 63 Fuse F 3.15A	OMF63-7431-3A150-SMD-0F-SN-00
3402.0048.22	OMF 63	Sub-miniature fuse-links	F 3.15A 63VAC / DC	OMF 63	OMF 63 Fuse F 3.15A	OMF63-7431-3A150-SMD-0F-SN-00
3402.0048.24	OMF 63	Sub-miniature fuse-links	F 3.15A 63VAC / DC	OMF 63	OMF 63 Fuse F 3.15A	OMF63-7431-3A150-SMD-0F-SN-00
3404.2303.11	OMK 125	Fuseholder with fuse-links	F 63 mA 125 V	OMK 125	OMK 125 F. in Holder F 63mA	OMK125-1252-0A063-FHD-0F-SN-00
3404.2303.22	OMK 125	Fuseholder with fuse-links	F 63 mA 125 V	OMK 125	OMK 125 F. in Holder F 63mA	OMK125-1252-0A063-FHD-0F-SN-00
3404.2303.23	OMK 125	Fuseholder with fuse-links	F 63 mA 125 V	OMK 125	OMK 125 F. in Holder F 63mA	OMK125-1252-0A063-FHD-0F-SN-00
3404.2304.11	OMK 125	Fuseholder with fuse-links	F100 mA 125 V	OMK 125	OMK 125 F. in Holder F 100mA	OMK125-1252-0A100-FHD-0F-SN-00
3404.2304.22	OMK 125	Fuseholder with fuse-links	F 100 mA 125 V	OMK 125	OMK 125 F. in Holder F 100mA	OMK125-1252-0A100-FHD-0F-SN-00
3404.2304.23	OMK 125	Fuseholder with fuse-links	F 100 mA 125 V	OMK 125	OMK 125 F. in Holder F 100mA	OMK125-1252-0A100-FHD-0F-SN-00
3404.2305.11	OMK 125	Fuseholder with fuse-links	F160 mA 125 V	OMK 125	OMK 125 F. in Holder F 160mA	OMK125-1252-0A160-FHD-0F-SN-00
3404.2305.22	OMK 125	Fuseholder with fuse-links	F160 mA 125 V	OMK 125	OMK 125 F. in Holder F 160mA	OMK125-1252-0A160-FHD-0F-SN-00
3404.2305.23	OMK 125	Fuseholder with fuse-links	F 160 mA 125 V	OMK 125	OMK 125 F. in Holder F 160mA	OMK125-1252-0A160-FHD-0F-SN-00
3404.2306.11	OMK 125	Fuseholder with fuse-links	F 250 mA 125 V	OMK 125	OMK 125 F. in Holder F 250mA	OMK125-1252-0A250-FHD-0F-SN-00
3404.2306.22	OMK 125	Fuseholder with fuse-links	F 250 mA 125 V	OMK 125	OMK 125 F. in Holder F 250mA	OMK125-1252-0A250-FHD-0F-SN-00
3404.2306.23	OMK 125	Fuseholder with fuse-links	F 250 mA 125 V	OMK 125	OMK 125 F. in Holder F 250mA	OMK125-1252-0A250-FHD-0F-SN-00
3404.2307.11	OMK 125	Fuseholder with fuse-links	F 400 mA 125 V	OMK 125	OMK 125 F. in Holder F 400mA	OMK125-1252-0A400-FHD-0F-SN-00
3404.2307.22	OMK 125	Fuseholder with fuse-links	F 400 mA 125 V	OMK 125	OMK 125 F. in Holder F 400mA	OMK125-1252-0A400-FHD-0F-SN-00
3404.2307.23	OMK 125	Fuseholder with fuse-links	F 400 mA 125 V	OMK 125	OMK 125 F. in Holder F 400mA	OMK125-1252-0A400-FHD-0F-SN-00
3404.2308.11	OMK 125	Fuseholder with fuse-links	F 630 mA 125 V	OMK 125	OMK 125 F. in Holder F 630mA	OMK125-1252-0A630-FHD-0F-SN-00
3404.2308.22	OMK 125	Fuseholder with fuse-links	F 630 mA 125 V	OMK 125	OMK 125 F. in Holder F 630mA	OMK125-1252-0A630-FHD-0F-SN-00
3404.2308.23	OMK 125	Fuseholder with fuse-links	F 630 mA 125 V	OMK 125	OMK 125 F. in Holder F 630mA	OMK125-1252-0A630-FHD-0F-SN-00
3404.2309.11	OMK 125	Fuseholder with fuse-links	F 1A 125 V	OMK 125	OMK 125 F. in Holder F 1A	OMK125-1252-1A000-FHD-0F-SN-00
3404.2309.22	OMK 125	Fuseholder with fuse-links	F 1A 125 V	OMK 125	OMK 125 F. in Holder F 1A	OMK125-1252-1A000-FHD-0F-SN-00
3404.2309.23	OMK 125	Fuseholder with fuse-links	F 1A 125 V	OMK 125	OMK 125 F. in Holder F 1A	OMK125-1252-1A000-FHD-0F-SN-00
3404.2310.11	OMK 125	Fuseholder with fuse-links	F 1.25A 125 V	OMK 125	OMK 125 F. in Holder F 1.25A	OMK125-1252-1A250-FHD-0F-SN-00
3404.2310.22	OMK 125	Fuseholder with fuse-links	F 1.25A 125 V	OMK 125	OMK 125 F. in Holder F 1.25A	OMK125-1252-1A250-FHD-0F-SN-00
3404.2310.23	OMK 125	Fuseholder with fuse-links	F 1.25A 125 V	OMK 125	OMK 125 F. in Holder F 1.25A	OMK125-1252-1A250-FHD-0F-SN-00
3404.2311.11	OMK 125	Fuseholder with fuse-links	F 1.6 A 125 V	OMK 125	OMK 125 F. in Holder F 1.6A	OMK125-1252-1A600-FHD-0F-SN-00
3404.2311.22	OMK 125	Fuseholder with fuse-links	F 1.6 A 125 V	OMK 125	OMK 125 F. in Holder F 1.6A	OMK125-1252-1A600-FHD-0F-SN-00
3404.2311.23	OMK 125	Fuseholder with fuse-links	F 1.6 A 125 V	OMK 125	OMK 125 F. in Holder F 1.6A	OMK125-1252-1A600-FHD-0F-SN-00
3404.2312.11	OMK 125	Fuseholder with fuse-links	F 2A 125 V	OMK 125	OMK 125 F. in Holder F 2A	OMK125-1252-2A000-FHD-0F-SN-00
3404.2312.22	OMK 125	Fuseholder with fuse-links	F 2A 125 V	OMK 125	OMK 125 F. in Holder F 2A	OMK125-1252-2A000-FHD-0F-SN-00
3404.2312.23	OMK 125	Fuseholder with fuse-links	F 2A 125 V	OMK 125	OMK 125 F. in Holder F 2A	OMK125-1252-2A000-FHD-0F-SN-00
3404.2313.11	OMK 125	Fuseholder with fuse-links	F 2.5 A 125 V	OMK 125	OMK 125 F. in Holder F 2.5A	OMK125-1252-2A500-FHD-0F-SN-00
3404.2313.22	OMK 125	Fuseholder with fuse-links	F 2.5 A 125 V	OMK 125	OMK 125 F. in Holder F 2.5A	OMK125-1252-2A500-FHD-0F-SN-00
3404.2313.23	OMK 125	Fuseholder with fuse-links	F 2.5 A 125 V	OMK 125	OMK 125 F. in Holder F 2.5A	OMK125-1252-2A500-FHD-0F-SN-00
3404.2314.11	OMK 125	Fuseholder with fuse-links	F 3 A 125 V	OMK 125	OMK 125 F. in Holder F 3A	OMK125-1252-3A000-FHD-0F-SN-00
3404.2314.22	OMK 125	Fuseholder with fuse-links	F 3 A 125 V	OMK 125	OMK 125 F. in Holder F 3A	OMK125-1252-3A000-FHD-0F-SN-00
3404.2314.23	OMK 125	Fuseholder with fuse-links	F 3 A 125 V	OMK 125	OMK 125 F. in Holder F 3A	OMK125-1252-3A000-FHD-0F-SN-00
3404.2315.11	OMK 125	Fuseholder with fuse-links	F 3.5 A 125 V	OMK 125	OMK 125 F. in Holder F 3.5A	OMK125-1252-3A500-FHD-0F-SN-00
3404.2315.22	OMK 125	Fuseholder with fuse-links	F 3.5 A 125 V	OMK 125	OMK 125 F. in Holder F 3.5A	OMK125-1252-3A500-FHD-0F-SN-00
3404.2315.23	OMK 125	Fuseholder with fuse-links	F 3.5 A 125 V	OMK 125	OMK 125 F. in Holder F 3.5A	OMK125-1252-3A500-FHD-0F-SN-00
3404.2316.11	OMK 125	Fuseholder with fuse-links	F 4 A 125 V	OMK 125	OMK 125 F. in Holder F 4A	OMK125-1252-4A000-FHD-0F-SN-00
3404.2316.22	OMK 125	Fuseholder with fuse-links	F 4 A 125 V	OMK 125	OMK 125 F. in Holder F 4A	OMK125-1252-4A000-FHD-0F-SN-00
3404.2316.23	OMK 125	Fuseholder with fuse-links	F 4 A 125 V	OMK 125	OMK 125 F. in Holder F 4A	OMK125-1252-4A000-FHD-0F-SN-00
3404.2317.11	OMK 125	Fuseholder with fuse-links	F 5 A 125 V	OMK 125	OMK 125 F. in Holder F 5A	OMK125-1252-5A000-FHD-0F-SN-00
3404.2317.22	OMK 125	Fuseholder with fuse-links	F 5 A 125 V	OMK 125	OMK 125 F. in Holder F 5A	OMK125-1252-5A000-FHD-0F-SN-00
3404.2317.23	OMK 125	Fuseholder with fuse-links	F 5 A 125 V	OMK 125	OMK 125 F. in Holder F 5A	OMK125-1252-5A000-FHD-0F-SN-00
3404.2343.11	OMK 125	Fuseholder with fuse-links	F 350 mA 125 V	OMK 125	OMK 125 F. in Holder F 350mA	OMK125-1252-0A350-FHD-0F-SN-00
3404.2343.22	OMK 125	Fuseholder with fuse-links	F 350 mA 125 V	OMK 125	OMK 125 F. in Holder F 350mA	OMK125-1252-0A350-FHD-0F-SN-00
3404.2343.23	OMK 125	Fuseholder with fuse-links	F 350 mA 125 V	OMK 125	OMK 125 F. in Holder F 350mA	OMK125-1252-0A350-FHD-0F-SN-00
3404.2344.11	OMK 125	Fuseholder with fuse-links	F 375 mA 125 V	OMK 125	OMK 125 F. in Holder F 375mA	OMK125-1252-0A375-FHD-0F-SN-00
3404.2344.22	OMK 125	Fuseholder with fuse-links	F 375 mA 125 V	OMK 125	OMK 125 F. in Holder F 375mA	OMK125-1252-0A375-FHD-0F-SN-00
3404.2344.23	OMK 125	Fuseholder with fuse-links	F 375 mA 125 V	OMK 125	OMK 125 F. in Holder F 375mA	OMK125-1252-0A375-FHD-0F-SN-00
3404.2345.11	OMK 125	Fuseholder with fuse-links	F 500 mA 125 V	OMK 125	OMK 125 F. in Holder F 500mA	OMK125-1252-0A500-FHD-0F-SN-00
3404.2345.22	OMK 125	Fuseholder with fuse-links	F 500 mA 125 V	OMK 125	OMK 125 F. in Holder F 500mA	OMK125-1252-0A500-FHD-0F-SN-00
3404.2345.23	OMK 125	Fuseholder with fuse-links	F 500 mA 125 V	OMK 125	OMK 125 F. in Holder F 500mA	OMK125-1252-0A500-FHD-0F-SN-00
3404.2346.11	OMK 125	Fuseholder with fuse-links	F 750 mA 125 V	OMK 125	OMK 125 F. in Holder F 750mA	OMK125-1252-0A750-FHD-0F-SN-00
3404.2346.22	OMK 125	Fuseholder with fuse-links	F 750 mA 125 V	OMK 125	OMK 125 F. in Holder F 750mA	OMK125-1252-0A750-FHD-0F-SN-00
3404.2346.23	OMK 125	Fuseholder with fuse-links	F 750 mA 125 V	OMK 125	OMK 125 F. in Holder F 750mA	OMK125-1252-0A750-FHD-0F-SN-00
3404.2347.11	OMK 125	Fuseholder with fuse-links	F 1.5 A 125 V	OMK 125	OMK 125 F. in Holder F 1.5A	OMK125-1252-1A500-FHD-0F-SN-00
3404.2347.22	OMK 125	Fuseholder with fuse-links	F 1.5 A 125 V	OMK 125	OMK 125 F. in Holder F 1.5A	OMK125-1252-1A500-FHD-0F-SN-00
3404.2347.23	OMK 125	Fuseholder with fuse-links	F 1.5 A 125 V	OMK 125	OMK 125 F. in Holder F 1.5A	OMK125-1252-1A500-FHD-0F-SN-00
3404.2348.11	OMK 125	Fuseholder with fuse-links	F 3.15A 125 V	OMK 125	OMK 125 F. in Holder F 3.15A	OMK125-1252-3A150-FHD-0F-SN-00
3404.2348.22	OMK 125	Fuseholder with fuse-links	F 3.15A 125 V	OMK 125	OMK 125 F. in Holder F 3.15A	OMK125-1252-3A150-FHD-0F-SN-00
3404.2348.23	OMK 125	Fuseholder with fuse-links	F 3.15A 125 V	OMK 125	OMK 125 F. in Holder F 3.15A	OMK125-1252-3A150-FHD-0F-SN-00
3404.2349.11	OMK 125	Fuseholder with fuse-links	F 125 mA 125 V	OMK 125	OMK 125 F. in Holder F 125mA	OMK125-1252-0A125-FHD-0F-SN-00
3404.2349.22	OMK 125	Fuseholder with fuse-links	F 125 mA 125 V	OMK 125	OMK 125 F. in Holder F 125mA	OMK125-1252-0A125-FHD-0F-SN-00
3404.2349.23	OMK 125	Fuseholder with fuse-links	F 125 mA 125 V	OMK 125	OMK 125 F. in Holder F 125mA	OMK125-1252-0A125-FHD-0F-SN-00
3422.0046.22	OMK 63	Fuseholder with fuse-links	F 750 mA 63V	OMK 63	OMK 63 F. in Holder F 750mA	OMK63-1252-0A750-FHD-0F-SN-00
3422.0049.23	OMK 63	Fuseholder with fuse-links	F 125 mA 63V	OMK 63	OMK 63 F. in Holder F 125mA	OMK63-1252-0A125-FHD-0F-SN-00
3422.0049.11	OMK 63	Fuseholder with fuse-links	F 125 mA 63V	OMK 63	OMK 63 F. in Holder F 125mA	OMK63-1252-0A125-FHD-0F-SN-00
3422.0003.11	OMK 63	Fuseholder with fuse-links	F 63 mA 63V	OMK 63	OMK 63 F. in Holder F 63mA	OMK63-1252-0A063-FHD-0F-SN-00
3422.0003.23	OMK 63	Fuseholder with fuse-links	F 63 mA 63V	OMK 63	OMK 63 F. in Holder F 63mA	OMK63-1252-0A063-FHD-0F-SN-00
3422.0004.11	OMK 63	Fuseholder with fuse-links	F 100 mA 63V	OMK 63	OMK 63 F. in Holder F 100mA	OMK63-1252-0A100-FHD-0F-SN-00
3422.0004.23	OMK 63	Fuseholder with fuse-links	F 100 mA 63V	OMK 63	OMK 63 F. in Holder F 100mA	OMK63-1252-0A100-FHD-0F-SN-00
3422.0005.11	OMK 63	Fuseholder with fuse-links	F 160 mA 63V	OMK 63	OMK 63 F. in Holder F 160mA	OMK63-1252-0A160-FHD-0F-SN-00
3422.0005.23	OMK 63	Fuseholder with fuse-links	F 160 mA 63V	OMK 63	OMK 63 F. in Holder F 160mA	OMK63-1252-0A160-FHD-0F-SN-00
3422.0006.11	OMK 63	Fuseholder with fuse-links	F 250 mA 63V	OMK 63	OMK 63 F. in Holder F 250mA	OMK63-1252-0A250-FHD-0F-SN-00
3422.0006.23	OMK 63	Fuseholder with fuse-links	F 250 mA 63V	OMK 63	OMK 63 F. in Holder F 250mA	OMK63-1252-0A250-FHD-0F-SN-00
3422.0007.11	OMK 63	Fuseholder with fuse-links	F 400mA 63V	OMK 63	OMK 63 F. in Holder F 400mA	OMK63-1252-0A400-FHD-0F-SN-00
3422.0007.23	OMK 63	Fuseholder with fuse-links	F 400mA 63V	OMK 63	OMK 63 F. in Holder F 400mA	OMK63-1252-0A400-FHD-0F-SN-00
3422.0008.11	OMK 63	Fuseholder with fuse-links	F 630 mA 63V	OMK 63	OMK 63 F. in Holder F 630mA	OMK63-1252-0A630-FHD-0F-SN-00
3422.0008.23	OMK 63	Fuseholder with fuse-links	F 630 mA 63V	OMK 63	OMK 63 F. in Holder F 630mA	OMK63-1252-0A630-FHD-0F-SN-00
3422.0009.11	OMK 63	Fuseholder with fuse-links	F 1A 63V	OMK 63	OMK 63 F. in Holder F 1A	OMK63-1252-1A000-FHD-0F-SN-00
3422.0009.23	OMK 63	Fuseholder with fuse-links	F 1A 63V	OMK 63	OMK 63 F. in Holder F 1A	OMK63-1252-1A000-FHD-0F-SN-00
3422.0010.11	OMK 63	Fuseholder with fuse-links	F 1.25 A 63V	OMK 63	OMK 63 F. in Holder F 1.25A	OMK63-1252-1A250-FHD-0F-SN-00
3422.0010.23	OMK 63	Fuseholder with fuse-links	F 1.25 A 63V	OMK 63	OMK 63 F. in Holder F 1.25A	OMK63-1252-1A250-FHD-0F-SN-00
3422.0011.11	OMK 63	Fuseholder with fuse-links	F 1.6 A 63V	OMK 63	OMK 63 F. in Holder F 1.6A	OMK63-1252-1A600-FHD-0F-SN-00

3422.0011.23	OMK 63	Fuseholder with fuse-links	F 1.6 A 63V	OMK 63	OMK 63 F. in Holder F 1.6A	OMK63-1252-1A600-FHD-0F-SN-00
3422.0012.11	OMK 63	Fuseholder with fuse-links	F 2A 63V	OMK 63	OMK 63 F. in Holder F 2A	OMK63-1252-2A000-FHD-0F-SN-00
3422.0012.23	OMK 63	Fuseholder with fuse-links	F 2A 63V	OMK 63	OMK 63 F. in Holder F 2A	OMK63-1252-2A000-FHD-0F-SN-00
3422.0013.11	OMK 63	Fuseholder with fuse-links	F 2.5 A 63V	OMK 63	OMK 63 F. in Holder F 2.5A	OMK63-1252-2A500-FHD-0F-SN-00
3422.0013.23	OMK 63	Fuseholder with fuse-links	F 2.5 A 63V	OMK 63	OMK 63 F. in Holder F 2.5A	OMK63-1252-2A500-FHD-0F-SN-00
3422.0014.11	OMK 63	Fuseholder with fuse-links	F 3 A 63V	OMK 63	OMK 63 F. in Holder F 3A	OMK63-1252-3A000-FHD-0F-SN-00
3422.0014.23	OMK 63	Fuseholder with fuse-links	F 3 A 63V	OMK 63	OMK 63 F. in Holder F 3A	OMK63-1252-3A000-FHD-0F-SN-00
3422.0015.11	OMK 63	Fuseholder with fuse-links	F 3.5 A 63V	OMK 63	OMK 63 F. in Holder F 3.5A	OMK63-1252-3A500-FHD-0F-SN-00
3422.0015.23	OMK 63	Fuseholder with fuse-links	F 3.5 A 63V	OMK 63	OMK 63 F. in Holder F 3.5A	OMK63-1252-3A500-FHD-0F-SN-00
3422.0016.11	OMK 63	Fuseholder with fuse-links	F 4 A 63V	OMK 63	OMK 63 F. in Holder F 4A	OMK63-1252-4A000-FHD-0F-SN-00
3422.0016.23	OMK 63	Fuseholder with fuse-links	F 4 A 63V	OMK 63	OMK 63 F. in Holder F 4A	OMK63-1252-4A000-FHD-0F-SN-00
3422.0017.11	OMK 63	Fuseholder with fuse-links	F 5 A 63V	OMK 63	OMK 63 F. in Holder F 5A	OMK63-1252-5A000-FHD-0F-SN-00
3422.0017.23	OMK 63	Fuseholder with fuse-links	F 5 A 63V	OMK 63	OMK 63 F. in Holder F 5A	OMK63-1252-5A000-FHD-0F-SN-00
3422.0043.11	OMK 63	Fuseholder with fuse-links	F 350 mA 63V	OMK 63	OMK 63 F. in Holder F 50mA	OMK63-1252-0A050-FHD-0F-SN-00
3422.0043.23	OMK 63	Fuseholder with fuse-links	F 350 mA 63V	OMK 63	OMK 63 F. in Holder F 350mA	OMK63-1252-0A350-FHD-0F-SN-00
3422.0044.11	OMK 63	Fuseholder with fuse-links	F 375 mA 63V	OMK 63	OMK 63 F. in Holder F 375mA	OMK63-1252-0A375-FHD-0F-SN-00
3422.0044.23	OMK 63	Fuseholder with fuse-links	F 375 mA 63V	OMK 63	OMK 63 F. in Holder F 375mA	OMK63-1252-0A375-FHD-0F-SN-00
3422.0045.11	OMK 63	Fuseholder with fuse-links	F 500 mA 63V	OMK 63	OMK 63 F. in Holder F 500mA	OMK63-1252-0A500-FHD-0F-SN-00
3422.0045.23	OMK 63	Fuseholder with fuse-links	F 500 mA 63V	OMK 63	OMK 63 F. in Holder F 500mA	OMK63-1252-0A500-FHD-0F-SN-00
3422.0046.11	OMK 63	Fuseholder with fuse-links	F 750 mA 63V	OMK 63	OMK 63 F. in Holder F 750mA	OMK63-1252-0A750-FHD-0F-SN-00
3422.0046.23	OMK 63	Fuseholder with fuse-links	F 750 mA 63V	OMK 63	OMK 63 F. in Holder F 750mA	OMK63-1252-0A750-FHD-0F-SN-00
3422.0047.11	OMK 63	Fuseholder with fuse-links	F 1.5A 63V	OMK 63	OMK 63 F. in Holder F 1.5A	OMK63-1252-1A500-FHD-0F-SN-00
3422.0047.23	OMK 63	Fuseholder with fuse-links	F 1.5A 63V	OMK 63	OMK 63 F. in Holder F 1.5A	OMK63-1252-1A500-FHD-0F-SN-00
3422.0048.11	OMK 63	Fuseholder with fuse-links	F 3.15A 63V	OMK 63	OMK 63 F. in Holder F 3.15A	OMK63-1252-3A150-FHD-0F-SN-00
3422.0048.23	OMK 63	Fuseholder with fuse-links	F 3.15A 63V	OMK 63	OMK 63 F. in Holder F 3.15A	OMK63-1252-3A150-FHD-0F-SN-00
3403.0116.11	OMT	Sub-miniature fuse-links	T 1A L 250VAC	OMT	OMT Fuse T 1A	OMT-1146-1A000-SMD-0T-SN-00
3403.0116.24	OMT	Sub-miniature fuse-links	T 1A L 250VAC	OMT	OMT Fuse T 1A	OMT-1146-1A000-SMD-0T-SN-00
3403.0117.11	OMT	Sub-miniature fuse-links	T 1.25A L 250VAC	OMT	OMT Fuse T 1.25A	OMT-1146-1A250-SMD-0T-SN-00
3403.0117.24	OMT	Sub-miniature fuse-links	T 1.25A L 250VAC	OMT	OMT Fuse T 1.25A	OMT-1146-1A250-SMD-0T-SN-00
3403.0119.11	OMT	Sub-miniature fuse-links	T 2A L AC250V / DC125V	OMT	OMT Fuse T 2A	OMT-1146-2A000-SMD-0T-SN-00
3403.0119.24	OMT	Sub-miniature fuse-links	T 2A L 250VAC	OMT	OMT Fuse T 2A	OMT-1146-2A000-SMD-0T-SN-00
3403.0120.11	OMT	Sub-miniature fuse-links	T 2.5A L 125VAC	OMT	OMT Fuse T 2.5A	OMT-1146-2A500-SMD-0T-SN-00
3403.0120.24	OMT	Sub-miniature fuse-links	T 2.5A L 125VAC	OMT	OMT Fuse T 2.5A	OMT-1146-2A500-SMD-0T-SN-00
3403.0122.11	OMT	Sub-miniature fuse-links	T 4A L 125VAC	OMT	OMT Fuse T 4A	OMT-1146-4A000-SMD-0T-SN-00
3403.0122.24	OMT	Sub-miniature fuse-links	T 4A L 125VAC	OMT	OMT Fuse T 4A	OMT-1146-4A000-SMD-0T-SN-00
3403.0129.11	OMT	Sub-miniature fuse-links	T 750mA L 250VAC	OMT	OMT Fuse T 750mA	OMT-1146-0A750-SMD-0T-SN-00
3403.0129.24	OMT	Sub-miniature fuse-links	T 750mA L 250VAC	OMT	OMT Fuse T 750mA	OMT-1146-0A750-SMD-0T-SN-00
3403.0130.11	OMT	Sub-miniature fuse-links	T 1.5A L 250VAC	OMT	OMT Fuse T 1.5A	OMT-1146-1A500-SMD-0T-SN-00
3403.0130.24	OMT	Sub-miniature fuse-links	T 1.5A L 250VAC	OMT	OMT Fuse T 1.5A	OMT-1146-1A500-SMD-0T-SN-00
3403.0131.11	OMT	Sub-miniature fuse-links	T 3A L 125VAC	OMT	OMT Fuse T 3A	OMT-1146-3A000-SMD-0T-SN-00
3403.0131.24	OMT	Sub-miniature fuse-links	T 3A L 125VAC	OMT	OMT Fuse T 3A	OMT-1146-3A000-SMD-0T-SN-00
3403.0132.11	OMT	Sub-miniature fuse-links	T 3.5A L 125VAC	OMT	OMT Fuse T 3.5A	OMT-1146-3A500-SMD-0T-SN-00
3403.0132.24	OMT	Sub-miniature fuse-links	T 3.5A L 125VAC	OMT	OMT Fuse T 3.5A	OMT-1146-3A500-SMD-0T-SN-00
3403.0123.11	OMT	Sub-miniature fuse-links	T 5A L 125VAC	OMT	OMT Fuse T 5A	OMT-1146-5A000-SMD-0T-SN-00
3403.0123.24	OMT	Sub-miniature fuse-links	T 5A L 125VAC	OMT	OMT Fuse T 5A	OMT-1146-5A000-SMD-0T-SN-00
3404.0112.22	OMT 125	Sub-miniature fuse links	T 500mA 125V	OMT 125	OMT 125 Fuse T 500mA	OMT125-7431-0A500-SMD-0T-SN-00
3404.0101.22	OMT 125	Sub-miniature fuse links	T 1.6A 125V	OMT 125	OMT 125 Fuse T 1.6A	OMT125-7431-1A600-SMD-0T-SN-00
3404.0115.22	OMT 125	Sub-miniature fuse links	T 1.5A 125V	OMT 125	OMT 125 Fuse T 1.5A	OMT125-7431-1A500-SMD-0T-SN-00
3404.0101.11	OMT 125	Sub-miniature fuse links	T 1.6A 125V	OMT 125	OMT 125 Fuse T 1.6A	OMT125-7431-1A600-SMD-0T-SN-00
3404.0101.24	OMT 125	Sub-miniature fuse links	T 1.6A 125V	OMT 125	OMT 125 Fuse T 1.6A	OMT125-7431-1A600-SMD-0T-SN-00
3404.0110.11	OMT 125	Sub-miniature fuse links	T 250mA 125V	OMT 125	OMT 125 Fuse T 250mA	OMT125-7431-0A250-SMD-0T-SN-00
3404.0110.22	OMT 125	Sub-miniature fuse links	T 250mA 125V	OMT 125	OMT 125 Fuse T 250mA	OMT125-7431-0A250-SMD-0T-SN-00
3404.0110.24	OMT 125	Sub-miniature fuse links	T 250mA 125V	OMT 125	OMT 125 Fuse T 250mA	OMT125-7431-0A250-SMD-0T-SN-00
3404.0111.11	OMT 125	Sub-miniature fuse links	T 375mA 125V	OMT 125	OMT 125 Fuse T 375mA	OMT125-7431-0A375-SMD-0T-SN-00
3404.0111.22	OMT 125	Sub-miniature fuse links	T 375mA 125V	OMT 125	OMT 125 Fuse T 375mA	OMT125-7431-0A375-SMD-0T-SN-00
3404.0111.24	OMT 125	Sub-miniature fuse links	T 375mA 125V	OMT 125	OMT 125 Fuse T 375mA	OMT125-7431-0A375-SMD-0T-SN-00
3404.0112.24	OMT 125	Sub-miniature fuse links	T 500mA 125V	OMT 125	OMT 125 Fuse T 500mA	OMT125-7431-0A500-SMD-0T-SN-00
3404.0113.11	OMT 125	Sub-miniature fuse links	T 750mA 125V	OMT 125	OMT 125 Fuse T 750mA	OMT125-7431-0A750-SMD-0T-SN-00
3404.0113.22	OMT 125	Sub-miniature fuse links	T 750mA 125V	OMT 125	OMT 125 Fuse T 750mA	OMT125-7431-0A750-SMD-0T-SN-00
3404.0113.24	OMT 125	Sub-miniature fuse links	T 750mA 125V	OMT 125	OMT 125 Fuse T 750mA	OMT125-7431-0A750-SMD-0T-SN-00
3404.0114.24	OMT 125	Sub-miniature fuse links	T 1A 125V	OMT 125	OMT 125 Fuse T 1A	OMT125-7431-1A000-SMD-0T-SN-00
3404.0115.11	OMT 125	Sub-miniature fuse links	T 1.5A 125V	OMT 125	OMT 125 Fuse T 1.5A	OMT125-7431-1A500-SMD-0T-SN-00
3404.0115.24	OMT 125	Sub-miniature fuse links	T 1.5A 125V	OMT 125	OMT 125 Fuse T 1.5A	OMT125-7431-1A500-SMD-0T-SN-00
3404.0116.11	OMT 125	Sub-miniature fuse links	T 2A 125V	OMT 125	OMT 125 Fuse T 2A	OMT125-7431-2A000-SMD-0T-SN-00
3404.0116.22	OMT 125	Sub-miniature fuse links	T 2A 125V	OMT 125	OMT 125 Fuse T 2A	OMT125-7431-2A000-SMD-0T-SN-00
3404.0116.24	OMT 125	Sub-miniature fuse links	T 2A 125V	OMT 125	OMT 125 Fuse T 2A	OMT125-7431-2A000-SMD-0T-SN-00
3404.0117.11	OMT 125	Sub-miniature fuse links	T 2.5A 125V	OMT 125	OMT 125 Fuse T 2.5A	OMT125-7431-2A500-SMD-0T-SN-00
3404.0117.22	OMT 125	Sub-miniature fuse links	T 2.5A 125V	OMT 125	OMT 125 Fuse T 2.5A	OMT125-7431-2A500-SMD-0T-SN-00
3404.0117.24	OMT 125	Sub-miniature fuse links	T 2.5A 125V	OMT 125	OMT 125 Fuse T 2.5A	OMT125-7431-2A500-SMD-0T-SN-00
3404.0118.11	OMT 125	Sub-miniature fuse links	T 3A 125V	OMT 125	OMT 125 Fuse T 3A	OMT125-7431-3A000-SMD-0T-SN-00
3404.0118.22	OMT 125	Sub-miniature fuse links	T 3A 125V	OMT 125	OMT 125 Fuse T 3A	OMT125-7431-3A000-SMD-0T-SN-00
3404.0118.24	OMT 125	Sub-miniature fuse links	T 3A 125V	OMT 125	OMT 125 Fuse T 3A	OMT125-7431-3A000-SMD-0T-SN-00
3404.0119.22	OMT 125	Sub-miniature fuse links	T 3.5A 125V	OMT 125	OMT 125 Fuse T 3.5A	OMT125-7431-3A500-SMD-0T-SN-00
3404.0119.24	OMT 125	Sub-miniature fuse links	T 3.5A 125V	OMT 125	OMT 125 Fuse T 3.5A	OMT125-7431-3A500-SMD-0T-SN-00
3404.0120.11	OMT 125	Sub-miniature fuse links	T 4A 125V	OMT 125	OMT 125 Fuse T 4A	OMT125-7431-4A000-SMD-0T-SN-00
3404.0120.22	OMT 125	Sub-miniature fuse links	T 4A 125V	OMT 125	OMT 125 Fuse T 4A	OMT125-7431-4A000-SMD-0T-SN-00
3404.0120.24	OMT 125	Sub-miniature fuse links	T 4A 125V	OMT 125	OMT 125 Fuse T 4A	OMT125-7431-4A000-SMD-0T-SN-00
3404.0121.11	OMT 125	Sub-miniature fuse links	T 5A 125V	OMT 125	OMT 125 Fuse T 5A	OMT125-7431-5A000-SMD-0T-SN-00
3404.0121.22	OMT 125	Sub-miniature fuse links	T 5A 125V	OMT 125	OMT 125 Fuse T 5A	OMT125-7431-5A000-SMD-0T-SN-00
3404.0121.24	OMT 125	Sub-miniature fuse links	T 5A 125V	OMT 125	OMT 125 Fuse T 5A	OMT125-7431-5A000-SMD-0T-SN-00
3404.0122.11	OMT 125	Sub-miniature fuse links	T 6.3A 125V	OMT 125	OMT 125 Fuse T 6.3A	OMT125-7431-6A300-SMD-0T-SN-00
3404.0122.22	OMT 125	Sub-miniature fuse links	T 6.3A 125V	OMT 125	OMT 125 Fuse T 6.3A	OMT125-7431-6A300-SMD-0T-SN-00
3404.0122.24	OMT 125	Sub-miniature fuse links	T 6.3A 125V	OMT 125	OMT 125 Fuse T 6.3A	OMT125-7431-6A300-SMD-0T-SN-00
3404.0173.11	OMT 125	Sub-miniature fuse links	T 160mA 125V	OMT 125	OMT 125 Fuse T 160mA	OMT125-7431-0A160-SMD-0T-SN-00
3404.0173.22	OMT 125	Sub-miniature fuse links	T 160mA 125V	OMT 125	OMT 125 Fuse T 160mA	OMT125-7431-0A160-SMD-0T-SN-00
3404.0173.24	OMT 125	Sub-miniature fuse links	T 160mA 125V	OMT 125	OMT 125 Fuse T 160mA	OMT125-7431-0A160-SMD-0T-SN-00
3404.0112.11	OMT 125	Sub-miniature fuse links	T 500mA 125V	OMT 125	OMT 125 Fuse T 500mA	OMT125-7431-0A500-SMD-0T-SN-00
3404.0114.11	OMT 125	Sub-miniature fuse links	T 1A 125V	OMT 125	OMT 125 Fuse T 1A	OMT125-7431-1A000-SMD-0T-SN-00
3404.0114.22	OMT 125	Sub-miniature fuse links	T 1A 125V	OMT 125	OMT 125 Fuse T 1A	OMT125-7431-1A000-SMD-0T-SN-00
3404.0119.11	OMT 125	Sub-miniature fuse links	T 3.5A 125V	OMT 125	OMT 125 Fuse T 3.5A	OMT125-7431-3A500-SMD-0T-SN-00
3404.0100.11	OMT 125	Sub-miniature fuse links	T 950mA 125V	OMT 125	OMT 125 Fuse T 950mA	OMT125-7431-0A950-SMD-0T-SN-00
3404.0100.22	OMT 125	Sub-miniature fuse links	T 950mA 125V	OMT 125	OMT 125 Fuse T 950mA	OMT125-7431-0A950-SMD-0T-SN-00
3404.0100.24	OMT 125	Sub-miniature fuse links	T 950mA 125V	OMT 125	OMT 125 Fuse T 950mA	OMT125-7431-0A950-SMD-0T-SN-00
3404.2325.22	OMZ 125 SICHERUNG 1.5A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 1.5A	OMZ125-1252-1A500-FHD-0T-SN-00
3404.2325.11	OMZ 125 SICHERUNG 1.5A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 1.5A	OMZ125-1252-1A500-FHD-0T-SN-00
3404.2325.23	OMZ 125 SICHERUNG 1.5A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 1.5A	OMZ125-1252-1A500-FHD-0T-SN-00
3404.2324.11	OMZ 125 SICHERUNG 1A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 1A	OMZ125-1252-1A000-FHD-0T-SN-00
3404.2324.22	OMZ 125 SICHERUNG 1A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 1A	OMZ125-1252-1A000-FHD-0T-SN-00
3404.2324.23	OMZ 125 SICHERUNG 1A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 1A	OMZ125-1252-1A000-FHD-0T-SN-00
3404.2327.11	OMZ 125 SICHERUNG 2.5A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 2.5A	OMZ125-1252-2A500-FHD-0T-SN-00
3404.2327.22	OMZ 125 SICHERUNG 2.5A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 2.5A	OMZ125-1252-2A500-FHD-0T-SN-00
3404.2327.23	OMZ 125 SICHERUNG 2.5A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 2.5A	OMZ125-1252-2A500-FHD-0T-SN-00
3404.2320.11	OMZ 125 SICHERUNG 250mA T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 250mA	OMZ125-1252-0A250-FHD-0T-SN-00
3404.2320.22	OMZ 125 SICHERUNG 250mA T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 250mA	OMZ125-1252-0A250-FHD-0T-SN-00
3404.2320.23	OMZ 125 SICHERUNG 250mA T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 250mA	OMZ125-1252-0A250-FHD-0T-SN-00
3404.2326.11	OMZ 125 SICHERUNG 2A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 2A	OMZ125-1252-2A000-FHD-0T-SN-00
3404.2326.22	OMZ 125 SICHERUNG 2A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 2A	OMZ125-1252-2A000-FHD-0T-SN-00
3404.2326.23	OMZ 125 SICHERUNG 2A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 2A	OMZ125-1252-2A000-FHD-0T-SN-00
3404.2329.11	OMZ 125 SICHERUNG 3.5A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 3.5A	OMZ125-1252-3A500-FHD-0T-SN-00
3404.2329.22	OMZ 125 SICHERUNG 3.5A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 3.5A	OMZ125-1252-3A500-FHD-0T-SN-00
3404.2329.23	OMZ 125 SICHERUNG 3.5A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 3.5A	OMZ125-1252-3A500-FHD-0T-SN-00
3404.2321.11	OMZ 125 SICHERUNG 375mA T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 375mA	OMZ125-1252-0A375-FHD-0T-SN-00
3404.2321.22	OMZ 125 SICHERUNG 375mA T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 375mA	OMZ125-1252-0A375-FHD-0T-SN-00
3404.2321.23	OMZ 125 SICHERUNG 375mA T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 375mA	OMZ125-1252-0A375-FHD-0T-SN-00
3404.2328.22	OMZ 125 SICHERUNG 3A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 3A	OMZ125-1252-3A000-FHD-0T-SN-00
3404.2328.23	OMZ 125 SICHERUNG 3A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 3A	OMZ125-1252-3A000-FHD-0T-SN-00
3404.2328.11	OMZ 125 SICHERUNG 3A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 3A	OMZ125-1252-3A000-FHD-0T-SN-00
3404.2330.11	OMZ 125 SICHERUNG 4A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 4A	OMZ125-1252-4A000-FHD-0T-SN-00

3404.2330.22	OMZ 125 SICHERUNG 4A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 4A	OMZ125-1252-4A000-FHD-0T-SN-00
3404.2330.23	OMZ 125 SICHERUNG 4A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 4A	OMZ125-1252-4A000-FHD-0T-SN-00
3404.2322.22	OMZ 125 SICHERUNG 500mA T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 500mA	OMZ125-1252-0A500-FHD-0T-SN-00
3404.2322.11	OMZ 125 SICHERUNG 500mA T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 500mA	OMZ125-1252-0A500-FHD-0T-SN-00
3404.2322.23	OMZ 125 SICHERUNG 500mA T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 500mA	OMZ125-1252-0A500-FHD-0T-SN-00
3404.2331.22	OMZ 125 SICHERUNG 5A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 5A	OMZ125-1252-5A000-FHD-0T-SN-00
3404.2331.11	OMZ 125 SICHERUNG 5A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 5A	OMZ125-1252-5A000-FHD-0T-SN-00
3404.2331.23	OMZ 125 SICHERUNG 5A T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 5A	OMZ125-1252-5A000-FHD-0T-SN-00
3404.2323.22	OMZ 125 SICHERUNG 750mA T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 750mA	OMZ125-1252-0A750-FHD-0T-SN-00
3404.2323.11	OMZ 125 SICHERUNG 750mA T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 750mA	OMZ125-1252-0A750-FHD-0T-SN-00
3404.2323.23	OMZ 125 SICHERUNG 750mA T	Fuseholder with fuse-links		OMZ 125	OMZ 125 F. in Holder T 750mA	OMZ125-1252-0A750-FHD-0T-SN-00
3-103-382	RTS-AC100			RTS	RTS Thermal Fuse >210°C	RTS-AC100
3-104-513	RTS-AC100 3. Gen			RTS	RTS Thermal Fuse >210°C	RTS-AC100
3-104-514	RTS-AC100 3. Gen			RTS	RTS Thermal Fuse >210°C	RTS-AC100
3-103-383	RTS-AS500			RTS	RTS Thermal Fuse >210°C with shunt	RTS-AS500
3-119-589	RTS-AS500 3. Gen			RTS	RTS Thermal Fuse >210°C with shunt	RTS-AS500
3-119-590	RTS-AS500 3. Gen			RTS	RTS Thermal Fuse >210°C with shunt	RTS-AS500
3-110-065	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
3-110-066	UAI 1206	Surface mount fuse	F 7.5A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 7.5A	UAI1206-1206-7A500-SMD-0F-AU-00
3413.0420.11	UAI 1206	Surface mount fuse	F 7.5A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 7.5A	UAI1206-1206-7A500-SMD-0F-AU-00
3413.0420.22	UAI 1206	Surface mount fuse	F 7.5A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 7.5A	UAI1206-1206-7A500-SMD-0F-AU-00
3413.0420.24	UAI 1206	Surface mount fuse	F 7.5A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 7.5A	UAI1206-1206-7A500-SMD-0F-AU-00
3413.0420.25	UAI 1206	Surface mount fuse	F 7.5A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 7.5A	UAI1206-1206-7A500-SMD-0F-AU-00
3413.0421	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
3413.0421	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
3413.0421	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
3413.0421	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
3413.0421.11	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
3413.0421.22	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
3413.0421.24	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
3413.0421.25	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
3413.0421.25.D	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
3413.0421.25.E	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
3413.0421.25.S	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC	UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
3-108-641	UMF 250	UMF 250 SICHERUNG 15A		UMF 250	UMF 250 Fuse F 15A	UMF250-0310-15A00-SMD-0F-SN-00
3405.0163.11	UMF 250	Sub-miniature fuse-links	F 500mA L	UMF 250	UMF 250 Fuse F 500mA L 250V AC	UMF250-0310-0A500-SMD-0F-SN-00
3405.0163.24	UMF 250	Sub-miniature fuse-links	F 500mA L	UMF 250	UMF 250 Fuse F 500mA L 250V AC	UMF250-0310-0A500-SMD-0F-SN-00
3405.0164.11	UMF 250	Sub-miniature fuse-links	F 630mA L	UMF 250	UMF 250 Fuse F 630mA L 250V AC	UMF250-0310-0A630-SMD-0F-SN-00
3405.0164.24	UMF 250	Sub-miniature fuse-links	F 630mA L	UMF 250	UMF 250 Fuse F 630mA L 250V AC	UMF250-0310-0A630-SMD-0F-SN-00
3405.0165.11	UMF 250	Sub-miniature fuse-links	F 800mA L	UMF 250	UMF 250 Fuse F 800mA L 250V AC	UMF250-0310-0A800-SMD-0F-SN-00
3405.0165.24	UMF 250	Sub-miniature fuse-links	F 800mA L	UMF 250	UMF 250 Fuse F 800mA L 250V AC	UMF250-0310-0A800-SMD-0F-SN-00
3405.0166.11	UMF 250	Sub-miniature fuse-links	F 1A L	UMF 250	UMF 250 Fuse F 1A L 250V AC	UMF250-0310-1A000-SMD-0F-SN-00
3405.0166.24	UMF 250	Sub-miniature fuse-links	F 1A L	UMF 250	UMF 250 Fuse F 1A L 250V AC	UMF250-0310-1A000-SMD-0F-SN-00
3405.0167.11	UMF 250	Sub-miniature fuse-links	F 1.25A L	UMF 250	UMF 250 Fuse F 1.25A L 250V AC	UMF250-0310-1A250-SMD-0F-SN-00
3405.0167.24	UMF 250	Sub-miniature fuse-links	F 1.25A L	UMF 250	UMF 250 Fuse F 1.25A L 250V AC	UMF250-0310-1A250-SMD-0F-SN-00
3405.0168.11	UMF 250	Sub-miniature fuse-links	F 1.6A L	UMF 250	UMF 250 Fuse F 1.6A L 250V AC	UMF250-0310-1A600-SMD-0F-SN-00
3405.0168.24	UMF 250	Sub-miniature fuse-links	F 1.6A L	UMF 250	UMF 250 Fuse F 1.6A L 250V AC	UMF250-0310-1A600-SMD-0F-SN-00
3405.0169.11	UMF 250	Sub-miniature fuse-links	F 2A L	UMF 250	UMF 250 Fuse F 2A L 250V AC	UMF250-0310-2A000-SMD-0F-SN-00
3405.0169.24	UMF 250	Sub-miniature fuse-links	F 2A L	UMF 250	UMF 250 Fuse F 2A L 250V AC	UMF250-0310-2A000-SMD-0F-SN-00
3405.0170.11	UMF 250	Sub-miniature fuse-links	F 2.5A L	UMF 250	UMF 250 Fuse F 2.5A L 250V AC	UMF250-0310-2A500-SMD-0F-SN-00
3405.0170.24	UMF 250	Sub-miniature fuse-links	F 2.5A L	UMF 250	UMF 250 Fuse F 2.5A L 250V AC	UMF250-0310-2A500-SMD-0F-SN-00
3405.0171.11	UMF 250	Sub-miniature fuse-links	F 3.15A L	UMF 250	UMF 250 Fuse F 3.15A L 250V AC	UMF250-0310-3A150-SMD-0F-SN-00
3405.0171.24	UMF 250	Sub-miniature fuse-links	F 3.15A L	UMF 250	UMF 250 Fuse F 3.15A L 250V AC	UMF250-0310-3A150-SMD-0F-SN-00
3405.0172.11	UMF 250	Sub-miniature fuse-links	F 4A L	UMF 250	UMF 250 Fuse F 4A L 250V AC	UMF250-0310-4A000-SMD-0F-SN-00
3405.0172.24	UMF 250	Sub-miniature fuse-links	F 4A L	UMF 250	UMF 250 Fuse F 4A L 250V AC	UMF250-0310-4A000-SMD-0F-SN-00
3405.0173.11	UMF 250	Sub-miniature fuse-links	F 5A L	UMF 250	UMF 250 Fuse F 5A L 250V AC	UMF250-0310-5A000-SMD-0F-SN-00
3405.0173.24	UMF 250	Sub-miniature fuse-links	F 5A L	UMF 250	UMF 250 Fuse F 5A L 250V AC	UMF250-0310-5A000-SMD-0F-SN-00
3405.0174.11	UMF 250	Sub-miniature fuse-links	F 6.3A L	UMF 250	UMF 250 Fuse F 6.3A L 250V AC	UMF250-0310-6A300-SMD-0F-SN-00
3405.0174.24	UMF 250	Sub-miniature fuse-links	F 6.3A L	UMF 250	UMF 250 Fuse F 6.3A L 250V AC	UMF250-0310-6A300-SMD-0F-SN-00
3405.0175.11	UMF 250	Sub-miniature fuse-links	F 8A L	UMF 250	UMF 250 Fuse F 8A L 250V AC	UMF250-0310-8A000-SMD-0F-SN-00
3405.0175.24	UMF 250	Sub-miniature fuse-links	F 8A L	UMF 250	UMF 250 Fuse F 8A L 250V AC	UMF250-0310-8A000-SMD-0F-SN-00
3405.0176.11	UMF 250	Miniature fuse-links	10A	UMF 250	UMF 250 Fuse F 10A	UMF250-0310-10A00-SMD-0F-SN-00
3405.0176.24	UMF 250	Miniature fuse-links	10A	UMF 250	UMF 250 Fuse F 10A	UMF250-0310-10A00-SMD-0F-SN-00
3405.0178.11	UMF 250	Sub-miniature fuse-links	15A	UMF 250	UMF 250 Fuse F 15A	UMF250-0310-15A00-SMD-0F-SN-00
3405.0178.24	UMF 250	Sub-miniature fuse-links	15A	UMF 250	UMF 250 Fuse F 15A	UMF250-0310-15A00-SMD-0F-SN-00
3404.2463.11	UMK 250	Fuse-links + Fuseholder	F 500mA L	UMK 250	UMK 250 F. in Holder F 500mA L 250V AC	UMK250-4211-0A500-FHD-0F-AG-00
3404.2463.22	UMK 250	Fuse-links + Fuseholder	F 500mA L	UMK 250	UMK 250 F. in Holder F 500mA L 250V AC	UMK250-4211-0A500-FHD-0F-AG-00
3404.2464.11	UMK 250	Fuse-links + Fuseholder	F 630mA L	UMK 250	UMK 250 F. in Holder F 630mA L 250V AC	UMK250-4211-0A630-FHD-0F-AG-00
3404.2464.22	UMK 250	Fuse-links + Fuseholder	F 630mA L	UMK 250	UMK 250 F. in Holder F 630mA L 250V AC	UMK250-4211-0A630-FHD-0F-AG-00
3404.2465.11	UMK 250	Fuse-links + Fuseholder	F 800mA L	UMK 250	UMK 250 F. in Holder 800mA F	UMK250-4211-0A800-FHD-0F-AG-00
3404.2465.22	UMK 250	Fuse-links + Fuseholder	F 800mA L	UMK 250	UMK 250 F. in Holder F 800mA L 250V AC	UMK250-4211-0A800-FHD-0F-AG-00
3404.2466.11	UMK 250	Fuse-links + Fuseholder	F 1A L	UMK 250	UMK 250 F. in Holder F 1A L 250V AC	UMK250-4211-1A000-FHD-0F-AG-00
3404.2466.22	UMK 250	Fuse-links + Fuseholder	F 1A L	UMK 250	UMK 250 F. in Holder F 1A L 250V AC	UMK250-4211-1A000-FHD-0F-AG-00
3404.2467.11	UMK 250	Fuse-links + Fuseholder	F 1.25A L	UMK 250	UMK 250 F. in Holder F 1.25A L 250V AC	UMK250-4211-1A250-FHD-0F-AG-00
3404.2467.22	UMK 250	Fuse-links + Fuseholder	F 1.25A L	UMK 250	UMK 250 F. in Holder F 1.25A L 250V AC	UMK250-4211-1A250-FHD-0F-AG-00
3404.2468.11	UMK 250	Fuse-links + Fuseholder	F 1.6A L	UMK 250	UMK 250 F. in Holder 1.6A F	UMK250-4211-1A600-FHD-0F-AG-00
3404.2468.22	UMK 250	Fuse-links + Fuseholder	F 1.6A L	UMK 250	UMK 250 F. in Holder F 1.6A L 250V AC	UMK250-4211-1A600-FHD-0F-AG-00
3404.2469.11	UMK 250	Fuse-links + Fuseholder	F 2A L	UMK 250	UMK 250 F. in Holder F 2A L 250V AC	UMK250-4211-2A000-FHD-0F-AG-00
3404.2469.22	UMK 250	Fuse-links + Fuseholder	F 2A L	UMK 250	UMK 250 F. in Holder 2 A F	UMK250-4211-2A000-FHD-0F-AG-00
3404.2470.11	UMK 250	Fuse-links + Fuseholder	F 2.5A L	UMK 250	UMK 250 F. in Holder F 2.5A L 250V AC	UMK250-4211-2A500-FHD-0F-AG-00
3404.2470.22	UMK 250	Fuse-links + Fuseholder	F 2.5A L	UMK 250	UMK 250 F. in Holder F 2.5A L 250V AC	UMK250-4211-2A500-FHD-0F-AG-00
3404.2471.11	UMK 250	Fuse-links+Fuseholder	F 3.15A L	UMK 250	UMK 250 F. in Holder 3.15A F	UMK250-4211-3A150-FHD-0F-AG-00
3404.2471.22	UMK 250	Fuse-links + Fuseholder	F 3.15A L	UMK 250	UMK 250 F. in Holder F 3.15A L 250V AC	UMK250-4211-3A150-FHD-0F-AG-00
3404.2472.11	UMK 250	Fuse-links + Fuseholder	F 4A L	UMK 250	UMK 250 F. in Holder F 4A L 250V AC	UMK250-4211-4A000-FHD-0F-AG-00
3404.2472.22	UMK 250	Fuse-links + Fuseholder	F 4A L	UMK 250	UMK 250 F. in Holder 4A F	UMK250-4211-4A000-FHD-0F-AG-00
3-101-576	UMT 250	Sub-miniature fuse-links	T 6.3A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 6.3A	UMT250-0310-6A300-SMD-0T-SN-00
3403.0173.11	UMT 250	Sub-miniature fuse-links	T 5A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 5A L 250V AC	UMT250-0310-5A000-SMD-0T-SN-00
3403.0173.24	UMT 250	Sub-miniature fuse-links	T 5A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 5A L 250V AC	UMT250-0310-5A000-SMD-0T-SN-00
3403.0174.11	UMT 250	Sub-miniature fuse-links	T 6.3A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 6.3A L 250V AC	UMT250-0310-6A300-SMD-0T-SN-00
3403.0174.24	UMT 250	Sub-miniature fuse-links	T 6.3A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 6.3A L 250V AC	UMT250-0310-6A300-SMD-0T-SN-00
3403.0174.24	UMT 250	Sub-miniature fuse-links	T 6.3A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 6.3A L 250V AC	UMT250-0310-6A300-SMD-0T-SN-00
3403.0174.24	UMT 250	Sub-miniature fuse-links	T 6.3A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 6.3A L 250V AC	UMT250-0310-6A300-SMD-0T-SN-00
3403.0175.11	UMT 250	Sub-miniature fuse-links	T 8A AC250V / DC125V	UMT 250	UMT 250 Fuse T 8A	UMT250-0310-8A000-SMD-0T-SN-00
3403.0175.24	UMT 250	Sub-miniature fuse-links	T 8A AC250V / DC125V	UMT 250	UMT 250 Fuse T 8A	UMT250-0310-8A000-SMD-0T-SN-00
3403.0176.11	UMT 250	Sub-miniature fuse-links	T 10A AC250V / DC125V	UMT 250	UMT 250 Fuse T 10A	UMT250-0310-10A00-SMD-0T-SN-00
3403.0176.24	UMT 250	Sub-miniature fuse-links	T 10A AC250V / DC125V	UMT 250	UMT 250 Fuse T 10A	UMT250-0310-10A00-SMD-0T-SN-00
3403.0155.11	UMT 250	Sub-miniature fuse-links	T 80mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 80mA L 250V AC	UMT250-0310-0A080-SMD-0T-SN-00
3403.0155.24	UMT 250	Sub-miniature fuse-links	T 80mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 80mA L 250V AC	UMT250-0310-0A080-SMD-0T-SN-00
3-101-577	UMT 250	Sub-miniature fuse-links	T 1.25A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 1.25A	UMT250-0310-1A250-SMD-0T-SN-00
3403.0161.11	UMT 250	Sub-miniature fuse-links	T 315mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 315mA L 250V AC	UMT250-0310-0A315-SMD-0T-SN-00
3403.0161.24	UMT 250	Sub-miniature fuse-links	T 315mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 315mA L 250V AC	UMT250-0310-0A315-SMD-0T-SN-00
3403.0162.11	UMT 250	Sub-miniature fuse-links	T 400mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 400mA L 250V AC	UMT250-0310-0A400-SMD-0T-SN-00
3403.0162.24	UMT 250	Sub-miniature fuse-links	T 400mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 400mA L 250V AC	UMT250-0310-0A400-SMD-0T-SN-00
3403.0163.11	UMT 250	Sub-miniature fuse-links	T 500mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 500mA L 250V AC	UMT250-0310-0A500-SMD-0T-SN-00
3403.0163.24	UMT 250	Sub-miniature fuse-links	T 500mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 500mA L 250V AC	UMT250-0310-0A500-SMD-0T-SN-00
3403.0163.24	UMT 250	Sub-miniature fuse-links	T 500mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 500mA L 250V AC	UMT250-0310-0A500-SMD-0T-SN-00
3403.0164.11	UMT 250	Sub-miniature fuse-links	T 630mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 630mA L 250V AC	UMT250-0310-0A630-SMD-0T-SN-00
3403.0164.24	UMT 250	Sub-miniature fuse-links	T 630mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 630mA L 250V AC	UMT250-0310-0A630-SMD-0T-SN-00
3403.0165.11	UMT 250	Sub-miniature fuse-links	T 800mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 800mA L 250V AC	UMT250-0310-0A800-SMD-0T-SN-00
3403.0165.24	UMT 250	Sub-miniature fuse-links	T 800mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 800mA L 250V AC	UMT250-0310-0A800-SMD-0T-SN-00
3403.0166.11	UMT 250	Sub-miniature fuse-links	T 1A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 1A L 250V AC	UMT250-0310-1A000-SMD-0T-SN-00
3403.0166.24	UMT 250	Sub-miniature fuse-links	T 1A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 1A L 250V AC	UMT250-0310-1A000-SMD-0T-SN-00
3403.0167.11	UMT 250	Sub-miniature fuse-links	T 1.25A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 1.25A L 250V AC	UMT250-0310-1A250-SMD-0T-SN-00
3403.0167.24	UMT 250	Sub-miniature fuse-links	T 1.25A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 1.25A L 250V AC	UMT250-0310-1A250-SMD-0T-SN-00
3403.0168.11	UMT 250	Sub-miniature fuse-links	T 1.6A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 1.6A L 250V AC	UMT250-0310-1A600-SMD-0T-SN-00
3403.0168.24	UMT 250	Sub-miniature fuse-links	T 1.6A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 1.6A L 250V AC	UMT250-0310-1A600-SMD-0T-SN-00
3403.0169.11	UMT 250	Sub-miniature fuse-links	T 2A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 2A L 250V AC	UMT250-0310-2A000-SMD-0T-SN-00
3403.0169.24	UMT 250	Sub-miniature fuse-links	T 2A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 2A L 250V AC	UMT250-0310-2A000-SMD-0T-SN-00

3403.0170.11	UMT 250	Sub-miniature fuse-links	T 2.5A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 2.5A L 250V AC	UMT250-0310-2A500-SMD-0T-SN-00
3403.0170.24	UMT 250	Sub-miniature fuse-links	T 2.5A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 2.5A L 250V AC	UMT250-0310-2A500-SMD-0T-SN-00
3403.0171.11	UMT 250	Sub-miniature fuse-links	T 3.15A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 3.15A L 250V AC	UMT250-0310-3A150-SMD-0T-SN-00
3403.0171.24	UMT 250	Sub-miniature fuse-links	T 3.15A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 3.15A L 250V AC	UMT250-0310-3A150-SMD-0T-SN-00
3403.0172.11	UMT 250	Sub-miniature fuse-links	T 4 AL AC250V / DC125V	UMT 250	UMT 250 Fuse T 4A L 250V AC	UMT250-0310-4A000-SMD-0T-SN-00
3403.0172.24	UMT 250	Sub-miniature fuse-links	T 4 A L AC250V / DC125V	UMT 250	UMT 250 Fuse T 4A L 250V AC	UMT250-0310-4A000-SMD-0T-SN-00
3403.0173.11.RM	UMT 250	Sub-miniature fuse-links	T 5 A AC250V / DC125V	UMT 250	UMT 250 Fuse T 5A L 250V AC	UMT250-0310-5A000-SMD-0T-SN-00
3403.0173.24.RM	UMT 250	Sub-miniature fuse-links	T 5 A AC250V / DC125V	UMT 250	UMT 250 Fuse T 5A L 250V AC	UMT250-0310-5A000-SMD-0T-SN-00
3403.0176.11.RM	UMT 250	Sub-miniature fuse-links	T 10A AC250V / DC125V	UMT 250	UMT 250 Fuse T 10A	UMT250-0310-10A00-SMD-0T-SN-00
3403.0176.24.RM	UMT 250	Sub-miniature fuse-links	T 10A AC250V / DC125V	UMT 250	UMT 250 Fuse T 10A	UMT250-0310-10A00-SMD-0T-SN-00
3-120-959	UMT 250	Sub-miniature fuse-links	T 250mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 250mA	UMT250-0310-0A250-SMD-0T-SN-00
3-120-960	UMT 250	Sub-miniature fuse-links	T 250mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 250mA	UMT250-0310-0A250-SMD-0T-SN-00
3403.0156.11	UMT 250	Sub-miniature fuse-links	T 100mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 100mA L 250V AC	UMT250-0310-0A100-SMD-0T-SN-00
3403.0156.24	UMT 250	Sub-miniature fuse-links	T 100mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 100mA L 250V AC	UMT250-0310-0A100-SMD-0T-SN-00
3403.0157.11	UMT 250	Sub-miniature fuse-links	T 125mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 125mA L 250V AC	UMT250-0310-0A125-SMD-0T-SN-00
3403.0157.24	UMT 250	Sub-miniature fuse-links	T 125mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 125mA L 250V AC	UMT250-0310-0A125-SMD-0T-SN-00
3403.0158.11	UMT 250	Sub-miniature fuse-links	T 160mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 160mA L 250V AC	UMT250-0310-0A160-SMD-0T-SN-00
3403.0158.24	UMT 250	Sub-miniature fuse-links	T 160mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 160mA L 250V AC	UMT250-0310-0A160-SMD-0T-SN-00
3403.0159.11	UMT 250	Sub-miniature fuse-links	T 200mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 200mA L 250V AC	UMT250-0310-0A200-SMD-0T-SN-00
3403.0159.24	UMT 250	Sub-miniature fuse-links	T 200mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 200mA L 250V AC	UMT250-0310-0A200-SMD-0T-SN-00
3403.0160.11	UMT 250	Sub-miniature fuse-links	T 250mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 250mA L 250V AC	UMT250-0310-0A250-SMD-0T-SN-00
3403.0160.24	UMT 250	Sub-miniature fuse-links	T 250mA L AC250V / DC125V	UMT 250	UMT 250 Fuse T 250mA L 250V AC	UMT250-0310-0A250-SMD-0T-SN-00
3403.0263.11	UMT-H	Surface mount fuses (SMD)	80mA	UMT-H	UMT-H Fuse 80mA	UMTH-5316-0A080-SMD-0T-SN-00
3403.0264.11	UMT-H	Surface mount fuses (SMD)	100mA	UMT-H	UMT-H Fuse 100mA	UMTH-5316-0A100-SMD-0T-SN-00
3403.0265.11	UMT-H	Surface mount fuses (SMD)	125mA	UMT-H	UMT-H Fuse 125mA	UMTH-5316-0A125-SMD-0T-SN-00
3403.0266.11	UMT-H	Surface mount fuses (SMD)	160mA	UMT-H	UMT-H Fuse 160mA	UMTH-5316-0A160-SMD-0T-SN-00
3403.0263.23	UMT-H	Surface mount fuses (SMD)	80mA	UMT-H	UMT-H Fuse 80mA	UMTH-5316-0A080-SMD-0T-SN-00
3403.0264.23	UMT-H	Surface mount fuses (SMD)	100mA	UMT-H	UMT-H Fuse 100mA	UMTH-5316-0A100-SMD-0T-SN-00
3403.0265.23	UMT-H	Surface mount fuses (SMD)	125mA	UMT-H	UMT-H Fuse 125mA	UMTH-5316-0A125-SMD-0T-SN-00
3403.0266.23	UMT-H	Surface mount fuses (SMD)	160mA	UMT-H	UMT-H Fuse 160mA	UMTH-5316-0A160-SMD-0T-SN-00
3403.0276.11	UMT-H	Surface mount fuses (SMD)	1.6A	UMT-H	UMT-H Fuse 1.6A	UMTH-5316-1A600-SMD-0T-SN-00
3403.0276.23	UMT-H	Surface mount fuses (SMD)	1.6A	UMT-H	UMT-H Fuse 1.6A	UMTH-5316-1A600-SMD-0T-SN-00
3403.0277.11	UMT-H	Surface mount fuses (SMD)	2A	UMT-H	UMT-H Fuse 2A	UMTH-5316-2A000-SMD-0T-SN-00
3403.0277.23	UMT-H	Surface mount fuses (SMD)	2A	UMT-H	UMT-H Fuse 2A	UMTH-5316-2A000-SMD-0T-SN-00
3403.0277.23.K	UMT-H	Surface mount fuses (SMD)	2A	UMT-H	UMT-H Fuse 2A	UMTH-5316-2A000-SMD-0T-SN-01
3403.0277.23.K2	UMT-H	Surface mount fuses (SMD)	2A	UMT-H	UMT-H Fuse 2A	UMTH-5316-2A000-SMD-0T-SN-02
3403.0282.11	UMT-H	Surface mount fuses (SMD)	6.3A	UMT-H	UMT-H Fuse 6.3A	UMTH-5316-6A300-SMD-0T-SN-00
3403.0282.23	UMT-H	Surface mount fuses (SMD)	6.3A	UMT-H	UMT-H Fuse 6.3A	UMTH-5316-6A300-SMD-0T-SN-00
3403.0266	UMT-H	Surface mount fuses (SMD)	160mA	UMT-H	UMT-H Fuse 160mA	UMTH-5316-0A160-SMD-0T-SN-00
3403.0276	UMT-H	Surface mount fuses (SMD)	1.6A	UMT-H	UMT-H Fuse 1.6A	UMTH-5316-1A600-SMD-0T-SN-00
3403.0282	UMT-H	Surface mount fuses (SMD)	6.3A	UMT-H	UMT-H Fuse 6.3A	UMTH-5316-6A300-SMD-0T-SN-00
3403.0267	UMT-H	Surface mount fuses (SMD)	200mA	UMT-H	UMT-H Fuse 200mA	UMTH-5316-0A200-SMD-0T-SN-00
3403.0267.11	UMT-H	Surface mount fuses (SMD)	200mA	UMT-H	UMT-H Fuse 200mA	UMTH-5316-0A200-SMD-0T-SN-00
3403.0267.23	UMT-H	Surface mount fuses (SMD)	200mA	UMT-H	UMT-H Fuse 200mA	UMTH-5316-0A200-SMD-0T-SN-00
3403.0268	UMT-H	Surface mount fuses (SMD)	250mA	UMT-H	UMT-H Fuse 250mA	UMTH-5316-0A250-SMD-0T-SN-00
3403.0268.23	UMT-H	Surface mount fuses (SMD)	250mA	UMT-H	UMT-H Fuse 250mA	UMTH-5316-0A250-SMD-0T-SN-00
3403.0269.23	UMT-H	Surface mount fuses (SMD)	315mA	UMT-H	UMT-H Fuse 315mA	UMTH-5316-0A315-SMD-0T-SN-00
3403.0287	UMT-H	Surface mount fuses (SMD)	20A	UMT-H	UMT-H Fuse 20A	UMTH-5316-20A00-SMD-0T-SN-00
3403.0287.11	UMT-H	Surface mount fuses (SMD)	20A	UMT-H	UMT-H Fuse 20A	UMTH-5316-20A00-SMD-0T-SN-00
3403.0287.23	UMT-H	Surface mount fuses (SMD)	20A	UMT-H	UMT-H Fuse 20A	UMTH-5316-20A00-SMD-0T-SN-00
3403.0288	UMT-H	Surface mount fuses (SMD)	25A	UMT-H	UMT-H Fuse 25A	UMTH-5316-25A00-SMD-0T-SN-00
3403.0288.11	UMT-H	Surface mount fuses (SMD)	25A	UMT-H	UMT-H Fuse 25A	UMTH-5316-25A00-SMD-0T-SN-00
3403.0288.23	UMT-H	Surface mount fuses (SMD)	25A	UMT-H	UMT-H Fuse 25A	UMTH-5316-25A00-SMD-0T-SN-00
3403.0289	UMT-H	Surface mount fuses (SMD)	30A	UMT-H	UMT-H Fuse 30A	UMTH-5316-30A00-SMD-0T-SN-00
3403.0289.11	UMT-H	Surface mount fuses (SMD)	30A	UMT-H	UMT-H Fuse 30A	UMTH-5316-30A00-SMD-0T-SN-00
3403.0289.23	UMT-H	Surface mount fuses (SMD)	30A	UMT-H	UMT-H Fuse 30A	UMTH-5316-30A00-SMD-0T-SN-00
3403.0264	UMT-H	Surface mount fuses (SMD)	100mA	UMT-H	UMT-H Fuse 100mA	UMTH-5316-0A100-SMD-0T-SN-00
3403.0265	UMT-H	Surface mount fuses (SMD)	125mA	UMT-H	UMT-H Fuse 125mA	UMTH-5316-0A125-SMD-0T-SN-00
3403.0268.11	UMT-H	Surface mount fuses (SMD)	250mA	UMT-H	UMT-H Fuse 250mA	UMTH-5316-0A250-SMD-0T-SN-00
3403.0269	UMT-H	Surface mount fuses (SMD)	315mA	UMT-H	UMT-H Fuse 315mA	UMTH-5316-0A315-SMD-0T-SN-00
3403.0269.11	UMT-H	Surface mount fuses (SMD)	315mA	UMT-H	UMT-H Fuse 315mA	UMTH-5316-0A315-SMD-0T-SN-00
3403.0270	UMT-H	Surface mount fuses (SMD)	400mA	UMT-H	UMT-H Fuse 400mA	UMTH-5316-0A400-SMD-0T-SN-00
3403.0270.11	UMT-H	Surface mount fuses (SMD)	400mA	UMT-H	UMT-H Fuse 400mA	UMTH-5316-0A400-SMD-0T-SN-00
3403.0270.23	UMT-H	Surface mount fuses (SMD)	400mA	UMT-H	UMT-H Fuse 400mA	UMTH-5316-0A400-SMD-0T-SN-00
3403.0271	UMT-H	Surface mount fuses (SMD)	500mA	UMT-H	UMT-H Fuse 500mA	UMTH-5316-0A500-SMD-0T-SN-00
3403.0271.11	UMT-H	Surface mount fuses (SMD)	500mA	UMT-H	UMT-H Fuse 500mA	UMTH-5316-0A500-SMD-0T-SN-00
3403.0271.23	UMT-H	Surface mount fuses (SMD)	500mA	UMT-H	UMT-H Fuse 500mA	UMTH-5316-0A500-SMD-0T-SN-00
3403.0272	UMT-H	Surface mount fuses (SMD)	630mA	UMT-H	UMT-H Fuse 630mA	UMTH-5316-0A630-SMD-0T-SN-00
3403.0272.11	UMT-H	Surface mount fuses (SMD)	630mA	UMT-H	UMT-H Fuse 630mA	UMTH-5316-0A630-SMD-0T-SN-00
3403.0272.23	UMT-H	Surface mount fuses (SMD)	630mA	UMT-H	UMT-H Fuse 630mA	UMTH-5316-0A630-SMD-0T-SN-00
3403.0273	UMT-H	Surface mount fuses (SMD)	800mA	UMT-H	UMT-H Fuse 800mA	UMTH-5316-0A800-SMD-0T-SN-00
3403.0273.11	UMT-H	Surface mount fuses (SMD)	800mA	UMT-H	UMT-H Fuse 800mA	UMTH-5316-0A800-SMD-0T-SN-00
3403.0273.23	UMT-H	Surface mount fuses (SMD)	800mA	UMT-H	UMT-H Fuse 800mA	UMTH-5316-0A800-SMD-0T-SN-00
3403.0274	UMT-H	Surface mount fuses (SMD)	1A	UMT-H	UMT-H Fuse 1A	UMTH-5316-1A000-SMD-0T-SN-00
3403.0274.11	UMT-H	Surface mount fuses (SMD)	1A	UMT-H	UMT-H Fuse 1A	UMTH-5316-1A000-SMD-0T-SN-00
3403.0274.23	UMT-H	Surface mount fuses (SMD)	1A	UMT-H	UMT-H Fuse 1A	UMTH-5316-1A000-SMD-0T-SN-00
3403.0275	UMT-H	Surface mount fuses (SMD)	1.25A	UMT-H	UMT-H Fuse 1.25A	UMTH-5316-1A250-SMD-0T-SN-00
3403.0275.11	UMT-H	Surface mount fuses (SMD)	1.25A	UMT-H	UMT-H Fuse 1.25A	UMTH-5316-1A250-SMD-0T-SN-00
3403.0275.23	UMT-H	Surface mount fuses (SMD)	1.25A	UMT-H	UMT-H Fuse 1.25A	UMTH-5316-1A250-SMD-0T-SN-00
3403.0278	UMT-H	Surface mount fuses (SMD)	2.5A	UMT-H	UMT-H Fuse 2.5A	UMTH-5316-2A500-SMD-0T-SN-00
3403.0278.11	UMT-H	Surface mount fuses (SMD)	2.5A	UMT-H	UMT-H Fuse 2.5A	UMTH-5316-2A500-SMD-0T-SN-00
3403.0278.23	UMT-H	Surface mount fuses (SMD)	2.5A	UMT-H	UMT-H Fuse 2.5A	UMTH-5316-2A500-SMD-0T-SN-00
3403.0279	UMT-H	Surface mount fuses (SMD)	3.15A	UMT-H	UMT-H Fuse 3.15A	UMTH-5316-3A150-SMD-0T-SN-00
3403.0279.11	UMT-H	Surface mount fuses (SMD)	3.15A	UMT-H	UMT-H Fuse 3.15A	UMTH-5316-3A150-SMD-0T-SN-00
3403.0279.23	UMT-H	Surface mount fuses (SMD)	3.15A	UMT-H	UMT-H Fuse 3.15A	UMTH-5316-3A150-SMD-0T-SN-00
3403.0280	UMT-H	Surface mount fuses (SMD)	4A	UMT-H	UMT-H Fuse 4A	UMTH-5316-4A000-SMD-0T-SN-00
3403.0280.11	UMT-H	Surface mount fuses (SMD)	4A	UMT-H	UMT-H Fuse 4A	UMTH-5316-4A000-SMD-0T-SN-00
3403.0280.23	UMT-H	Surface mount fuses (SMD)	4A	UMT-H	UMT-H Fuse 4A	UMTH-5316-4A000-SMD-0T-SN-00
3403.0281	UMT-H	Surface mount fuses (SMD)	5A	UMT-H	UMT-H Fuse 5A	UMTH-5316-5A000-SMD-0T-SN-00
3403.0281.11	UMT-H	Surface mount fuses (SMD)	5A	UMT-H	UMT-H Fuse 5A	UMTH-5316-5A000-SMD-0T-SN-00
3403.0281.23	UMT-H	Surface mount fuses (SMD)	5A	UMT-H	UMT-H Fuse 5A	UMTH-5316-5A000-SMD-0T-SN-00
3403.0283	UMT-H	Surface mount fuses (SMD)	8A	UMT-H	UMT-H Fuse 8A	UMTH-5316-8A000-SMD-0T-SN-00
3403.0283.11	UMT-H	Surface mount fuses (SMD)	8A	UMT-H	UMT-H Fuse 8A	UMTH-5316-8A000-SMD-0T-SN-00
3403.0283.23	UMT-H	Surface mount fuses (SMD)	8A	UMT-H	UMT-H Fuse 8A	UMTH-5316-8A000-SMD-0T-SN-00
3403.0284	UMT-H	Surface mount fuses (SMD)	10A	UMT-H	UMT-H Fuse 10A	UMTH-5316-10A00-SMD-0T-SN-00
3403.0284.11	UMT-H	Surface mount fuses (SMD)	10A	UMT-H	UMT-H Fuse 10A	UMTH-5316-10A00-SMD-0T-SN-00
3403.0284.23	UMT-H	Surface mount fuses (SMD)	10A	UMT-H	UMT-H Fuse 10A	UMTH-5316-10A00-SMD-0T-SN-00
3403.0285.11	UMT-H	Surface mount fuses (SMD)	12.5A	UMT-H	UMT-H Fuse 12.5A	UMTH-5316-12A50-SMD-0T-SN-00
3403.0285.23	UMT-H	Surface mount fuses (SMD)	12.5A	UMT-H	UMT-H Fuse 12.5A	UMTH-5316-12A50-SMD-0T-SN-00
3403.0286.11	UMT-H	Surface mount fuses (SMD)	16A	UMT-H	UMT-H Fuse 16A	UMTH-5316-16A00-SMD-0T-SN-00
3403.0286.23	UMT-H	Surface mount fuses (SMD)	16A	UMT-H	UMT-H Fuse 16A	UMTH-5316-16A00-SMD-0T-SN-00
3-103-079	UMT-M	Surface mount fuses (SMD)	16A	UMT-H	UMT-M Fuse 16A	UMTM-5316-16A00-SMD-0T-SN-00
3-109-343	UMT-M	Surface mount fuses (SMD)	16A	UMT-H	UMT-M Fuse 16A	UMTM-5316-16A00-SMD-0T-SN-00
3404.2411.11	UMZ 250	Fuse-links + Fuseholder	T 315mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 315mA	UMZ250-4211-0A315-FHD-0T-AG-00
3404.2411.22	UMZ 250	Fuse-links + Fuseholder	T 315mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 315mA	UMZ250-4211-0A315-FHD-0T-AG-00
3404.2412.11	UMZ 250	Fuse-links + Fuseholder	T 400mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 400mA	UMZ250-4211-0A400-FHD-0T-AG-00
3404.2412.22	UMZ 250	Fuse-links + Fuseholder	T 400mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 400mA	UMZ250-4211-0A400-FHD-0T-AG-00
3404.2413.11	UMZ 250	Fuse-links + Fuseholder	T 500mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 500mA	UMZ250-4211-0A500-FHD-0T-AG-00
3404.2413.22	UMZ 250	Fuse-links + Fuseholder	T 500mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 500mA	UMZ250-4211-0A500-FHD-0T-AG-00
3404.2414.11	UMZ 250	Fuse-links + Fuseholder	T 630mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 630mA	UMZ250-4211-0A630-FHD-0T-AG-00
3404.2414.22	UMZ 250	Fuse-links + Fuseholder	T 630mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 630mA	UMZ250-4211-0A630-FHD-0T-AG-00
3404.2415.11	UMZ 250	Fuse-links + Fuseholder	T 800mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 800mA	UMZ250-4211-0A800-FHD-0T-AG-00
3404.2415.22	UMZ 250	Fuse-links + Fuseholder	T 800mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 800mA	UMZ250-4211-0A800-FHD-0T-AG-00
3404.2416.11	UMZ 250	Fuse-links + Fuseholder	T 1A L AC250V	UMZ 250	UMZ 250 F. in Holder T 1A	UMZ250-4211-1A000-FHD-0T-AG-00
3404.2416.22	UMZ 250	Fuse-links + Fuseholder	T 1A L AC250V	UMZ 250	UMZ 250 F. in Holder T 1A	UMZ250-4211-1A000-FHD-0T-AG-00
3404.2417.11	UMZ 250	Fuse-links + Fuseholder	T 1.25A L AC250V	UMZ 250	UMZ 250 F. in Holder T 1.25A	UMZ250-4211-1A250-FHD-0T-AG-00
3404.2417.22	UMZ 250	Fuse-links + Fuseholder	T 1.25A L AC250V	UMZ 250	UMZ 250 F. in Holder T 1.25A	UMZ250-4211-1A250-FHD-0T-AG-00
3404.2418.11	UMZ 250	Fuse-links + Fuseholder	T 1.6A L AC250V	UMZ 250	UMZ 250 F. in Holder T 1.6A	UMZ250-4211-1A600-FHD-0T-AG-00

3404.2418.22	UMZ 250	Fuse-links + Fuseholder	T 1.6A L AC250V	UMZ 250	UMZ 250 F. in Holder T 1.6A	UMZ250-4211-1A600-FHD-0T-AG-00
3404.2419.11	UMZ 250	Fuse-links + Fuseholder	T 2A L AC250V	UMZ 250	UMZ 250 F. in Holder T 2A	UMZ250-4211-2A000-FHD-0T-AG-00
3404.2419.22	UMZ 250	Fuse-links + Fuseholder	T 2A L AC250V	UMZ 250	UMZ 250 F. in Holder T 2A	UMZ250-4211-2A000-FHD-0T-AG-00
3404.2420.22	UMZ 250	Fuse-links + Fuseholder	T 2.5A L AC250V	UMZ 250	UMZ 250 F. in Holder T 2.5A	UMZ250-4211-2A500-FHD-0T-AG-00
3404.2421.11	UMZ 250	Fuse-links + Fuseholder	T 3.15A L AC250V	UMZ 250	UMZ 250 F. in Holder T 3.15A	UMZ250-4211-3A150-FHD-0T-AG-00
3404.2421.22	UMZ 250	Fuse-links + Fuseholder	T 3.15A L AC250V	UMZ 250	UMZ 250 F. in Holder T 3.15A	UMZ250-4211-3A150-FHD-0T-AG-00
3404.2422.22	UMZ 250	Fuse-links + Fuseholder	T 4A L AC250V	UMZ 250	UMZ 250 F. in Holder T 4A	UMZ250-4211-4A000-FHD-0T-AG-00
3404.2420.11	UMZ 250	Fuse-links + Fuseholder	T 2.5A L AC250V	UMZ 250	UMZ 250 F. in Holder T 2.5A	UMZ250-4211-2A500-FHD-0T-AG-00
3404.2422.11	UMZ 250	Fuse-links + Fuseholder	T 4A L AC250V	UMZ 250	UMZ 250 F. in Holder T 4A	UMZ250-4211-4A000-FHD-0T-AG-00
3404.2405.11	UMZ 250	Fuse-links + Fuseholder	T 80mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 80mA	UMZ250-4211-0A080-FHD-0T-AG-00
3404.2405.22	UMZ 250	Fuse-links + Fuseholder	T 80mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 80mA	UMZ250-4211-0A080-FHD-0T-AG-00
3404.2406.11	UMZ 250	Fuse-links + Fuseholder	T 100mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 100mA	UMZ250-4211-0A100-FHD-0T-AG-00
3404.2406.22	UMZ 250	Fuse-links + Fuseholder	T 100mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 100mA	UMZ250-4211-0A100-FHD-0T-AG-00
3404.2407.11	UMZ 250	Fuse-links + Fuseholder	T 125mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 125mA	UMZ250-4211-0A125-FHD-0T-AG-00
3404.2407.22	UMZ 250	Fuse-links + Fuseholder	T 125mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 125mA	UMZ250-4211-0A125-FHD-0T-AG-00
3404.2408.11	UMZ 250	Fuse-links + Fuseholder	T 160mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 160mA	UMZ250-4211-0A160-FHD-0T-AG-00
3404.2408.22	UMZ 250	Fuse-links + Fuseholder	T 160mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 160mA	UMZ250-4211-0A160-FHD-0T-AG-00
3404.2409.11	UMZ 250	Fuse-links + Fuseholder	T 200mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 200mA	UMZ250-4211-0A200-FHD-0T-AG-00
3404.2409.22	UMZ 250	Fuse-links + Fuseholder	T 200mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 200mA	UMZ250-4211-0A200-FHD-0T-AG-00
3404.2410.11	UMZ 250	Fuseholder with fuse-links	T 250mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 250mA	UMZ250-4211-0A250-FHD-0T-AG-00
3404.2410.22	UMZ 250	Fuse-links + Fuseholder	T 250mA L AC250V	UMZ 250	UMZ 250 F. in Holder T 250mA	UMZ250-4211-0A250-FHD-0T-AG-00
3412.0114.24	USF 0603	Surface mount fuse	FF 750mA 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 750mA	USF0603-0603-0A750-SMD-SF-AU-00
3412.0114.26	USF 0603	Surface mount fuse	FF 750mA 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 750mA	USF0603-0603-0A750-SMD-SF-AU-00
3412.0113.24	USF 0603	Surface mount fuse	FF 500mA 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 500mA	USF0603-0603-0A500-SMD-SF-AU-00
3412.0113.26	USF 0603	Surface mount fuse	FF 500mA 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 500mA	USF0603-0603-0A500-SMD-SF-AU-00
3412.0115.24	USF 0603	Surface mount fuse	FF 1A 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 1A	USF0603-0603-1A000-SMD-SF-AU-00
3412.0115.26	USF 0603	Surface mount fuse	FF 1A 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 1A	USF0603-0603-1A000-SMD-SF-AU-00
3412.0117.24	USF 0603	Surface mount fuse	FF 1.5A 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 1.5A	USF0603-0603-1A500-SMD-SF-AU-00
3412.0117.26	USF 0603	Surface mount fuse	FF 1.5A 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 1.5A	USF0603-0603-1A500-SMD-SF-AU-00
3412.0119.26	USF 0603	Surface mount fuse	FF 2A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 2A	USF0603-0603-2A000-SMD-SF-AU-00
3412.0120.24	USF 0603	Surface mount fuse	FF 2.5A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 2.5A	USF0603-0603-2A500-SMD-SF-AU-00
3412.0120.26	USF 0603	Surface mount fuse	FF 2.5A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 2.5A	USF0603-0603-2A500-SMD-SF-AU-00
3412.0121.26	USF 0603	Surface mount fuse	FF 3A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 3A	USF0603-0603-3A000-SMD-SF-AU-00
3412.0122.24	USF 0603	Surface mount fuse	FF 3.5A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 3.5A	USF0603-0603-3A500-SMD-SF-AU-00
3412.0122.26	USF 0603	Surface mount fuse	FF 3.5A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 3.5A	USF0603-0603-3A500-SMD-SF-AU-00
3412.0123.26	USF 0603	Surface mount fuse	FF 4A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 4A	USF0603-0603-4A000-SMD-SF-AU-00
3412.0124.24	USF 0603	Surface mount fuse	FF 5A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 5A	USF0603-0603-5A000-SMD-SF-AU-00
3412.0124.26	USF 0603	Surface mount fuse	FF 5A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 5A	USF0603-0603-5A000-SMD-SF-AU-00
3412.0113.11	USF 0603	Surface mount fuse	FF 500mA 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 500mA	USF0603-0603-0A500-SMD-SF-AU-00
3412.0114.11	USF 0603	Surface mount fuse	FF 750mA 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 750mA	USF0603-0603-0A750-SMD-SF-AU-00
3412.0115.11	USF 0603	Surface mount fuse	FF 1A 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 1A	USF0603-0603-1A000-SMD-SF-AU-00
3412.0117.11	USF 0603	Surface mount fuse	FF 1.5A 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 1.5A	USF0603-0603-1A500-SMD-SF-AU-00
3412.0119.11	USF 0603	Surface mount fuse	FF 2A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 2A	USF0603-0603-2A000-SMD-SF-AU-00
3412.0120.11	USF 0603	Surface mount fuse	FF 2.5A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 2.5A	USF0603-0603-2A500-SMD-SF-AU-00
3412.0121.11	USF 0603	Surface mount fuse	FF 3A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 3A	USF0603-0603-3A000-SMD-SF-AU-00
3412.0122.11	USF 0603	Surface mount fuse	FF 3.5A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 3.5A	USF0603-0603-3A500-SMD-SF-AU-00
3412.0123.11	USF 0603	Surface mount fuse	FF 4A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 4A	USF0603-0603-4A000-SMD-SF-AU-00
3412.0124.11	USF 0603	Surface mount fuse	FF 5A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 5A	USF0603-0603-5A000-SMD-SF-AU-00
3412.0119.24	USF 0603	Surface mount fuse	FF 2A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 2A	USF0603-0603-2A000-SMD-SF-AU-00
3412.0113.22	USF 0603	Surface mount fuse	FF 500mA 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 500mA	USF0603-0603-0A500-SMD-SF-AU-00
3412.0114.22	USF 0603	Surface mount fuse	FF 750mA 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 750mA	USF0603-0603-0A750-SMD-SF-AU-00
3412.0115.22	USF 0603	Surface mount fuse	FF 1A 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 1A	USF0603-0603-1A000-SMD-SF-AU-00
3412.0117.22	USF 0603	Surface mount fuse	FF 1.5A 32VAC / 63VDC	USF 0603	USF 0603 Fuse FF 1.5A	USF0603-0603-1A500-SMD-SF-AU-00
3412.0119.22	USF 0603	Surface mount fuse	FF 2A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 2A	USF0603-0603-2A000-SMD-SF-AU-00
3412.0120.22	USF 0603	Surface mount fuse	FF 2.5A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 2.5A	USF0603-0603-2A500-SMD-SF-AU-00
3412.0121.22	USF 0603	Surface mount fuse	FF 3A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 3A	USF0603-0603-3A000-SMD-SF-AU-00
3412.0122.22	USF 0603	Surface mount fuse	FF 3.5A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 3.5A	USF0603-0603-3A500-SMD-SF-AU-00
3412.0123.22	USF 0603	Surface mount fuse	FF 4A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 4A	USF0603-0603-4A000-SMD-SF-AU-00
3412.0124.22	USF 0603	Surface mount fuse	FF 5A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 5A	USF0603-0603-5A000-SMD-SF-AU-00
3412.0121.24	USF 0603	Surface mount fuse	FF 3A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 3A	USF0603-0603-3A000-SMD-SF-AU-00
3412.0123.24	USF 0603	Surface mount fuse	FF 4A 32VAC / 32VDC	USF 0603	USF 0603 Fuse FF 4A	USF0603-0603-4A000-SMD-SF-AU-00
3413.0112.22	USF 1206	Surface mount fuse	FF 375mA 125VAC / DC	USF 1206	USF 1206 Fuse FF 375mA	USF1206-1206-0A375-SMD-SF-AU-00
3413.0112.24	USF 1206	Surface mount fuse	FF 375mA 125VAC / DC	USF 1206	USF 1206 Fuse FF 375mA	USF1206-1206-0A375-SMD-SF-AU-00
3413.0112.26	USF 1206	Surface mount fuse	FF 375mA 125VAC / DC	USF 1206	USF 1206 Fuse FF 375mA	USF1206-1206-0A375-SMD-SF-AU-00
3413.0112.11	USF 1206	Surface mount fuse	FF 375mA 125VAC / DC	USF 1206	USF 1206 Fuse FF 375mA	USF1206-1206-0A375-SMD-SF-AU-00
3413.0113.11	USF 1206	Surface mount fuse	FF 500mA 125VAC / DC	USF 1206	USF 1206 Fuse FF 500mA	USF1206-1206-0A500-SMD-SF-AU-00
3413.0114.11	USF 1206	Surface mount fuse	FF 750mA 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 750mA	USF1206-1206-0A750-SMD-SF-AU-00
3413.0115.11	USF 1206	Surface mount fuse	FF 1A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 1A	USF1206-1206-1A000-SMD-SF-AU-00
3413.0116.11	USF 1206	Surface mount fuse	FF 1.25A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 1.25A	USF1206-1206-1A250-SMD-SF-AU-00
3413.0117.11	USF 1206	Surface mount fuse	FF 1.5A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 1.5A	USF1206-1206-1A500-SMD-SF-AU-00
3413.0119.11	USF 1206	Surface mount fuse	FF 2A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 2A	USF1206-1206-2A000-SMD-SF-AU-00
3413.0120.11	USF 1206	Surface mount fuse	FF 2.5A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 2.5A	USF1206-1206-2A500-SMD-SF-AU-00
3413.0121.11	USF 1206	Surface mount fuse	FF 3A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 3A	USF1206-1206-3A000-SMD-SF-AU-00
3413.0123.11	USF 1206	Surface mount fuse	FF 4A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 4A	USF1206-1206-4A000-SMD-SF-AU-00
3413.0113.22	USF 1206	Surface mount fuse	FF 500mA 125VAC / DC	USF 1206	USF 1206 Fuse FF 500mA	USF1206-1206-0A500-SMD-SF-AU-00
3413.0113.24	USF 1206	Surface mount fuse	FF 500mA 125VAC / DC	USF 1206	USF 1206 Fuse FF 500mA	USF1206-1206-0A500-SMD-SF-AU-00
3413.0113.26	USF 1206	Surface mount fuse	FF 500mA 125VAC / DC	USF 1206	USF 1206 Fuse FF 500mA	USF1206-1206-0A500-SMD-SF-AU-00
3413.0114.22	USF 1206	Surface mount fuse	FF 750mA 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 750mA	USF1206-1206-0A750-SMD-SF-AU-00
3413.0114.24	USF 1206	Surface mount fuse	FF 750mA 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 750mA	USF1206-1206-0A750-SMD-SF-AU-00
3413.0114.26	USF 1206	Surface mount fuse	FF 750mA 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 750mA	USF1206-1206-0A750-SMD-SF-AU-00
3413.0115.22	USF 1206	Surface mount fuse	FF 1A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 1A	USF1206-1206-1A000-SMD-SF-AU-00
3413.0115.24	USF 1206	Surface mount fuse	FF 1A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 1A	USF1206-1206-1A000-SMD-SF-AU-00
3413.0115.26	USF 1206	Surface mount fuse	FF 1A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 1A	USF1206-1206-1A000-SMD-SF-AU-00
3413.0116.22	USF 1206	Surface mount fuse	FF 1.25A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 1.25A	USF1206-1206-1A250-SMD-SF-AU-00
3413.0116.24	USF 1206	Surface mount fuse	FF 1.25A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 1.25A	USF1206-1206-1A250-SMD-SF-AU-00
3413.0116.26	USF 1206	Surface mount fuse	FF 1.25A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 1.25A	USF1206-1206-1A250-SMD-SF-AU-00
3413.0117.22	USF 1206	Surface mount fuse	FF 1.5A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 1.5A	USF1206-1206-1A500-SMD-SF-AU-00
3413.0117.24	USF 1206	Surface mount fuse	FF 1.5A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 1.5A	USF1206-1206-1A500-SMD-SF-AU-00
3413.0117.26	USF 1206	Surface mount fuse	FF 1.5A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 1.5A	USF1206-1206-1A500-SMD-SF-AU-00
3413.0119.22	USF 1206	Surface mount fuse	FF 2A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 2A	USF1206-1206-2A000-SMD-SF-AU-00
3413.0119.24	USF 1206	Surface mount fuse	FF 2A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 2A	USF1206-1206-2A000-SMD-SF-AU-00
3413.0119.26	USF 1206	Surface mount fuse	FF 2A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 2A	USF1206-1206-2A000-SMD-SF-AU-00
3413.0120.22	USF 1206	Surface mount fuse	FF 2.5A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 2.5A	USF1206-1206-2A500-SMD-SF-AU-00
3413.0120.24	USF 1206	Surface mount fuse	FF 2.5A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 2.5A	USF1206-1206-2A500-SMD-SF-AU-00
3413.0120.26	USF 1206	Surface mount fuse	FF 2.5A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 2.5A	USF1206-1206-2A500-SMD-SF-AU-00
3413.0121.22	USF 1206	Surface mount fuse	FF 3A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 3A	USF1206-1206-3A000-SMD-SF-AU-00
3413.0121.24	USF 1206	Surface mount fuse	FF 3A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 3A	USF1206-1206-3A000-SMD-SF-AU-00
3413.0121.26	USF 1206	Surface mount fuse	FF 3A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 3A	USF1206-1206-3A000-SMD-SF-AU-00
3413.0123.22	USF 1206	Surface mount fuse	FF 4A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 4A	USF1206-1206-4A000-SMD-SF-AU-00
3413.0123.24	USF 1206	Surface mount fuse	FF 4A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 4A	USF1206-1206-4A000-SMD-SF-AU-00
3413.0123.26	USF 1206	Surface mount fuse	FF 4A 32VAC / 63V DC	USF 1206	USF 1206 Fuse FF 4A	USF1206-1206-4A000-SMD-SF-AU-00
3413.0002.11	USFF 1206	Surface mount fuse	FF 50mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 50mA	USFF-1206-0A050-SMD-SF-AU-00
3413.0002.22	USFF 1206	Surface mount fuse	FF 50mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 50mA	USFF-1206-0A050-SMD-SF-AU-00
3413.0002.24	USFF 1206	Surface mount fuse	FF 50mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 50mA	USFF-1206-0A050-SMD-SF-AU-00
3413.0006.11	USFF 1206	Surface mount fuse	FF 125mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 125mA	USFF-1206-0A125-SMD-SF-AU-00
3413.0006.22	USFF 1206	Surface mount fuse	FF 125mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 125mA	USFF-1206-0A125-SMD-SF-AU-00
3413.0006.24	USFF 1206	Surface mount fuse	FF 125mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 125mA	USFF-1206-0A125-SMD-SF-AU-00
3413.0008.11	USFF 1206	Surface mount fuse	FF 160mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 160mA	USFF-1206-0A160-SMD-SF-AU-00
3413.0008.22	USFF 1206	Surface mount fuse	FF 160mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 160mA	USFF-1206-0A160-SMD-SF-AU-00
3413.0008.24	USFF 1206	Surface mount fuse	FF 160mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 160mA	USFF-1206-0A160-SMD-SF-AU-00
3413.0009.11	USFF 1206	Surface mount fuse	FF 200mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 200mA	USFF-1206-0A200-SMD-SF-AU-00
3413.0009.22	USFF 1206	Surface mount fuse	FF 200mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 200mA	USFF-1206-0A200-SMD-SF-AU-00
3413.0009.24	USFF 1206	Surface mount fuse	FF 200mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 200mA	USFF-1206-0A200-SMD-SF-AU-00
3413.0010.11	USFF 1206	Surface mount fuse	FF 250mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 250mA	USFF-1206-0A250-SMD-SF-AU-00
3413.0010.22	USFF 1206	Surface mount fuse	FF 250mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 250mA	USFF-1206-0A250-SMD-SF-AU-00
3413.0010.24	USFF 1206	Surface mount fuse	FF 250mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 250mA	USFF-1206-0A250-SMD-SF-AU-00
3413.0002.26	USFF 1206	Surface mount fuse	FF 50mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 50mA	USFF-1206-0A050-SMD-SF-AU-00
3413.0006.26	USFF 1206	Surface mount fuse	FF 125mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 125mA	USFF-1206-0A125-SMD-SF-AU-00

3413.0008.26	USFF 1206	Surface mount fuse	FF 160mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 160mA	USFF-1206-0A160-SMD-SF-AU-00
3413.0009.26	USFF 1206	Surface mount fuse	FF 200mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 200mA	USFF-1206-0A200-SMD-SF-AU-00
3413.0010.26	USFF 1206	Surface mount fuse	FF 250mA 125VAC / 63VDC	USFF 1206	USFF 1206 Fuse FF 250mA	USFF-1206-0A250-SMD-SF-AU-00
3413.0213.22	USI 1206	Surface mount fuse	F 500mA L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 500mA	USI-1206-0A500-SMD-0F-AU-00
3413.0219.22	USI 1206	Surface mount fuse	F 2A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 2A	USI-1206-2A000-SMD-0F-AU-00
3413.0223.22	USI 1206	Surface mount fuse	F 5A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 5A	USI-1206-5A000-SMD-0F-AU-00
3413.0213.11	USI 1206	Surface mount fuse	F 500mA L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 500mA	USI-1206-0A500-SMD-0F-AU-00
3413.0214.11	USI 1206	Surface mount fuse	F 630mA L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 630mA	USI-1206-0A630-SMD-0F-AU-00
3413.0215.11	USI 1206	Surface mount fuse	F 800mA L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 800mA	USI-1206-0A800-SMD-0F-AU-00
3413.0216.11	USI 1206	Surface mount fuse	F 1A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 1A	USI-1206-1A000-SMD-0F-AU-00
3413.0217.11	USI 1206	Surface mount fuse	F 1.25A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 1.25A	USI-1206-1A250-SMD-0F-AU-00
3413.0218.11	USI 1206	Surface mount fuse	F 1.6A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 1.6A	USI-1206-1A600-SMD-0F-AU-00
3413.0219.11	USI 1206	Surface mount fuse	F 2A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 2A	USI-1206-2A000-SMD-0F-AU-00
3413.0220.11	USI 1206	Surface mount fuse	F 2.5A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 2.5A	USI-1206-2A500-SMD-0F-AU-00
3413.0221.11	USI 1206	Surface mount fuse	F 3.15A L AC32V / DC63V	USI 1206	USI 1206 Fuse F 3.15A	USI-1206-3A150-SMD-0F-AU-00
3413.0222.11	USI 1206	Surface mount fuse	F 4A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 4A	USI-1206-4A000-SMD-0F-AU-00
3413.0223.11	USI 1206	Surface mount fuse	F 5A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 5A	USI-1206-5A000-SMD-0F-AU-00
3413.0224.11	USI 1206	Surface mount fuse	F 6.3A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 6.3A	USI-1206-6A300-SMD-0F-AU-00
3413.0214.22	USI 1206	Surface mount fuse	F 630mA L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 630mA	USI-1206-0A630-SMD-0F-AU-00
3413.0216.22	USI 1206	Surface mount fuse	HCSF	USI 1206	USI 1206 Fuse F 1A	USI-1206-1A000-SMD-0F-AU-00
3413.0222.22	USI 1206	Surface mount fuse	F 4A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 4A	USI-1206-4A000-SMD-0F-AU-00
3413.0224.22	USI 1206	Surface mount fuse	F 6.3A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 6.3A	USI-1206-6A300-SMD-0F-AU-00
3413.0213.24	USI 1206	Surface mount fuse	F 500mA L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 500mA	USI-1206-0A500-SMD-0F-AU-00
3413.0213.26	USI 1206	Surface mount fuse	F 500mA L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 500mA	USI-1206-0A500-SMD-0F-AU-00
3413.0214.24	USI 1206	Surface mount fuse	F 630mA L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 630mA	USI-1206-0A630-SMD-0F-AU-00
3413.0214.26	USI 1206	Surface mount fuse	F 630mA L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 630mA	USI-1206-0A630-SMD-0F-AU-00
3413.0215.22	USI 1206	Surface mount fuse	F 800mA L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 800mA	USI-1206-0A800-SMD-0F-AU-00
3413.0215.24	USI 1206	Surface mount fuse	F 800mA L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 800mA	USI-1206-0A800-SMD-0F-AU-00
3413.0215.26	USI 1206	Surface mount fuse	F 800mA L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 800mA	USI-1206-0A800-SMD-0F-AU-00
3413.0216.24	USI 1206	Surface mount fuse	F 1A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 1A	USI-1206-1A000-SMD-0F-AU-00
3413.0216.26	USI 1206	Surface mount fuse	F 1A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 1A	USI-1206-1A000-SMD-0F-AU-00
3413.0217.22	USI 1206	Surface mount fuse	F 1.25A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 1.25A	USI-1206-1A250-SMD-0F-AU-00
3413.0217.24	USI 1206	Surface mount fuse	F 1.25A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 1.25A	USI-1206-1A250-SMD-0F-AU-00
3413.0217.26	USI 1206	Surface mount fuse	F 1.25A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 1.25A	USI-1206-1A250-SMD-0F-AU-00
3413.0218.22	USI 1206	Surface mount fuse	F 1.6A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 1.6A	USI-1206-1A600-SMD-0F-AU-00
3413.0218.24	USI 1206	Surface mount fuse	F 1.6A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 1.6A	USI-1206-1A600-SMD-0F-AU-00
3413.0218.26	USI 1206	Surface mount fuse	F 1.6A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 1.6A	USI-1206-1A600-SMD-0F-AU-00
3413.0219.24	USI 1206	Surface mount fuse	F 2A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 2A	USI-1206-2A000-SMD-0F-AU-00
3413.0219.26	USI 1206	Surface mount fuse	F 2A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 2A	USI-1206-2A000-SMD-0F-AU-00
3413.0220.22	USI 1206	Surface mount fuse	F 2.5A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 2.5A	USI-1206-2A500-SMD-0F-AU-00
3413.0220.24	USI 1206	Surface mount fuse	F 2.5A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 2.5A	USI-1206-2A500-SMD-0F-AU-00
3413.0220.26	USI 1206	Surface mount fuse	F 2.5A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 2.5A	USI-1206-2A500-SMD-0F-AU-00
3413.0221.00	USI 1206	Surface mount fuse	F 3.15A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 3.15A	USI-1206-3A150-SMD-0F-AU-00
3413.0221.22	USI 1206	Surface mount fuse	F 3.15A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 3.15A	USI-1206-3A150-SMD-0F-AU-00
3413.0221.24	USI 1206	Surface mount fuse	F 3.15A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 3.15A	USI-1206-3A150-SMD-0F-AU-00
3413.0221.26	USI 1206	Surface mount fuse	F 3.15A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 3.15A	USI-1206-3A150-SMD-0F-AU-00
3413.0222.24	USI 1206	Surface mount fuse	F 4A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 4A	USI-1206-4A000-SMD-0F-AU-00
3413.0222.26	USI 1206	Surface mount fuse	F 4A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 4A	USI-1206-4A000-SMD-0F-AU-00
3413.0223.24	USI 1206	Surface mount fuse	F 5A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 5A	USI-1206-5A000-SMD-0F-AU-00
3413.0223.26	USI 1206	Surface mount fuse	F 5A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 5A	USI-1206-5A000-SMD-0F-AU-00
3413.0224.24	USI 1206	Surface mount fuse	F 6.3A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 6.3A	USI-1206-6A300-SMD-0F-AU-00
3413.0224.26	USI 1206	Surface mount fuse	F 6.3A L 32VAC / 63V DC	USI 1206	USI 1206 Fuse F 6.3A	USI-1206-6A300-SMD-0F-AU-00
3413.0512.11	USN 1206		12A	USN 1206	USN 1206 Thermal Fuse 12A	USN1206-12A00
3413.0550.25	USN 1206		12A	USN 1206	USN 1206 Thermal Fuse 12A	USN1206-12A00
3413.0331.22	UST 1206	Surface mount fuse	F 20A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 20A	UST-1206-20A00-SMD-0T-AU-00
3413.0331.24	UST 1206	Surface mount fuse	F 20A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 20A	UST-1206-20A00-SMD-0T-AU-00
3413.0331.26	UST 1206	Surface mount fuse	F 20A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 20A	UST-1206-20A00-SMD-0T-AU-00
3413.0332.22	UST 1206	Surface mount fuse	F 25A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 25A	UST-1206-25A00-SMD-0T-AU-00
3413.0332.24	UST 1206	Surface mount fuse	F 25A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 25A	UST-1206-25A00-SMD-0T-AU-00
3413.0332.26	UST 1206	Surface mount fuse	F 25A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 25A	UST-1206-25A00-SMD-0T-AU-00
3413.0326.11	UST 1206	Surface mount fuse	F 7A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 7A	UST-1206-7A000-SMD-0T-AU-00
3413.0327.11	UST 1206	Surface mount fuse	F 8A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 8A	UST-1206-8A000-SMD-0T-AU-00
3413.0328.11	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 10A	UST-1206-10A00-SMD-0T-AU-00
3413.0329.11	UST 1206	Surface mount fuse	F 12A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 12A	UST-1206-12A00-SMD-0T-AU-00
3413.0330.11	UST 1206	Surface mount fuse	F 15A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 15A	UST-1206-15A00-SMD-0T-AU-00
3413.0331.11	UST 1206	Surface mount fuse	F 20A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 20A	UST-1206-20A00-SMD-0T-AU-00
3413.0332.11	UST 1206	Surface mount fuse	F 25A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 25A	UST-1206-25A00-SMD-0T-AU-00
3413.0326.22	UST 1206	Surface mount fuse	F 7A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 7A	UST-1206-7A000-SMD-0T-AU-00
3413.0326.24	UST 1206	Surface mount fuse	F 7A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 7A	UST-1206-7A000-SMD-0T-AU-00
3413.0326.26	UST 1206	Surface mount fuse	F 7A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 7A	UST-1206-7A000-SMD-0T-AU-00
3413.0327.22	UST 1206	Surface mount fuse	F 8A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 8A	UST-1206-8A000-SMD-0T-AU-00
3413.0327.24	UST 1206	Surface mount fuse	F 8A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 8A	UST-1206-8A000-SMD-0T-AU-00
3413.0327.26	UST 1206	Surface mount fuse	F 8A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 8A	UST-1206-8A000-SMD-0T-AU-00
3413.0328.22	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 10A	UST-1206-10A00-SMD-0T-AU-00
3413.0328.24	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 10A	UST-1206-10A00-SMD-0T-AU-00
3413.0328.24.CI	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 10A	UST-1206-10A00-SMD-0T-AU-00
3413.0328.26	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 10A	UST-1206-10A00-SMD-0T-AU-00
3413.0329.22	UST 1206	Surface mount fuse	F 12A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 12A	UST-1206-12A00-SMD-0T-AU-00
3413.0329.24	UST 1206	Surface mount fuse	F 12A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 12A	UST-1206-12A00-SMD-0T-AU-00
3413.0329.26	UST 1206	Surface mount fuse	F 12A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 12A	UST-1206-12A00-SMD-0T-AU-00
3413.0330.22	UST 1206	Surface mount fuse	F 15A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 15A	UST-1206-15A00-SMD-0T-AU-00
3413.0330.24	UST 1206	Surface mount fuse	F 15A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 15A	UST-1206-15A00-SMD-0T-AU-00
3413.0330.26	UST 1206	Surface mount fuse	F 15A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 15A	UST-1206-15A00-SMD-0T-AU-00
3413.0327.11	UST 1206	Surface mount fuse	F 8A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 8A	UST-1206-8A000-SMD-0T-AU-00
3413.0327.24	UST 1206	Surface mount fuse	F 8A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 8A	UST-1206-8A000-SMD-0T-AU-00
3413.0327.26	UST 1206	Surface mount fuse	F 8A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 8A	UST-1206-8A000-SMD-0T-AU-00
3413.0328.11	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 10A	UST-1206-10A00-SMD-0T-AU-00
3413.0328.24	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 10A	UST-1206-10A00-SMD-0T-AU-00
3413.0328.26	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 10A	UST-1206-10A00-SMD-0T-AU-00
3413.0330.11	UST 1206	Surface mount fuse	F 15A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 15A	UST-1206-15A00-SMD-0T-AU-00
3413.0330.24	UST 1206	Surface mount fuse	F 15A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 15A	UST-1206-15A00-SMD-0T-AU-00
3413.0330.26	UST 1206	Surface mount fuse	F 15A 32VAC / 63V DC	UST 1206	UST 1206 Fuse T 15A	UST-1206-15A00-SMD-0T-AU-00
3-101-050	HCF	Sub-miniature fuse	7.5 A 125VAC / DC	HCF	HCF Fuse 7.5A	HCF-3220-7A500-SMD-SF-SN-00
3-101-051	HCF	Sub-miniature fuse	10 A 125VAC / DC	HCF	HCF Fuse 10A	HCF-3220-10A00-SMD-SF-SN-00
3-101-056	HCF	Sub-miniature fuse	5 A 125VAC / DC	HCF	HCF Fuse 5A	HCF-3220-5A000-SMD-SF-SN-00
3-101-062	HCF	Sub-miniature fuse	15A 125VAC / DC	HCF	HCF Fuse 15A	HCF-3220-15A00-SMD-SF-SN-00
3-122-712	UMT-W	Surface mount fuse (SMD)	5A	UMT-W	UMT-W Fuse TT 5A	UMTW-5316-5A000-SMD-ST-SN-00
3-122-713	UMT-W	Surface mount fuse (SMD)	5A	UMT-W	UMT-W Fuse TT 5A	UMTW-5316-5A000-SMD-ST-SN-00
3-122-714	UMT-W	Surface mount fuse (SMD)	7.5A	UMT-W	UMT-W Fuse TT 7.5A	UMTW-5316-7A500-SMD-ST-SN-00
3-122-715	UMT-W	Surface mount fuse (SMD)	7.5A	UMT-W	UMT-W Fuse TT 7.5A	UMTW-5316-7A500-SMD-ST-SN-00
3-122-716	UMT-W	Surface mount fuse (SMD)	10A	UMT-W	UMT-W Fuse TT 10A	UMTW-5316-10A00-SMD-ST-SN-00
3-122-717	UMT-W	Surface mount fuse (SMD)	10A	UMT-W	UMT-W Fuse TT 10A	UMTW-5316-10A00-SMD-ST-SN-00
3-122-718	UMT-W	Surface mount fuse (SMD)	15A	UMT-W	UMT-W Fuse TT 15A	UMTW-5316-15A00-SMD-ST-SN-00
3-122-719	UMT-W	Surface mount fuse (SMD)	15A	UMT-W	UMT-W Fuse TT 15A	UMTW-5316-15A00-SMD-ST-SN-00
3-122-720	UMT-W	Surface mount fuse (SMD)	20A	UMT-W	UMT-W Fuse TT 20A	UMTW-5316-20A00-SMD-ST-SN-00
3-122-721	UMT-W	Surface mount fuse (SMD)	20A	UMT-W	UMT-W Fuse TT 20A	UMTW-5316-20A00-SMD-ST-SN-00